

## **Mechanic Motor Vehicle 1st Year – Transparencies**



# Table of Contents

<b><u>Mechanic Motor Vehicle 1st Year – Transparencies</u></b> .....	<b>1</b>
<u>Vernier Caliper parts and principle</u> .....	1
<u>Reading of Vernier Caliper</u> .....	2
<u>Micrometer parts and graduations</u> .....	3
<u>Micrometer reading</u> .....	4
<u>Wheel alignment</u> .....	5
<u>Tyre wear Patterns and causes</u> .....	7
<u>Clutch actuation (Hydraulic)</u> .....	7
<u>Types of gears</u> .....	8
<u>Function of Universal joint and slip joint</u> .....	9
<u>Hydraulic brakes</u> .....	10
<u>Relationship between piston and flywheel movement</u> .....	12
<u>Four Stroke cycle operation (petrol)</u> .....	12
<u>Four Stroke cycle operation (Diesel)</u> .....	13
<u>Two stroke cycle operation (Petrol)</u> .....	14
<u>Bore dial gauge–checking ovality and taper</u> .....	15
<u>Overhead valve operating mechanism</u> .....	17
<u>Cooling system</u> .....	18
<u>Fuel pump operation</u> .....	19
<u>Carburettor Function</u> .....	20
<u>Float and starting circuit</u> .....	21
<u>Idling and main circuit</u> .....	22
<u>Pump and Econostat circuit</u> .....	23
<u>Lubrication system (Engine oil circulation)</u> .....	24
<u>Lubrication system (full flow and by pass flow oil filter)</u> .....	25
<u>Ignition system</u> .....	26



# Mechanic Motor Vehicle 1st Year – Transparencies



**CIMM** CENTRAL INSTRUCTIONAL  
 MEDIA INSTITUTE, MADRAS  
 AN INDO - GERMAN PROJECT






Directorate General of Employment & Training, Ministry of Labour, Govt. of India.

Developed by  
 CENTRAL INSTRUCTIONAL MEDIA INSTITUTE  
 in collaboration with DEUTSCHE GESELLSCHAFT FUER TECHNISCHE ZUSAMMENARBEIT (GTZ)  
 Germany.  
 P.O. Box 3142, 76, GST Road, Guindy, Madras – 600 032. Phone: 234 5256, 234 5257, Fax: (0091-44) 234 2791

## Vernier Caliper parts and principle


TR 01 02 01 01 95





### Reading of Vernier Caliper

TR 01 02 01 02 95




49 Main scale divisions are divided into 50 vernier scale divisions

$$\begin{aligned}
 \text{VALUE OF 1 VSD} &= \frac{49}{50} \text{ mm} \\
 \text{LEAST COUNT} &= 1\text{MD} - 1\text{VSD} \\
 &= 1 - \frac{49}{50} \\
 &= \frac{1}{50} = 0.02 \text{ mm}
 \end{aligned}$$


MAIN SCALEREADING = 10.00mm

VALUE OF COINCIDING  
VERNIER DIVISION } = 00.40mm


READING = 10.40mm




ASSIGNMENTS:-




A READING 9.32 mm



B READING 35.40 mm




C READING 15.00 mm



D READING 66.80 mm

**Micrometer parts and graduations**



TR 01 02 02 01 95



## Micrometer reading


TR 01 02 02 02 95

### MICROMETER GRADUATIONS




### MICROMETER READING






Example




MAIN DIVISIONS	=	12.00mm
SUB DIVISION	=	0.50mm
THIMBLE DIVISIONS	=	0.24mm
<b>READING</b>	=	<b>12.74mm</b>


ASSIGNMENTS:-



**B READING** 5.50 mm




**B READING** 19.55 mm




**B READING** 1.89 mm

Wheel alignment


TR 10 09 04 01 95



**A = Caster angle**




**B**     King pin inclination  
**C**     Camber angle  
**B+C=** Included angle



**D-E = Toe-in**

# Tyre wear Patterns and causes



TR 10 09 03 01 95



WEAR PATTERN	IDEAL	<u>At shoulders</u>	<u>At center</u>	<u>On one side</u>	<u>Feathered edge</u>	<u>Bald spots</u>
CAUSE	PERFECT CONDITION	<u>Under inflation</u>	<u>Over inflation</u>	<u>Excessive camber</u>	<u>Incorrect toe</u>	<u>Unbalanced wheel</u>

# Clutch actuation (Hydraulic)

TR 10 02 06 01 95




**Action:** The diaphragm spring (6) pushes the pressure plate (5) against the clutch plate (4). Power flows from crankshaft (8) ' flywheel (9) ' pressure plate (5) ' clutch plate (4) ' and to primary shaft (10)

**Action:** The downward movement of the clutch pedal (1) pumps fluid from the master cylinder (2) to the slave cylinder (3) and pushes the release bearing (7) and the diaphragm (6) inwards. The pressure plate (5) and the clutch plate (4) move away from the flywheel (9). No power flows from the crankshaft (8) to the primary shaft (10)


## Types of gears

TR 10 03 07 01 95




**Spur Gears**

Teeth are straight and parallel  
 Only one tooth is in contact at a time.  
 There is no axial thrust  
 APPLICATION – Gear box




**Worm Gears**

Teeth are at an angle and curved  
 More teeth are in contact at a time  
 There is axial thrust  
 APPLICATION – Gear box.




**Helical gears**

Teeth are at an angle  
 More teeth are in contact at a time  
 There is axial thrust  
 APPLICATION – Gear box.




**Rack and Pinion**

Teeth are parallel  
 Only one tooth is in contact at a time  
 There is no axial thrust.  
 Converts rotary motion into linear motion.  
 APPLICATION – Steering



**Herring Bone Gears**


Teeth are straight at an angle  
 More teeth are in contact at a time  
 Axial thrust is neutralized  
 APPLICATION – Gear box



**Spiral Bevel Gears**


Teeth are curved  
 More teeth are in contact at a time  
 Produces axial thrust  
 Transmits torque at 90°  
 APPLICATION – Final drive differential

**Function of Universal joint and slip joint**



Hydraulic brakes

TR 10 11 02 01 95




When the brake pedal (1) is pressed, the push rod forces the piston (3) of the Master Cylinder (2) forward against the spring tension. The primary cup covers compensating port (4). The pressurised fluid is supplied to the wheel cylinders (7) through the non return check valve (6). The wheel cylinder piston pushes the brake shoes (8) towards the brake drum (9) and stops the rotation of the brake drum.

When the brake pedal (1) is released, the pedal comes to its original position with the help of the pedal return spring and shoes by the retracting springs. Wheel cylinder pistons are pushed inside and the fluid is sent back to master cylinder (2) by lifting the check valve (6) from its seat through the compensating port (4) and the transfer port (5).

# Relationship between piston and flywheel movement

TR 10 01 01 01 95

- A Top Dead center (T.D.C)
- B Bottom Dead Center (B.D.C.)
- C Stroke length
- D Crank throw




## Four Stroke cycle operation (petrol)

TR 10 01 01 02 95


--	--	--	--






**Four Stroke cycle operation (Diesel)**

TR 10 01 01 03 95




			
<b>A – Suction Stroke</b>	<b>B – Compression Stroke</b>	<b>C – Power Stroke</b>	<b>D – Exhaust Stroke</b>
<p><b>Action:</b> Inlet valve (1) opens and only air enters inside the cylinder.</p>	<p><b>Action:</b> Inlet valve (1) and exhaust valve (3) are closed. Air is compressed.</p>	<p><b>Action:</b> Valves (1) &amp; (3) are closed and Injector (2) sprays diesel. Diesel is ignited by hot compressed air. Piston is forced down by burnt gases.</p>	<p><b>Action:</b> Exhaust valve (3) opens and exhaust gases are forced out of the cylinder.</p>

### Two stroke cycle operation (Petrol)


TR 10 01 01 04 95

--	--	--




### Bore dial gauge–checking ovality and taper

TR 10 01 08 01 95




ENLARGED  
VIEW - A

1. Dial
2. Stem
3. Extension Rod
4. Plunger
5. Guide shoe




A-B	Ovality
-----	---------



C-D	Taper
D-E	
C-E	

**Overhead valve operating mechanism**

TR 10 01 01 05 95



<b>Crankshaft Gear (10)</b>	<b>21 teeth</b>
<b>Camshaft Gear (3)</b>	<b>42 teeth</b>

The flywheel (1) rotates in clock-wise direction.

The crankshaft (2) and the gear (10) also rotate in clockwise direction.


The camshaft gear (3) and the camshaft (4) rotate in the anti-clockwise direction at half of the crankshaft speed.

The eccentricity of the cam lobe (11) pushes the tappet (5) and the push rod (6) in upward direction. The push rod (6) pushes the rocker lever (7).

The rocker lever (7) swivels and the valve (9) is opened against the pressure of the spring (8).


## Cooling system

TR 10 01 07 01 95




**Engine cold**

When the thermostat (5) is closed the by-pass port (9) opens and water circulates in the engine itself and warms up quickly.



**Engine hot**


When the thermostat (5) is opened, the by-pass port (9) closes. Water is circulated to the radiator through outlet (10)



Water flows from pump (1) ' Engine block (2) ' Cylinder head (3) ' radiator uppertank (4) through thermostat (5) ' Radiator core (6) ' Lower tank (7) ' and to water pump (1). Air passes through the radiator cores with the help of a fan (8)


**Fuel pump operation**

TR 10 01 02 01 95



Suction

Delivery



DETAILS:

6


8

6

8

When the rocker arm (1) is actuated by a cam lobe (2), diaphragm (3) is pulled down. The inlet valve (6) opens and the fuel is sucked in chamber (7).

When the diaphragm is pushed up by the spindle (4), the outlet valve (8) opens and the fuel is sent to carburetor via outlet (5).




Idling

When the float chamber is full, back pressure keeps the diaphragm (3) down and the connecting link (9) does not move, only the rocker arm (1) moves. The spring (10) reduces the rattling noise.

**Carburettor Function**

TR 10 01 02 02 95






- A Float circuit:** When the needle valve (2) opens, fuel flows to the float chamber (4) through the inlet (5) and filter (6).
- B Starting circuit:** Petrol is drawn from the float chamber (4) through the starter jet (9) to the passage (12).
- C Idling circuit:** Petrol is drawn to the well (14) from the float chamber (4) through the main jet (20)
- D Main circuit:** Petrol is drawn from the float chamber (4) to the emulsion tube (21) through the main jet (20)
- E Pump circuit:** Petrol is drawn from the float chamber (4) to the pump chamber through the pump inlet valve (23) and to the pump jet (26)
- F Econostat circuit:** Petrol is drawn from the float chamber (4) to the econostat tube (31) through the jet (32)


### Float and starting circuit

TR 10 01 02 03 95



**B Starting circuit**

When the dash board knob is pulled out, the starter valve lever (8) rotates the starter disc valve (10) and opens the fuel passage (12). Petrol is drawn from the float chamber (4) through the starter jet (9) to the fuel passage (12). Air is drawn from the air jet (11). Air fuel mixture passes through the passage (13) below the throttle (7).




**A Float circuit**

When the fuel flows to various circuits, fuel level in the float chamber (4) drops. The float (1) move down and the needle valve (2) opens. Fuel flows through the inlet (5) and the filter (6) to the float chamber (4). When the fuel level rises in the float chamber (4) the float (1) moves up and closes the needle valve (2) by the toggle (3).


### Idling and main circuit

TR 10 01 02 04 95



**D Main circuit**


On further wide opening of the throttle valve (7), air velocity increases across the narrow passage and creates more vacuum. Petrol is drawn from the float chamber (4) through the main jet (20) to the emulsion tube (21). Vacuum draws petrol through the emulsion tube orifices and air through choke tube and the air correction jet (22).




**C Idling circuit**

When the throttle valve (7) is closed, the petrol to flow from the well (14) to the pilot jet (15) through the air bleeder (16). Both air and fuel mixture is drawn through the screw (19) and the orifice (18) to discharge extra mixture required to run the engine at idling speed. Volume of fuel is controlled by the screw (19). When the throttle (7) is closed, the orifice (18) discharges extra mixture required for idling.

### Pump and Econostat circuit



TR 10 01 02 05 95



### F Econostat circuit

Under full load and full throttle opening at cruising speed, petrol is sucked from the float chamber (4) to the econostat tube (31) through the jet (32) and injected by an injector (33) which provides maximum fuel economy.

### E Pump circuit

When the throttle (7) is closed, the diaphragm (25) is pushed back. Petrol is sucked from the float chamber (4) to the pump chamber through the non return valve (23).

Due to sudden wide opening of the throttle (7), the lever (24) pushes the diaphragm (25) forward. Petrol passes through the pump jet (26) and opens the non return valve (27). The petrol is injected to the choke tube by the injector (28). This action supplies extra amount of fuel required for avoiding flat spots. The spring loaded rod (29) is adjusted by a nut (30) for effective travel of the diaphragm.

## Lubrication system (Engine oil circulation)




TR 10 01 06 01 95

### Oil circulation

Oil flows from strainer (10) ' Oil pump (1) ' Filter (15) ' Oil gallery (5) ' Main bearings (4) ' Connecting rod bearings (3) ' and finally to sump.

From main gallery (5) to ' Camshaft bearings (6) ' rocker shaft (7) ' rocker arms (8) ' and to sump.

From main gallery to timing gear/chain (9) ' and to sump. Excess pressure from pump (1) is relieved by the oil pressure relief valve (2)



**Detail X-A: oil under normal pressure**


Relief valve plunger (11) closes the by-pass port (12) and oil passes through outlet port (13) and to the oil filter (15)

**Detail X-B – Oil pressure more than specified limit**

The relief valve plunger (11) moves against the spring pressure (14) and opens the by-pass port (12). Excess of pressurised oil escapes through by-pass port (12) and to the oil sump.


**Lubrication system (full flow and by pass flow oil filter)**

TR 10 01 06 02 95



**Type – Full flow oil filter**

**Function:** From the oil pump (1) all the oil passes through the filter (2) to the main oil gallery (5). By pass valve (4) provided in the filter allows oil to reach main oil gallery directly when the filter is choked. Excess oil pressure is relieved by oil pressure relief valve (3).




**Type – By pass flow oil filter**

**Function:** From the oil pump (1) only part goes to the oil sump (6). The remaining oil goes to the main oil gallery (5). Excess oil pressure is relieved by oil pressure relief valve (3).

**Ignition system**

TR 10 10 04 01 95



**FIRING ORDER: 1-3-4-2**

**Function:** Current flows from battery (A) ' Ignition switch (B) ' the primary windings of the Ignition coil (C) ' CB points (E) ' earth (D). Condenser (F) is fitted parallel to CB points (E). High tension current from coil (C) ' High tension wire (G) ' Carbon rod (T) at the centre of the distributor cap (R) ' rotor (H) ' distributor cap segments (W) ' HT wires (K) ' spark plug (L). The battery (A) the distributor (P) and the spark plug (L) are earthed at points (D) on the vehicle frame. Distributor (P) gets drive from the engine camshaft (M) through the screw gear (N) and rotates at half of the engine speed.

