

IBM 8275 Model 318/322/326 Identification

| | |
|---------------------------------|-------|
| Building/Room/Rack | _____ |
| Unit Number | _____ |
| IP Address | _____ |
| Network Administrator Telephone | _____ |
| Service Contact | _____ |
| Telephone | _____ |

IBM Support Information - WWW

Download latest code, fixes, and technical tips for your IBM products. You can also register to receive e-mail notifications about your products.

<http://www.networking.ibm.com/support>

Using Web Browser Management

You can use the Internet to configure the 8275. Enter the IP address of the switch in your Internet browser's address field. You are prompted for a user name and password.

Note: The default user name is admin. This user name has no default password.

Troubleshooting

1. Determine if fan is running; if not, test the ac power outlet.
2. Remove and reattach all cables. Check all cables, connectors, and ports for damage.
3. Verify that all configuration settings are correct.

4. Verify that the power-on self-test (POST) runs correctly.

POST Error Display

If the 8275 Model 318, 322, or 326 fails during the POST, an error code is displayed in the eight diagnostics LEDs as shown in the following figure.


| Diagnostics LED Indicators | Error Status |
|----------------------------|--------------------------------|
| On ● Off ○ | |
| ○ ○ ● ○ ○ ○ ○ ● | Boot Program Flash Damaged |
| ○ ○ ● ○ ○ ○ ● ○ | Run-Time Program Flash Damaged |
| ○ ○ ● ○ ○ ○ ● ● | CPU Memory Failure |
| ○ ○ ● ○ ○ ● ○ ○ | Peripheral Controller Failure |
| ○ ○ ● ○ ○ ● ○ ● | COM Port Failure |
| ○ ● ○ ○ ○ ○ ○ ● | NPB Failure |
| ○ ● ○ ○ ○ ○ ● ○ | PSP Memory Failure |
| ○ ● ○ ○ ○ ○ ● ● | PSP Failure |
| ○ ● ○ ○ ○ ● ○ ○ | FEIU Failure |
| ○ ● ○ ○ ○ ● ○ ● | PHY Failure |
| ○ ● ○ ○ ○ ● ● ○ | ARL Failure |
| ○ ● ○ ○ ○ ● ● ● | ARL Memory Failure |

Placing a Call to the IBM Product Help Center

- In the U.S.A., call the IBM PC HelpCenter at 1-800-772-2227.
- In Canada, call HelpPC at 1-800-IBM-SERV (1-800-426-7378).
- Outside of the U.S.A. and Canada, contact your place of purchase or your local IBM branch office.

System Status Error LED Indicators

During the POST, the utilization % LEDs indicate module error status shown below.



| Utilization % LEDs | ERROR STATUS |
|------------------------|--------------------|
| ○ ○ ○ ○ ○ ○ ○ ○ | |
| 1 5 10 20 30 50 70 90+ | |
| ● ○ ○ ○ ○ ○ ○ ○ | CPU MODULE FAILURE |
| ○ ● ○ ○ ○ ○ ○ ○ | SLOT #1 FAILURE |
| ○ ○ ● ○ ○ ○ ○ ○ | SLOT #2 FAILURE |
| ○ ○ ○ ● ○ ○ ○ ○ | SLOT #3 FAILURE |
| ○ ○ ○ ○ ● ○ ○ ○ | SLOT #4 FAILURE |

Preparing to Call the IBM Product Help Center

Gather the following information:

- Product model and serial number
- Proof of purchase
- Status of LEDs
- Description of problem
- Exact wording of SNMP traps (if any)
- Hardware and software configuration

If possible be near your 8275. The technical support representative might want to walk you through a procedure during the call.


Status LEDs

Table 1. Meanings of the 8275 LEDs

| LED | State | Meaning |
|------------------|----------|---|
| Power (Power On) | On | There is ac power to the 8275 and the power supply is OK. |
| | Off | No ac power is present, or there is a power supply failure. |
| OK | On | Normal operation. |
| | Off | Internal fault. |
| Fault | On | Internal fault. |
| | Off | Normal operation. |
| Link/Tx/Rx | On | A device is connected to this port but port is idle. |
| | Off | A device is not connected to this port. |
| | Blinking | Port is receiving data. |
| Col (Amber) | On | Collisions detected. |
| | Off | Collisions not detected. |
| 100 / 10 | On | Port is a 100 Mbps port. |
| | Off | Port is a 10 Mbps port or no 100 Mbps detected. |

The utilization % LEDs are a relative indicator of the amount of network traffic being processed by the 8275 (includes both broadcast and management traffic).

Management Menu



- 1 Login Panel
- 2 Main Menu
- 3 System Information
- 4 Management Configuration
- 5 Network Configuration
- 6 Trap Receiver Configuration
- 7 SNMP Community Configuration
- 8 Device Configuration
- 9 Switch Configuration
- 10 Port Configuration
- 11 Port Statistics
- 12 Spanning Tree Configuration
- 13 Serial Port Configuration
- 14 VLAN Port Management
- 15 Create VLAN
- 16 Delete VLAN
- 17 Modify/View VLAN
- 18 Trunking Port Management
- 19 Create/View Trunking Group
- 20 Delete Trunking Group
- 21 Modify Trunking Group
- 22 Port Monitoring
- 23 User Account Management
- 24 Create New User
- 25 Modify Users
- 26 Change Password
- 27 System Utilities
- 28 Download Code to Switch
- 29 Download Configuration Data to Switch
- 30 Upload Configuration Data to Switch
- 31 System Reset
- 32 Factory Reset to Default Configuration
- 33 BootP/TFTP Server Configuration
- 34 Login Timeout Interval
- 35 Ping