




Cash Removal and Replacement Procedures

Bill Dispenser Cassette

Cassette Removal

Step 1:
Pull down blue handle
on front of cassette.





Step 2:
Press and HOLD blue release
button while pulling firmly on
cassette handle.




Cassette Loading



Step 1:
Rotate blue cassette lever clockwise
to open. Lift cassette lid and tilt it all
the way back to support cassette body.



Step 2:
Slide the push plate toward the front
of cassette until it clicks. Stack bills
neatly against the back of the cassette.
Fan bills to ensure all bills are even.




Step 3:
Touch the blue push plate release
latch to secure bills in place .




Cassette Replacement

Step 1:
Close cassette top until
it clicks.



Step 2:
Align cassette in proper slot
and firmly press on front of
cassette until cassette BEEPS
FOUR TIMES.



REMEMBER:
Obtain optimum performance
by avoiding poor quality bills:
No staples
No large tears
No missing sections
No extremely crumpled bills
No foreign bills

REMEMBER:
Ensure loaded bills match the
denomination label located
on the cassette push plate.




Bill Acceptor Cassette Removal and Replacement

Cassette Removal


Step 1:

Lift security cover. Rotate knob counter-clockwise to the REMOVE position.



Step 2:

Lift and tilt bottom of cassette forward. Pull down to remove cassette.



Emptying the Cassette

Step 1:

Insert index finger in top cover access hole, lift cover and remove bills.



Cassette Replacement


Step 1:

Lift and tilt top of cassette forward to fit into acceptor mounting hooks. Firmly push up and back on cassette.



Step 2:

Lift security cover and rotate knob counter-clockwise to ENGAGE position. Pull handle to ensure cassette is properly seated.




Coin Dispenser Cassette Removal and Replacement

Cassette Removal

Step 1:

Grasp the cassette on both sides with both hands and lift the cassette straight out of the base.



Step 2:


Lift straight up until it clears the base completely then remove cassette from the lane.



Emptying the Cassette

Step 1:

Release locks by pressing down on the cassette cover locks with your thumbs and push the cover up until the locks release.



Step 2:


Continue pushing the cover up until the top of the coin chambers are exposed. The top of the chambers will allow enough room to insert additional coins.



Cassette Replacement

Step 1:

Grasp the cassette with both hands and gently insert into the base. Ensure cassette tracks line up with the base.



Step 2:

Ensure the cassette is completely inserted inside the base.



NOTE:
After loading coins push the cover down firmly until the cover locks snap.