

BJT Bias


Copyright (c) 2012 Young W. Lim.

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.2 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license is included in the section entitled "GNU Free Documentation License".


Please send corrections (or suggestions) to youngwlim@hotmail.com.

This document was produced by using OpenOffice and Octave.

Common Base (1)





Electron Flow




Current Flow


Common Base (2)




Electron Flow




Current Flow



Common Emitter (1)







Electron Flow




Current Flow


Common Emitter (2)



Common Collector (1)




Electron Flow





Current Flow


Common Collector (2)




Electron Flow




Current Flow




Common Emitter (2)



Electron Flow




Current Flow




Maintain Magnetic Field


Before



Initial




Final



No Energy in magnetic field

Induced EMF

Storing Magnetic Energy



References

[1] <http://en.wikipedia.org/>

[2] J.H. McClellan, et al., Signal Processing First, Pearson Prentice Hall, 2003