

IBM System/3 Models 4, 8, 10, and 12 Communications Control Program Data Areas and Diagnostic Aids

Program Numbers:

5702-SC1 (Models 8 and 10) 5703-SC1 (Model 4) 5705-SC1 (Model 12)

Features 6033/6070/6071

SY21-0048-1 File No. S3-36

#### Second Edition (March 1978)

. . . . . . .

This is a major revision of, and obsoletes, SY21-0048-0 and Technical Newsletters SN21-5529 and SN21-5517. Information has been added to support improvements in IBM System/3 Model 12 System Control Program (Program Number 5705-SC1). Changes to text and illustrations are indicated by a vertical line at the left of the change.

This edition applies to the System/3 program versions listed below and to all subsequent versions and modifications until otherwise indicated in new editions or technical newsleters.

Version	Modification	Program Number	Feature Number	Model
15	0	5702-SC1	6033	8, 10
15	0	5703-SC1	6033	4
4	0	5705-SC1	6070, 6071	12


Changes are periodically made to the specifications herein; before using this publication in connection with the operation of IBM systems, refer to the latest IBM System/3 Bibliography, GC20-8080, for the editions that are applicable and current.

Use this publication only for the purposes stated in the Preface.

Publications are not stocked at the address below. Requests for copies of IBM publications and for technical information about the system should be made to your IBM representative or to the branch office serving your locality.

This publication could contain technical inaccuracies or typographical errors. Address your comments about this publication to IBM Corporation, Publications, Department 245, Rochester, Minnesota 55901. Comments become the property of IBM.

© Copyright International Business Machines Corporation 1976, 1978




- Descriptions of data areas
- Descriptions of how to use the diagnostic aids
- Additional references

Note: All displacements herein are relative to zero and are in hexadecimal notation. All lengths are in decimal notation. Field names reference the entire field and do not imply either leftmost or rightmost addressability.

#### **RELATED PUBLICATIONS**

- IBM System/3 Model 4 Operator's Guide, GC21-5149
- IBM System/3 Communications Control Program Programmer's Reference Manual, GC21-7579
- IBM System/3 Models 8, 10, and 12 System Communication Control Program System Reference, GC21-7588
- IBM System/3 Communications Control Program (5702-SC1) Terminal Operator's Guide, GC21-7580
- IBM System/3 Models B, 10, and 12 System Communications Control Program System Operator's Guide, GC21-7581
- IBM System/3 Multiline/Multipoint Binary Synchronous Communications Reference Manual, GC21-7573
- IBM System/3 Multiple Line Terminal Adapter RPO Program Reference and Component Description Manual, GC21-7560
- IBM System/3 Disk Systems Binery Synchronous Communications Programming Support Input/Output Control System Logic, SY21-0526
- IBM System/3 Multiple Line Terminal Adapter RPQ Supporting RPQs S40028-S40033 Program Numbers 5799-WAU (Models 10 and 12) 5799-WEK (Model 15) Program Logic Manual, SY21-0527
- IBM System/3 Models 4, 8, 10, and 12 Communications Control Program Logic Manual, SY21-0531
- IBM System/3 Model 4 Communications Control Program Programmer's Reference Manual, GC21-5150
- IBM System/3 Communication Control Program Messages Manual, GC21-5170
- IBM System/3 Disk Sort Reference Manual, SC21-7522
- IBM System/3 Communications Control Program System Design Guide, GC21-5165



# Contents

	LIST OF ABBREVIATIONS	хi
	SECTION 1. DATA AREAS	1-1
		-3
		-3
		-3
	Transfer Toology I I I I I I I I I I I I I I I I I I I	-3
		-3
	= <del>, .</del>	1-4
_		1-5
		1-7
		1-9
	Contents for \$CGNPE	
	Contents for \$CGNPS	
		15
		17
		17
À	-,	18
		19
		24
	-,	25
		·25 ·27
		27
	Main Storage Table Save Area	
	File Control Table (FCT) Compressed	
	File Control Table (FCT) While Building FCT Entries	
	Line Control Table (LCT) Compressed	
	Program Characteristics Table (PCT) Compressed	
	Terminal Attributes Table (TAT)	
	Terminal Attributes (TAU) Table	
	Terminal Name Table (TNT) Compressed	
	Terminals Used Table (TUT) Compressed	
	\$CCPFILE1	
	Disk Layout of \$CCPFILE	
	Configuration Record	
	Directory	
	File Control Table (FCT)	
	Symbolic File Name Entries Only	
	Physical File Name Entries Only	
	Indexed Files Only	
	Indexed Files with Master Index Only	
	Line Control Table (LCT)	45
	Control Station Lines Only	-47
	Switched BSCA Lines Only (Optional)	47
	Displacements for Each ID to Receive (Optional)	47
	Program Characteristics Table (PCT)	-48
	System Information Table (SIT)	-52
	Terminals Used Table (TUT)	-54
	BSCA Terminals on Control Station or Multipoint Lines	
	Only (Optional)	-56
	MLTA Terminals on Control Station or 1050 Switched	
	Lines Only (Optional)	-56
	Terminal Name Table (TNT), Terminal Unit Block (TUB),	
	Switched Terminal Table (STT)	
	\$CCPLOG FILE (MODEL 4 ONLY)	
	STARTUP DATA AREAS	57

Phase Roller List	-57
Startup Save Area	-58
Scan Control Block Used with \$CCSCN	1-60
Transient Relocation List	1-61
XREF Transient List	1-65
CCP EXECUTION DATA AREAS	1-69
CCP Communication Area (\$CCCOM)	1-69
Addresses of Component Work Areas	1-69
Addresses of System Task Control Blocks (TCBs)	
System Level Flags	
System Constants	
Common Register Save Areas	1-71
Addresses of Disk I/O Intercept Points in	
CCP Dispatcher	
Queue/List Origin Address Pointers	
Addresses of CCP, MLTA, and BSCA Trace Routines	
Buffer Storage Allocation Control Block	
User Program Area Allocation Control Block	
Console Buffer Control Block	
Dispatcher Work Area	
Task Control Block Dynamic Addresses	
General Work Area	
Unit Record Allocation/Usage Bytes	
Password Save Area	
Disk Addresses of DSM Data Management Routines	
User Program Dump Area Information	
Miscellaneous Pointers	
Expansion Area	
Display Formatting Facility Work Area	
Display Format Facility Load Parameter List	
Task Control Block (TCB)	
Task Control Block User Area	
Command Processor Work Area	
Allocation Work Area	
Termination Work Area	
Communication Management Work Area	1-92
Console Management Work Area for	
Models 8, 10, and 12	
Console IOB Work Area (Models 8, 10, and 12)	1-94
Data Fields Passed to the Console Manager to	1 04
Handle Console Requests from \$CC4CM Transients	
Console Input Buffer	
Console Management Work Area for Model 4	
Console Buffer Layout	
File Specification Block (FSB)	
Console IOB for Models 8, 10, and 12	
Console Additional Cells	
Console Status Byte	
Keyboard IOB for Model 4	
Disk IOB	
BSCA Line Control Block (LCB)	
End of DTF	
Second BSCA Only Segment	1-114

BSCA Input/Output Block (IOB)1-115
Receive Buffer
Transmit Buffer
BSCA Work Area
BSCA I/O Area
Organization of BSCA IOBs and Buffers in
BSCA I/O Area
MLTA Adapter DTF
MLTA Line Control Block (LCB)
Device Dependent Section
MLTA Polling List
Parameter Bytes
Poll Entries
End-of-List Bytes
MLTA IOCS IOB
MLTA IOCS Common Area
Contents Directory Entry (CDE)
Statistical Data Recording (SDR) Table
Communications Parameter List
GETMAIN/FREEMAIN Parameter List
Main Storage Control Block (SCB)
Free Segment Control Block
Standard Parameter List
User Record Area
User Record Area for RPG II Output
User Record Area for RPG II Input
RPG II Areas
Sector Queue Block (SQB)
Segment Control Block (SCB)1-159
Short Disk DTF (SDF)
5444/5447 Disk Drive
5445 Disk Drive
Switched Terminal Table (STT)1-163
Symbolic File Table (XDT)
Terminal Attributes Table (TAT)1-164
Terminal Attributes Set (TAS)
Terminal Name Table (TNT)
Terminal Unit Block (TUB)
System Parameter List within TUB
Terminal Identification and Address Characters 1-168
Queue Chain Fields
Data Mode Escape Fields
Current Terminal Attribute Set Fields
Terminal Type Fields

Transients	
Beginning of a CCP transient	į
Relocation Address Table in a CCP Transient	j
DFF DATA AREAS	,
DFGR Common Area	•
PFGR Common Area	,
DFF Field Descriptor Table (FDT)	3
First Entry (Format Physical Attributes)	3
Field Entry (14 Bytes Each: 17 Entries in First	
Sector, 18 in All Other Sectors)	)
DFF Terminal Table (TT)	)
DFF Format Table (FT)	j
DFF Program Appended Storage (PAS) Constants	
and Work Areas	2
Copy Text and Work Area1-183	
EAU Text and Work Area	
DFF Field Classes	ì
INSTALLATION VERIFICATION PROGRAM DISK RECORD 1-187	
Disk Record Created by CCPIVP	,
SECTION 2. DIAGNOSTIC AID	1
MAIN STORAGE DURING CCP EXECUTION	
\$CC4 Load Modules	
Optional Load Modules	
Control Blocks and Data Areas	
Display Format Facility	
EXECUTION TIME CONTROL BLOCKS	
STORAGE ALLOCATION	
INTERRUPT PROCESSING	
DSM INTERCEPT	
SYMBOLIC FILE SUPPORT	
SYMBOLIC FILE ASSOCIATION	
HOW-TO-FIND DIAGRAMS	
How to Find \$CCCOM without Remap 2-1	
How to Find \$CCCOM with Remap (During CCP Execution Only) 2-1	
How to Find the System Task Control Block (TCB)	
How to Find the User Task Control Block (TCB)	
How to Find the User Program Area Boundaries	
How to Find a Particular User Program's Boundaries	3
How to Find User Program Area Available	
Space Boundaries	4
How to Find a User Program Module by Active	
Task Control Block	+
How to Find a User Program Module by Contents	
Directory Entry	4
How to Find a User Task's Last Teleprocessing	_
I/O Request	
How to Find Terminal Unit Blocks by Terminal ID	
How to Find Terminal Unit Blocks by Symbolic Terminal Name 2-19	
How to Find the Communications Buffer Area	
How to Find the Last Communications Parameter List	
now to rind the releprocessing DTFs (WLTA/DOCA/	•

How to Find the Teleprocessing Line Buffers
How to Find Disk DTFs
Symbolic-Actual DTF References
How to Find the Teleprocessing Line Queue
How to Find the Invite Input Hold Buffer for a
Teleprocessing Line
How to Find the Console Buffer
How to Find the Console Output Queue
How to Find the Console Input Queue
How to Find Terminal Attribute Sets in the Terminal
Attribute Table
How to Find the TUBs (Terminals) Owned by a Task
How to Determine the Terminal Operator's/FILE
Specifications
How to Find Main Storage Management Allocated Storage
Boundaries and Free Storage Chains
How to Find Teleprocessing Buffer Location and Lengths
How to Find the CCP Trace Tables
How to Find the MLTA Trace
How to Find the BSCA Trace
TRACES
CCP Trace
Type 01 — Dispatcher Initial Entry
Type 02 — Dispatcher NCEIOS Intercept
Type 03 — Dispatcher NCEIOW Intercept
Type 04 — NCEIOW Entry from Dispatcher
Type 05 — General Entry Intercept
Type 06 - Transient Request
Type 07 - Entry to Post (\$CC4PS)
Type 08 - Entry to GETMAIN (\$CC4GM)
Type 09 — Entry to FREEMAIN (\$CC4FM)
Type 0A - \$CC4CM Return from IOCS after CHECK
on Op End
Type 0B/1B — \$CC4CM Return from IOCS after START I/O 2-36
Type 0C — \$CC4II Entry to User I/O Interface
Type 0D – \$CC4IS Entry to System I/O Interface
Type 0E — \$CC4II Return to User
BSCA Trace
MLTA Trace
MLTA Trace F0 SIO
MLTA Trace F1
MLTA Trace F2
MLTA Trace F3 Op Complete
Trace Halt \$CC\$SA
Dump Program
How to Use \$CCPDD
Using the Standalone Dump Program (Models 8, 10,
and 12 Only)
REP Statement Processor
How to Write a Service Aid Program
CCP HALTS

Program Termination Codes
Operation Codes
Operation Symbols
Operation Modifier Symbols
Return Codes
BSCA Control Characters and Codes
EBCDIC
ASCII
Control Characters
How to Determine the Write Control Character (WCC) 2-74
Startup Specifications
Console Operator Commands
Additional Console Operator Facilities for Model 4 2-80
Field Lights for Model 4
Terminal Operator Commands
MLTERFIL
BSCA SDR/OBR
INDEX X-1

Ì

#### List of Abbreviations

Addr A main storage address

AID Attention ID ΔМ

Allocation manager API Applied program language

Arithmetic variable Arith ARR Address recall register

American National Standard Code for Information Interchange ASCII

ATR Address translation register

Bin Binary number

Bool Binary (Boolean) variable

BSCA Binary synchronous communications adapter

CDF Contents directory entry

C/H Disk address (cylinder/head)

C/H/R Disk address (cylinder/head/record)

C/H/R/D Disk address (cylinder/head/record/displacement)

C/S Disk address (cylinder/sector)

C/S/D Disk address (cylinder/sector/byte displacement within sector) C/S/D/D

Disk address (cylinder/sector/byte displacement from the

beginning of that sector)

C/S/N Disk address and length (cylinder/sector/number of sectors)

Current address buffer

calcs Calculations

CAB

CAM Compiler access method CAR Current address register

CCP Communications control program

CCPIVP CCP installation verification program

Char Alphameric characters

Charn Character variable СМ Communications manager

CMD Command

СМТ Console management task

COMARA Communications area COMMON Common area

CP Command processor CPU Central processing unit

CRT Cathode-ray tube

DC Define constant

Dec Zoned decimal characters

DECR Display format control routine

DFGR Display format generator routine DFF Display format facility

DFT Display format table

Disp Displacement DME Data mode escape

DPF Dual program feature DSM Disk system management

DTF Define the file DTT Define the table EAU Erase all unprotected

Extended binary-coded decimal interchange code **EBCDIC** 

End of job EOJ

EOT End of transmission EPL External pointer list Error recovery procedure ERP

External symbol list ESL

FCT File control table Field descriptor table FDT

File share area **FSA ESB** 

File specification block

FΤ Format table

High density buffer HDB HPL. Halt program level

Instruction address register IAR

ID Identification IFT Input format table 1/0 Input/output Inst Instruction IOB Input/output block

Input/output control system LOCS IOS Input/output supervisor IPI Initial program load Intermediate text block ITR

LCB Line control block Line control table LCT

Length Lng

MDT Modified data tag

MFCM Multifunction card machine MECU Multifunction card unit MLMP Multiline/multipoint MLTA Multiple line terminal adapter Multiple requesting terminal MRT

NEP Never-ending program

OBR Outboard recorder OCL Operation control language OHA Output hold area

OLE Overlay linkage editor Online test

parm Parameter

PAS Program appended storage Program check interrupt PCI PCSR Program check status register

PCT Program control table or program characteristics table

Program Information Department PID **PLCA** Program level communication area

PMR Program mode register PSR Program status register **PTAM** Pseudo tape access method

Perforated tape and transmission code/extended binary-coded PTTC/EBCD

decimal

OLT

	_	
ı	RB	Request block
1	REQ	Request
1	RIB	Request indicator byte
١	RJE	Remote job entry
١	RLD	Relocation list dictionary
Į	k∨ı	Reverse interrupt
-	SAR	Stop address register
١	SCA	System communication area
-1	SCB	Segment control block
١	SCP	System control program
ı	SDF	Short disk DTF
Λ	SDR	Statistical data recording
I	SIO	Start input/output
/	SIT	System information table
П	SPD	Selector pen detectable
- 1	SQB	Sector enqueue block
-	SRT	Single requesting terminal
	STT	Switched terminal table
	svc	Supervisor call
	SWA	Scheduler work area
	SYSBFR	Control statement input buffer
	SYSCOM	System communication region
	SYSLOG	System log routine
	TAB	Transition address buffer
	TAR	Transition address register
	TAS	Terminal attributes set
	TAT	Terminal attributes table
	TAU	Terminal attributes use
1	тсв	Task control block
ľ	ТМ	Termination management
١	TNT	Terminal name table
١	TP	Teleprocessing
1	TT	Terminal table
	TUB	Terminal unit block
	TUT	Terminals used table
	PA	User program area
	UPSI	User program switch indicator
	<b>утос</b>	Volume table of contents
	wac	Write control character
	wyb	Write to operator
	wfor	Write to operator with reply
	CTL	Transfer control
	<b>X</b> DT	Symbolic file table
,	XREF	Cross-reference
	XR1	Index register 1
	XR2	Index register 2

This section describes data areas used by CCP routines. Data areas used by CCP routines but not unique to CCP (for example, disk DTFs or telecommunications polling lists) are not described here; their descriptions can be found in the logic manual of the appropriate DSM component program.

The CCP data areas are described in eight groups:

- 1. SCP generator data areas
- 2. Assignment build local data areas
- \$\$CCPFILE
- 4, \$CCPLOG File (Model 4 only)
- Startup data areas
  - 6 CCP execution data areas
- DFF data areas
- 8. Installation verification program disk record

CCP data areas are described in tables (arranged in alphabetic sequence with in each group) containing the following information about each field:

- Disp Hex—The displacement of the field from the beginning of the data area, given in hex. If the field consists of more than one byte, the displacements of the first byte and the last bytes are indicated. When a byte is used more than once within the same area, the second and subsequent entries for the byte are shown in parenthesis.
- Label—The name of the field as it is referred to by CCP routines.
- Lng Dec-The number of bytes in the field, given in decimal.

Description

Code

Form—The form of data contained in the field. The codes used are:

0000	Description
Addr	A main storage address
Bin	Binary number
Bits	A collection of bits, each of which has individual significance
C/H	Disk address (cylinder/head)
Char	Alphameric characters
C/H/R	Disk address (cylinder/head/record)
C/H/R/D	Disk address (cylinder/head/record/displacement)
C/S	Disk address (cylinder/sector)
C/S/D	Disk address (cylinder/sector/byte displacement within sector)
C/S/D/D	Disk address (cylinder/sector/byte displacement from the begin ning of that sector)
C/S/N	Disk address and length (cylinder/sector/number of sectors)
Dec	Zoned decimal characters
Disp	A binary number representing a displacement within main storage
Inst	Instruction
Mix	More than one of the above forms in the same field

- Description—The content of the field and the meaning of the information in the field. When the Form of the field is bit, the following information is also given:
  - Hex Value—The hex value indicates when a bit is on. More than one significant bit can be on (multiple meanings for the byte).
  - Symbol-The name of the bit if applicable.
  - Meaning-The meaning of the bit when it is on.

### SCP Generator Data Areas

### COMMUNICATIONS AREA (COMARA)

- COMARA is part of \$CGNIN.
- This area contains the transfer vector and an address table for all other tables in \$CGNIN.

Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description
00-05		6	Bin	Current phase name
06-07		2	Bin	Displacement from COMARA to COM- MON. If a register points to COMARA, adding this constant to its contents causes the result to point to COMMON
Transfer	Vector			
08-0B		4	Addr	Transfer to disk data management
0C-0F		4	Addr	Transfer to printer data management
Address 1	Table			
10-11		2	Addr	Disk data management transfer address
12-13		2	Addr	Printer data management transfer address
14-15		2	Addr	Printer DTF address
16-17		2	Addr	Header area start address
DTFs and	d IOBs			
18-48		49	Bin	Object file (\$WORK) DTF
49-5E		22	Bin	Object file (\$WORK) IOB
5F-8F		49	Bin	Source file (\$SOURCE) DTF
90-A5		22	Bin	Source file (\$SOURCE) IOB
A6-D6		49	Bin	Work file (\$WORK2) DTF
D7-EC		22	Bin	Work file (\$WORK2) IOB

 $<sup>^{1}\,\</sup>mathrm{All}$  labels address the high-storage (rightmost) byte of the field.

#### COMMON AREA (COMMON)

- COMMON is part of \$CGNIN.
- This area is used for interphase constants, working storage, and communication among phases.

The following chart shows which fields in COMMON are used by more than one phase of the SCP generator. Only data fields used by more than one phase are shown. Fields that are merely initialized for the next phase are not included. A bullet (•) is used to indicate the phase in which a data field is initialized, used in, or terminated.

Phese Field	\$CGNIN	\$CGNCM	\$CGNSB	\$CGNSF	\$CGN\$S	\$CGNPE	\$CGNP\$	\$CGNBX	\$CGNSX
OPTIONS BGNCOL ENDCOL SEQCNT	:	:	•	•	•	•	:	•	
MODULE		•			•	•			
TITLEN ESLCNT INTLCR MAXLCR SYMOVS		:	:	•	:	:			
NSTENT MAXSTE SYTBSA SYTBEA SYMCNT				:	:				
ESLTBA PAGCNT LPSIZE LPCLSW SQFDST					•	:	:		•
SQFDLG MNESCT ERRCNT XRPASR XRFRST						•	:	:	:
XRLAST XRBLKC								:	:

Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description			
Contents for \$CGNIN and \$CGNCM							
00-01	CMCADP	2	Disp	Displacement to COMARA			
02-03	10	2	Bin	Binary 0 constant			
04-05	11	2	Bin	Binary 1 constant			
06-07	12	2	Bin	Binary 2 constant			
08	OPTONS	1	Bin	Processor options			
09-0A	SEQCNT	2	Bin	Count of sequence errors in the source file (\$SOUCRE)			
OB-13	INTRCD	10	Bin	Disk data management work area			
14-15	BGNCOL	2	Bin	Source record begin column			
16	_	1	-	Reserved			
17-1C	MODULE	6	Char	Module name			
1D-22	TITLEN	6	Char	Title name			
23	ESLCNT	1	Bin	Count of ESL records			
24	CATGVL	1	Bin	Module category level			
25-26	COML4V	2	Bin	EXTRN subtype 4 common length			
27-28	COML5V	2	Bin	EXTRN subtype 5 common length			
29-2A	NAMLNG	2	Bin	Length of name field			
28-2C	OPTCOL	2	Bin	Rightmost column number of operation code			
2D-2E	OPTLNG	2	Bin	Operation code length			
2F-30	OPDCOL	2	Bin	Leftmost column number of operation field			

 $<sup>^{1}\,\</sup>mathrm{All}$  labels address the high-storage (rightmost) byte of the field.

2 Bin

31-32 OPDLNG

Operand field length

Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description
33-34	OPDEND	2	Bin	Rightmost column number of operand field
35-36	PRECOL	2	Bin	Points to current source column
37-39	OPFTEN	3	Addr	End of operand format table
3A	NOFOPD	1	Bin	Number of operands
3B-46	EPOSEN	12	Bin	Operand element position table
47	NOFELE	1	Bin	Number of elements in operand
48-51	INTEND	10	Bin	Control record build area
52-5B	NAMEND	10	Bin	Name record build area
5C- <b>6</b> 5	TRMEND	10	Bin	Term record build area
66-6F	ERREND	10	Bin	Error record build area
70-D0	SOURFD	97	Char	Source record input area
D1-D8	LASTSQ	8	Char	Last source sequence field
D9	CTLSWS	1	Bin	Control switches
DA-DB	AAWORK	2	Bin	Work area A
DC-DD	ABWORK	2	Bin	Work area B
DE-DF	ACWORK	2	Bin	Work area C
E0	PACI	1	Bin	Pseudo accumilator switches
E1-E4	PAC	4	Bin	Pseudo accumulator 1
E5-E8	TPAC	4	Bin	Pseudo accumulator 2
E9	SWTCH1	1	Bin	Temporary bit switches
EA-EB	13	2	Bin	Binary constant 3
EC	EXTCNT	1	Bin	EXTRN count

<sup>&</sup>lt;sup>1</sup>All labels address the high-storage (rightmost) byte of the field.

Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description
ED-EE	ON	2	Char	Print keyword
EF-F1	OFF	3	Char	Print keyword
F2-F5	DATA	4	Char	Print keyword
F6-FB	NODATA	6	Char	Print keyword
FC-FD	ENDCOL	2	Bin	Source record end column
Contents	for \$CGNSB	and \$0	GNSF	
00-01	CMCADP	2	Disp	Displacement to COMARA
02-03	10	2	Bin	Binary 0 constant
04-05	11	2	Bin	Binary 1 constant
06-07	12	2	Bin	Binary 2 constant
08	OPTONS	1	Bin	Processor options
09-0A	SEQCNT	2	Bin	Count of sequence errors in the source file (\$SOURCE)
0B-13	INTRCD	10	Bin	Disk data management work area
14-15	BGNCOL	2	Bin	Source record begin column
16	-	1	-	Reserved
17-1C	MODULE	6	Char	Module name
1D-22	TITLEN	6	Char	Title name
23	ESLCNT	1	Bin	Count of ESL records
24	CATGVL	1	Bin	Module category level
25-26	COML4V	2	Bin	EXTRN subtype 4 common length
27-28	COML5V	2	Bin	EXTRN subtype 5 common length
29-2C	LOCNTR	3	Bin	Current location counter value
2D-2F	LCRCHG	3	Bin	Location counter increment

 $<sup>^{1}</sup>$ All labels address the high-storage (rightmost) byte of the field.

Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description
30	LOCRSW	1	Bin	Location counter switch
31	SYMOVS	1	Bin	Symbol table overflow switches
32-33	NSTENT	2	Bin	Number of table entries
34-35	MAXSTE	2	Bin	Maximum number of entries
36-37	SYTBSA	2	Addr	Symbol table start address
38-39	SYTBEA	2	Addr	Symbol table end address
3A-3B	SYMENT	2	Bin	Current symbol count
3C	SYMIND	1	Bin	Symbol table indicators
3D-46	SYMEND	10	Bin	Symbol entry build/search area
47-50	INTEND	10	Bin	Control record save area
51-5A	TRMEND	10	Bin	Term record save area
5B-64	ERREND	10	Bin	Error record build area
65-66	AAWORK	2	Bin	Work area A
67-68	ABWORK	2	Bin	Work area B
69-6A	ACWORK	2	Bin	Work area C
6B	PACI	1	Bin	Pseudo accumulator switches
6C-6F	PAC	4	Bin	Pseudo accumulator 1
70-73	TPAC	4	Bin	Pseudo accumulator 2
74-76	INTLCR	3	Bin	Initial location counter
77-79	MAXLCR	3	Bin	Maximum location counter
7A-A5	EXPVTB	44	Bin	Expression evaluation tables
A6-B3	EXPWRK	14	Bin	Expression evaluation work area
B4-B7	MWORK	4	Bin	Multiplication work area
B8-BD	SYMSAV	6	Bin	Symbol save area

<sup>&</sup>lt;sup>1</sup> All labels address the high-storage (rightmost) byte of the field.

_	Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description
	Contents	for \$CGNSS			
	00-01	CMCADP	2	Disp	Displacement to COMARA
	02-03	10	2	Bin	Binary 0 constant
	04-05	11	2	Bin	Binary 1 constant
)	06-07	12	2	Bin	Binary 2 constant
	08	OPTONS	1	Bin	Processor options
	09-0A	SEQCNT	2	Bin	Count of sequence errors in the source file (\$SOURCE)
)	0B-13	INTRCD	10	Bin	Disk data management work area
	14-15	BGNCOL	2	Bin	Source record begin column
	16	· <del>-</del>	1	-	Reserved
	17-1C	MODULE	6	Char	Module name
	1D-22	TITLEN	6	Char	Title name
	23	ESLCNT	1	Bin	Count of ESL records
	24	CATGVL	1	Bin	Module category level
	25-26	COML4V	2	Bin	EXTRN subtype 4 common length
	27-28	COML5V	2	Bin	EXTRN subtype 5 common length
)	29-2C	LOCNTR	3	Bin	Current location counter value
,	2D-2F	LCRCHG	3	Bin	Location counter increment
	30	LOCRSW	1	Bin	Location counter switch
	31	SYMOVS	1	Bin	Symbol table overflow switches
)	32-33	NSTENT	2	Bin	Number of table entries
	34-25	MAXSTE	2	Bin	Maximum number of entries
	36-37	SYTBSA	2	Addr	Symbol table start address
	38-39	SYTBEA	2	Addr	Symbol table end address
•	<sup>1</sup> All lab	els address the	e high-s	storage (rig	phtmost) byte of the field.

Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description
3A-3B	SYMONT	2	Bin	Current symbol count
3C	SYMIND	1	Bin	Symbol table indicators
3D-46	SYMEND	10	Bin	Symbol entry build/search area
47-50	INTEND	10	Bin	Control record save area
51-5A	TRMEND	10	Bin	Term record save area
5B-64	ERREND	10	Bin	Error record build area
65-66	AAWPRL	2	Bin	Work area A
67-68	ABWORK	2	Bin	Work area B
69-6A	ACWORK	2	Bin	Work area C
6B	PACI	1	Bin	Pseudo accumulator switches
6C-6F	PAC	4	Bin	Pseudo accumulator 1
70-73	TPAC	4	Bin	Pseudo accumulator 2
74-76	INTLCR	3	Bin	Initial location counter
77-79	MAXLCR	3	Bin	Maximum location counter
7A-7B	ESLINC	2	Bin	ESL record length constant
7C-7D	ESLPTR	2	Addr	Pointer to ESL table
7E-89	ESLREC	12	Bin	ESL record build area
Contents	for \$CGNPE			
00-01	CMCADP	2	Disp	Displacement to COMARA
02-03	10	2	Bin	Binary 0 constants
04-05	11	2	Bin	Binary 1 constant
06-07	12	2	Bin	Binary 2 constant
08	OPTONS	1	Bin	Processor options

<sup>&</sup>lt;sup>1</sup> All labels address the high-storage (rightmost) byte of the field.

Disp Hex	Label <sup>l</sup>	Lng Dec	Form	Description
09-0A	SEQCNT	2	Bin	Count of sequence errors in the source file (\$SOURCE)
0B-13	INTRCD	10	Bin	Disk data management work area
14-15	BGNCOL	2	Bin	Source record begin column
16	_	1	_	Reserved
17-1C	MODULE	6	Char	Module name
1D-22	TITLEN	6	Char	Title name
23	ESLCNT	1	Bin	Count of ESL records
24-25	ESLINC	2	Bin	ESL record increment
26-27	_	2	_	Reserved
28-29	ESLTBA	2	Addr	Address of ESL table
2A-35	ESLREC	12	Bin	ESL record save area
36-37	_	2	-	Reserved
38-39	AAWORK	2	Bin	Work area A
3A-3B	ABWORK	2	Bin	Work area B
3C-3D	ACWORK	2	Bin	Work area C
3E	PACI	1	Bin	Pseudo accumulator switches
3F-42	PAC	4	Bin	Pseudo accumulator 1
43-44	TPAC	4	Bin	Pseudo accumulator 2
Contents	for \$CGNPS			
00-01	CMCADP	2	Disp	Displacement to COMARA
02-03	10	2	Bin	Binary 0 constant
04-05	11	2	Bin	Binary 1 constant
06-07	12	2	Bin	Binary 2 constant

<sup>&</sup>lt;sup>1</sup> All labels address the high-storage (rightmost) byte of the field.

Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description
08	OPTONS	1,	Bin	Processor options
09-0A	SECCNT	2	Bin	Count of sequence errors in the source file (\$SQURCE)
0B-13	INTRCD	10	Bin	Disk data management work area
14-15	BGNCOL	2	Bin	Source record begin column
16-17	ERRONT	2	Ŗin	Count of source statements in error
18	PAGENT	1	Bin	Printer page size
19	LINCNT	1	Bin	Printer line count
1,A	LPSIZE	1	Bin	Printer column size
1B	LPCLSW	1	Bin	Print size switches
1C-25	INTEND	10	Bin	Control record area
26-30	ERREND	11	Bin	Error record area
31	PRNTSW	1	Bin	Print control switches
32	USWTCH	1	Bin	Temporary bit switches
33-34	LDADDR	2	Addr	Object code load address
35-37	DCWORK	3	Bin	DC work area
38-39	AAWORK	2	Bin	Work area A
3A-3B	ABWORK	2	Bin	Work area B
3C-3D	ACWORK	2	Bin	Work area C
3E	PACI	1	Bin	Pseudo accumulator switches
3F-42	PAC	4	Bin	Pseudo accumulator 1
43-46	TPAC	4	Bin	Pseudo accumulator 2
47	RELIND	1.	Bin	Relocation and EXTRN switches
48-4F	OBJECT	8	Bin	Object code assembly area

<sup>&</sup>lt;sup>1</sup>All labels address the high-storage (rightmost) byte of the field.

Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description
50-51	VALUE1	2	Bin	Base value for register 1
52-53	VALUE2	2	Bin	Base value for register 2
54-63	HEXOBJ	16	Mix	Hex object conversion area
64-8F	EXPVTB	44	Mix	Expression evaluation tables
90-93	MWORK	4	Bin	Multiplication work area
94-95	OBDADF	2	Bin	Duplication factor for DC code
96-97	OBDAAD	2	Addr	Address of DC code
98-99	OBDLTH	2	Bin	Object code length
9A-9B	MOVELH	2	Bin	Object code move length
9C	RELDSP	1	Bin	RLD value
9D-9E	BYTAVL	2	Bin	Bytes left on object record
9F	_	1	-	Reserved
A0	FX96LN	1	Bin	Fold column for 96-column printer
A1	F120LN	1,	Bin	Fold column for 120-column printer
A2	DCZERO	1	Char	Decimal 0
A3-A5	SEQALP	3	Bin	Sequence error code
A6	OPCDNO	1	Bin	Operation code error constant
Α7	OPNDNO	1	Bin	Operand error constant
A8-A9	18	2	Bin	Binary 8
AA-AB	MINUS8	2	Bin	Binary -8
AC-AD	116	2	Bin	Binary 16
AE	157	1	Bin	Binary 57
AF-B0	1256	2	Bin	Binary 256

All labels address the high-storage (rightmost) byte of the field.

Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description
B1-B2	QCDMAX	2	Bin	Maximum MVX instruction queue code value
B3-B4	JPDEC3	2	Bin	Jump instruction length
B5-B6	HEXSAD	2	Addr	Start address of hex conversion
B7-B8	HEXEAD	2	Addr	End address of hex conversion
В9	D1	1	Char	Decimal 1
BA-BB	TXTTXA	2	Addr	Object text address
BC-BD	TDTRLA	2	Addr	Object RLD field address
BE-BF	ASEMAD	2	Addr	Assembly area address
C0-C1	SOURAD	2	Addr	Address of source start
C2-C3	OBOADR	2	Addr	Object output area address
C4-C5	SRCADR	2	Addr	Source input area address
C6-C9	STMTNO	4	Bin	Source statement number
CA-CB	MINUS1	2	Bin	Binary -1
CC-CD	NAMEXN	2	Bin	EXTRN number
CE-CF	OPADEC	2	Bin	Output area decrement
D0-D1	OBJDEC	2	Bin	Input area decrement
D2-D3	PRTOAD	2	Addr	Print area start address
D4-D5	PRTOCA	2	Addr	Print object field address
D6-D7	ASEMSA	2	Addr	Assembly area start address
D8-D9	HEADRA	2	Addr	Header area address
DA-DC	ERRFLG	3	Bin	Error flag

All labels address the high-storage (rightmost) byte of the field.

Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description
Contents	for \$CGNBX	and \$C	GNSX	
00-01	CMCADP	2	Disp	Displacement to COMARA
02-03	10	2	Bin	Binary 0 constant
04-05	11	2	Bin	Binary 1 constant
06-07	12	2	Bin	Binary 2 constant
08	OPTONS	1	Bin	Processor options
09-0A	SEQCNT	2	Bin	Count of sequence errors in the source file (\$SOURCE)
0B-13	INTRCD	10	Bin	Disk data management work area
14-15	BGNCOL	2	Bin	Source record begin column
16-17	ERRCNT	2	Bin	Count of source statements in error
18	PAGCNT	1	Bin	Printer page size
19	LINCNT	1	Bin	Printer line count
1A	LPSIZE	1	Bin	Printer column size
1B	LPCLSW	1	Bin	Print size switches
1C-27	XRTAB	12	Bin	Merge string table A (see \$CGNBX or \$CGNSX listing, COMMON Subfields and Values Definitions, for details)
28-33	XRBTAB	12	Bin	Merge string table B (see \$CGNBX or \$CGNSX listing, COMMON Subfields and Values Definitions, for details)
34-3B	XRAVLT	8	Bin	Cross-reference file availability table
3C-3D	XRPASR	2	Bin	Merge passes to last pass
3E-3F	XRPASC	2	Bin	Current pass count
40-41	XRFRST	2	C/S	Address of first XREF block
42-43	XRLAST	2	C/S	Address of last XREF block

 $<sup>^{1}\,\</sup>mathrm{All}$  labels address the high-storage (rightmost) byte of the field.

				1
Disp Hex	Label <sup>1</sup>	Lng Dec	Form	Description
44-45	XRBSST	2	Bin	Block string length in sectors
48-49	XRRCSZ	2	Bin	Blocks in XREF file
4A-57	XRCTAB	14	Bin	XREF file output block table (see \$CGNBX listing, COMMON Subfields and Values Definitions, for details)
58-B7	XRPIME	96	Char	Print image area
B8	XRREFC	1	Bin	Reference count
B9-BA	XRREFP	2	Bin	Reference pointer
BB-BC	XRRFPS	2	Bin	Start reference pointer
BD	XRRDSW	1	Bin	String switch A/B
BE-C3	XRSYMS	6	Char	Current symbol save area
C4-C5	XRKYLC	2	Bin	Length of sort key minus 1
C6-C7	XRNKRL	2	Bin	Length of record not in key
C8-C9	AAWORK	2	Bin	Work area A
CA-CB	ABWORK	2	Bin	Work area B
CC-CD	ACWORK	2	Bin	Work area C
CE	PACI	1	Bin	Pseudo accumulator switches
CD-D2	PAC	4	Bin	Pseudo accumulator 1
D3-D6	TPAC	4	Bin	Pseudo accumulator 2

 $<sup>^{1}\,\</sup>mathrm{All}$  labels address the high-storage (rightmost) byte of the field.

#### PRINTER COMMUNICATIONS AREA

- The printer communications area is loaded with \$CGNPE.
- This area remains in main storage through the end of SCP generator execution.
- The area consists of the following:
  - Printer DTF
  - Printer buffer
  - Header area

#### SYMBOL TABLE

- The symbol table is built in the lower end of main stoage by \$CGNSB.
- The table consists of 10-byte entries, one for each symbol found.
- The table is used by \$CGNSF (if overflow occurs) and \$CGNSS.
- The table is designed to fill the entire space between the code and the work file disk buffer as shown in the following storage layout:
  - Communications area (COMARA)
  - Common area (COMMON)
  - Disk data management
  - \$CGNSB code
  - Symbol table
  - Disk buffers

Following is the breakdown for each 10-byte entry in the symbol table:

Disp Hex	Label	Lng Dec	Form	Description Symbol attributes:			
00	SYMATR	1	Bit				
				Hex Value	Symbol	Meaning	
				30	EXTIND	Indicates an EXTRN symbol	
				02	SYMRES	Indicates symbol is resolved	
				01	ABSIND	Indicates an abso- lute attribute	
				00	RELIND	Indicates a relocat- able attribute	
01-06	SYMBOL	6	Char	The syn	nbol padded	with blanks	
07	SYMLNG	1	Bin	Length attribute of symbol minus 1			
08-09	SYMVAL	2	Bin	Symbol value			


### WORK FILE (\$WORK2)

- \$WORK2 is used by the SCP generator for intermediate storage (on a disk storage drive) throughout execution (see Work File Activity, following).
- The file contains three types of data: intermediate text, symbol table entries, and cross-reference data
- The cross-reference data is written into the same area as the intermediate text and symbol table, and imposes no additional space requirements (see Work File Format, following).

# Work File Activity

Phase	Function	Data Activity
\$CGNIN	Initialize	None
\$CGNCM	Compression	Put intermediate text
\$CGNSB	Build symbol table; assign location counter	Update with location counter value and error records
\$CGNSF	Process overflow symbol table	Update symbolic terms Add symbol table entries Update symbolic term
\$CGNSS	Substitute symbols	Update symbolic term Add symbol table entries
\$CGNPE	ESL processing; initialize	Prime buffer
\$CGNPS	Generate object code	Get intermediate text
\$CGNBX	XREF build	Get intermediate text Write XREF blocks
\$CGNSX	XREF merge	Read XREF blocks Write XREF blocks

#### Work File Format



#### Intermediate Text Data

This data is used by the processor for translation from the source assembler language to either a relocatable or an absolute object module. The source code is translated to object code during a series of passes. At any point, the intermediate text contains the object program information at its current level of translation.

The intermediate text data is made up of variable length strings of fixed length (10-byte) records. There are four types of records in the file:

- Control Records—one produced for each instruction in the program.
   Delimits the variable length string.
- Name Records—one produced for each name field entry and for all EXTRN names.
- Term Records—produced from the contents of the operand field. Contain expression terms, constants, and miscellaneous information.
- Error Records—contain error indicators.

The size of a string for a source statement is dependent on the statement type and the contents of the operand field. The following rules can be used to determine intermediate text requirements. (The rules apply only to error free source programs. A statement that contains errors generally requires less storage space.)

- 1. All Instructions:
  - a. One record for each machine or assembler instruction or comment statement in the program.
  - b. One record if there is a name field entry.
- Machine Instructions—one additional record for each term in the operand field.
- 3. Assembler Instructions:
  - END, ENTRY, EQU, EXTRN, ORG, USING—one additional record for each term in the operand field.
  - EXTRN, ISEQ, PRINT, SPACE, START—one additional record for each instruction.
  - TITLE—additional records = N/8 (plus one for any nonzero remainder), where N is the number of characters in the title operand field.
  - d. DS/DC:
    - One additional record for duplication factor (default or specified value).
    - 2) One additional record for each term in the length specification.
  - e. DC:
    - 1) Address constant—one record for each term in address expression.
    - All other constants—additional records = N/8 (plus one for any nonzero remainder), where N is the number of bytes required to contain the converted constant plus one.

# WORK FILE (\$WORK2) (Continued)

Lng

Dec

Form

Following is a sample list of instructions together with the intermediate text space requirements for each:

Instruction	Text Space
START 0	3
SLC A(2),A MVC A(2),CON1 ALC A(2),CON2 HPL X'FF',X'FF'	5 4 4 3
DS CL2	4
DC 1L2'500'	5
DC 1L2'320'	5
END ENTRY	2
	START 0  SLC A(2),A  MVC A(2),CON1  ALC A(2),CON2  HPL X'FF',X'FF'  DS CL2  DC IL2'500'  DC IL2'320'

Description

Control Record				
00	1	Bit	Record type and in	dicators:
			Hex	
			Value Symbol	Meaning
			20	Sequence error on this statement
			10	Symbol table overflow
			08	Last text record
			04	Missing end state- ment (last text record only)
			02	Module name missing (last text record only)
			01	Name record follows
01	1	-	Reserved	
02	1	Bin	Object code length for machine instructions	
03	1	Bin	Operation code (machine instruction	

Disp

Hex

Label

# WORK FILE (\$WORK2) (Continued)

Disp	<b>.</b>	Lng	<b>.</b>	December 1		
Hex	Form	Dec	Form	Description		
04		1	Bin	Q-code (machine code for machine instructions)		
05		1	Bit	Operand format:		
				Hex		
				Value Symbol	Meaning	
					Operand 1:	
				E0	A(L,R)	
				C0	A(L)	
				A0	A(,R)	
				80	Α	
					Operand 2:	
				0E	,A(L,R)	
				0C	,A(L)	
				0A	,A(,R)	
				01	,Α	
06-07		2	Bin	Location counter value assigned before this instruction		
08-09		2	Bin	Statement number of this instruction		
Name F	Record					
00		1	Bit	Record type and indicator:		
				Hex		
				Value Symbol	Meaning	
				44	Symbol defined more than once	
				40	Symbol defined only once	
01-06		6	Char	The symbol padded with blanks		
07-08		2	Bin	Statement number where the symbol is defined		
09		1	Bin	EXTRN number for otherwise zero	or external symbol,	

# WORK FILE (\$WORK2) (Continued)

Disp Hex	Label	Lng Dec	Form	Descripti	on		
Term Rec	ord						(
00		1	Bit	Record type and term attributes:			
				Hex Value	Symbol	Meaning	
				B0 A0		EXTERN symbol Multiplication operation	(
				90		Subtraction operation	
				80 08		Addition operation Operation could be changed by exe- cution (machine instruction)	(
				04		Last term in an expression	
				02		Symbolic term resolved	

01

Absolute term

Disp Hex	Label	Lng Dec	Form	Descript	ion	
01-09		9	Mix		tents of the s follows:	ese bytes are deter-
				If byte	01 contains	:
				Hex Value	Meaning	
				3F	Bytes 02 neous us the lengt	self-defining term06 have miscella- es. Byte 07 contains th attribute (0). Bytes intain the term value.
					are creat	owing special terms ed with a self- term indicator:
					DC/DS	First term record contains constant type in byte 04 and the dup lication factor in byte 09.
					SPACE	Space operand value in byte 09.
					PRINT	Current print control settings in byte 07:
						Hex Value Meaning
						08 DATA; otherwise NODATA
						04 ON; other- wise OFF 02 GEN; other-
						wise NOGEN
					ISEQ	Sequence ISEQ specification. Bytes 06-07 contain the sequence field length minus 1. Bytes 08-09 contain the sequence field start column.

Disp Hex	Label	Lng Dec	Form	Description
Error Re	ecord			
00		1	Bit	Record type:
				Hex Value Symbol Meaning
				CO Error record type
01		1	Bin	Name field error indicator bits
02		1	Bin	Operation field error indicator bits
03-05		3	Bin	Operand field error indicator bits
06-09		4	_	Reserved


### Symbol Table Entries

- Symbol table entries are added to the work file after the intermediate text only if a cross-reference listing is requested.
- Each symbol table entry is 10 bytes long.

Disp Hex	Label	Lng Dec	Form	Descripti	on	
00	SYMATR	1	Bit	Symbol a	attributes:	
				Hex Value	Symbol	Meaning
				80	EXTDEF	EXTRN defini- tion symbol
				30	EXTIND	EXTRN symbol
				02	SYMRES	Symbol resolved
				01	ABSIND	An absolute attribute
				00	RELIND	A relocatable attribute
01-06	SYMBOL	6	Char	The sym	bol padded	with blanks
07	SYMLNG	1	Bin	Length a	ttribute of s	symbol
08-09	SYMVAL	2	Bin	Symbol	value	

### Cross-Reference Data





Disp Hex	Label	Lng Dec	Form	Descrip	tion	
Symbol	Attribute R	ecord (T	ranslated :	Symbol Ta	ble Entry)	
00-05		6	Char	The syn	nbol padded	with blanks
06		1	Bit	Type ar	nd symbol att	tributes:
				Hex		
				Value	Symbol	Meaning
				80	EXTDEF	EXTRN defir
				30	EXTIND	EXTRN symt
				02	SYMRES	•
				01	ABSIND	An absolute attribute
				00	RELIND	A relocatable attribute
07		1	Bin	Length	attribute	
08-09		2	Bin	Symbol	value	
Symbol	Definition F	Record (	Translated	Name Red	cord)	
00-05		6	Char	The syn	nbol padded	with blanks
06		1	Bit	Type:		
				Hex Value	Symbol	Meaning
				40		A symbol det tion record
07-08		2	Bin	Stateme defined		vhere the symb

Disp Hex	Label	Lng Dec	Form	Description
Symbol	Reference Red	cord (T	ranslated :	Term Record)
00-05		6	Char	The symbol padded with blanks
06		1	Bit	Type:
				Hex Value Symbol Meaning
				A symbol reference record
07-08		2	Bin	The statement number of the reference shifted one bit to the left. The rightmost bit on indicates a machine operand which could be altered by executing the instructions
09		1	Bin	Term type and attribute byte

### Assignment Build Local Data Areas

### CONTROL STATEMENT KEYWORD PARAMETER LIST

- Each statement processor passes control to \$CC2SS (syntax scan) with register 1 containing the address of the keyword parameter list within that phase.
- Syntax scan provides syntactical diagnostics for the statement keywords and
  modifies the parameter list (SXSVL) according to the parameter values
  supplied. This data is then in a form that can be processed by the calling
  ohase.
- Control is returned to the calling phase, which continues with diagnostics and processing based on the parameter values.

Disp Hex	Label	Lng Dec	Form	Description
00-01	SXSBFR	2	Addr	. Address of control statement input buffer
02-03	SXSBD@	2	Addr	Control statement input buffer pointer
04-05	SXSER@	2	Addr	Address of error routine
06	SXSFG1	1	Bit	Flag byte:
				Hex Value Symbol Meaning
				80 SXSCNT Continued statement 40 SXSSCT Continued sublist value
07	SXSENT		Disp	Displacement to first keyword element

The following equates describe one keyword and are repeated for each keyword of the control statement:

00	SXSKEL	1	Bin	Length of this keyword element in binary
01	SXSKWN	1	Bin	Keyword number
02	SXSKF1	1	Bit	Input flag byte:

Hex Value	Symbol	Meaning
80	SXSSLC	Sublist capable keyword
40	sxssvc	Split-value capa- ble keyword
20	SXSCVT	Convert value to binary
10	SXSYN	Yes/no type value

### CONTROL STATEMENT KEYWORD PARAMETER LIST (Continued)

Lng

Hex	Label	Dec	Form	Descript	ion	
				Hex Value	Symbol	Meaning
02 (continue	ed)			08	SXSCMP	Translate this key- word value to 2 bytes of hex data by using the table at the address pointed to by SXSCP@
				04 01	SXSREQ SXSCLN	Recuired keyword Length of value must have as many characters as in SXSLNE; length of value can vary
03	SXSKF2	1	Bit	Output	flag byte:	
				Hex Value	Symbol	Meaning
				80	SXSFND	Keyword given on statement
				40	SXSERR	Error detected while processing
				20	SXSCPV	this keyword Value is com- pressed
				10	SXSZOK	Zero value accept- ed, only used if SXSCVT = 1
04		1	_	Reserve	d	
05-06	SXSCP@	2	Addr	Address	of compress	s table
(05-06)	SXSMXV	2	Bin	converte	d to binary	wed if value is to be (this item is vith SXSCP@)
07-0E	SXSKWD	8	Char	Keywor	d left-justifi	ed
OF	SXSLNE	1	Bin	Length	1 of expec	ted value, hex 00 if

Disp

## CONTROL STATEMENT KEYWORD PARAMETER LIST (Continued)

_	Disp Hex	Label	Lng Dec	Form	Descripti	on
	10	SXSLNG	1	Bin	Length – are:	-1 of value. Possible contents
					Value	Meaning
					0 1 1 1 1	Yes/no value Converted value Compressed (not sublist) Sublist (address of output list) Split-value (address of output list) Not compressed or anything else
	11-nn	SXSVAL	n	Mix	Keyword in length	l value, left-justified, can vary
	(11-12)	SXSTB@	2	Addr	Address of table	of sublist table or split-value
	(nn)	SXSEND	1	Bin	Flag at er element,	nd of last keyword parameter hex FF
	The follo		are use	d for the c	ompressec	table. This table is pointed
	00	SXSVON	1	Bin		e order number, hex 00 if not e capable
	01	SXSCVL	1	Bin	Length o	f value to check against
	02-03	sxsscv	2	Bin		sed value, hex 0000 if SXSSVL all blanks
	04-nn	SXSSVL	n	Char	statemen	compare against that given in t (if all blanks, the value is on the statement)
		wing equates a			utput spli	t-value or sublist parameter

00	SXSOLN	1	Bin	Split-value order number	
01	SXSOLN	1	Bin	Length -1 of value	
02-nn	SXSOVL	n	Mix	The value, variable length	

### MAIN STORAGE TABLE SAVE AREA

- Compressed forms of the tables built by a particular statement processor can be saved in the main storage save area.
- This is a means of passing information (from phase to phase), which is necessary for the modification of various tables.

Disp		Lng		
	1 -11	D	C	Description
Hex	Label	Dec	Form	Description

### File Control Table (FCT) Compressed

00	FTJMP	1	-	Reserved
01	FTMCL	1	Bits	Flag byte
02-09	FTNAM	8	Char	File name
0A	FTAT1	1	Bits	File attributes byte 1
ОВ	FTAT2	1	Bits	File attributes byte 2
oc	FTSTR	1	Bin	Relative sector of entry in work file
0D	FTDISP	1	Bin	Displacement in sector
0E-0F	FTCR1	2	Bin	Record length
10	FTLNG	0	Bin	Length of compressed entry

### File Control Table (FCT) While Building FCT Entries

(10)	FTKYL	1 ,	Bin	Key length
11-12	FTKYD	2	Bin	Key position
13	FTLNG	0	Bin	Length of compressed entry during FCT build

### Line Control Table (LCT) Compressed

00-01	LTJMP	2	Bin	Compressed LCT entry length in binary
02	LTNLN	1	Bin	Line number and type
03	LTAT1	1	Bits	Line attributes byte 1:

Hex Value	Symbol	Meaning
40	LTSND	Index send given
02	LTPLL	Poll list given

### MAIN STORAGE TABLE SAVE AREA (Continued

Disp Hex	Label	Lng Dec	Form	Description
04	LTAT2	1	Bits	Line attributes byte 2
05	LTTCD	1	Bits	Line transmission code
06	LTLNA	1	Bits	Line configuration
07-08	LTBLK	2	Bin	Block length for this line
09-0A	LTDFF	2	Bin	DFF output hold area size
ОВ	LTLNG	0	Bin	Minimum length of compressed entry
(0B-nn)	LTPL	n	Char	Poll list, two-byte entries, the two- character ID given on the line control statement
			Bin	Modified to one-byte entries after last terminal for this line is processed (single byte entries are terminal internal ID)

## Program Characteristics Table (PCT) Compressed 6

1 Bin

TASBKF 1 Bin

Char

00-05

06

04

PTNAM

PTSTR

				the work file
07	PTDISP	1	Bin	Sector displacement to beginning of this entry
08	PTLNG	0	Bin	Length of compressed entry
Termina	l Attributes T	able (T	AT)	
00	TASAT1	1	Bits	Attribute byte 1 (for bit definitions, see index entry: terminal attributes set)
01	TASAT2	1	Bits	Attribute byte 2 (for bit definitions, see index entry: terminal attributes set)
02-03	TASRCL	2	Bin	Record length

Program name

Blocking factor

Relative sector number of this entry in

## MAIN STORAGE TABLE SAVE AREA (Continued)

Disp Hex	Label	Lng Dec	Form	Descript	Description		
Termina	l Attributes L	ise (TA	U) Table				
00	TATBSC	1	Bin	BSCA Ii	ne use:		
				Hex Value	Meaning		
					Reference BSCA lir	d by a terminal on	
				88	2		
				81	1	_	
01	TATMLT	1	Bit	MLTA	ine use:		
				Hex			
				Value	Meaning		
					Reference MLTA li	d by a terminal on ne:	
				80	8		
				40	7		
				20	6		
				10	5		
				80	4		
				04	3		
				02	2		
				01	1		
Termina	al Name Table	(TNT)	Compress	ed			
00-05	TNNAM	6	Char	Symbol	ic terminal r	name	
06	TNTUB	1	Bin	Relative	number of	associated TUT entry	
07	TNLIN	1	Bin	Line nu associat		which this name is	
80	TNFLG	1	Bit	Flag by	te for diagno	ostics:	
				Hex			
				Value	Symbol	Meaning	
				03	TNPG	Already referred to by this	

TNLNG 0 Bin Length of a compressed entry

09

### MAIN STORAGE TABLE SAVE AREA (Continued)

TTLNG 0 Bin

06

Disp Hex	Label	Lng Dec	Form	Descripti	ion	
Terminal	s Used Table	(TUT)	Compresse	d		
00-01	TTID	2	Char	Terminal	physical in	dentifier
02	TTIID	1	Bin	Internal	terminal IC	)
03	TTCHR	1	Bits	Terminal	l characteri	stics:
				Hex Value	Symbol	Meaning
				80	TTPRI	Primary name assigned
				20	ТТРН#	Phone number is required
04	TTLIN	1	Bin	Line nur	nber for th	is ter <b>m</b> inal
05	TTADR	1	Char	MLTA a	ddress char	acter

Length of compressed entry

DISK LAYOUT OF \$CCPFILE

\$CCPFILE

### CONFIGURATION RECORD

The CCP configuration record is formatted by CCP generation and written as the first sector of \$CCPFILE by \$CC1BF. It is never altered after its creation. In addition to its use as a printable record of a particular version of CCP, the contents of the configuration record are also used in the following two ways:

- The startup module, \$CCP, compares the entire first sector of \$CC1BF with the first sector of the operator-selected \$CCPFILE to ensure that the selected \$CCPFILE is the one generated when the modules on the production pack were generated.
- The assignment stage uses specific values of various bytes and bits to determine the functional level of the CCP system, thus the validity of statements and keyword values.

Disp Hex	Label		Lng Dec	Form	Descripti	on	
00-01	CFGV	'RF	2	Bin	Model 4)		or hex EBD4 on   CCPFILE has been F
. 02	CFGI	0	1	Bit			upported by CCP ported by user's
					Hex		
					Value	Symbol	Meaning
P					80	CFGMFU	MFCU supported
					40	CFG142	1442 supported
					20	CFGP52	5203 supported
					10	CFGP14	1403 supported
					08	CFGR2	DSM supports disk drive R2
					04	CFGF2	DSM supports disk drive F2
					02	CFGD1	DSM supports disk drive D1
					01	CFGD2	DSM supports disk drive D2
03-06	CFGR	V1 -	4	_	Reserved		
07	CFGF	A1	1	Bit	System fa	acilities:	
					Hex Value	Symbol	Meaning
					¥ aruc	Cymbol	mouning
					80	CFGDPF	DPF supported
					40	CFGSHR	File update sharing supported
					20	CFGN41	Directly attached 3741 supported

Disp Hex	Label	Lng Dec	Form	Descript	ion	
				Hex Value	Symbol	Meaning
07 (continu	ued)			10 Bits 4-7	CFGXUT CFGMXP	Reserved Maximum number (in binary) of concurrent user programs
80	CFGFA2	1	Bit	CCP faci	lities:	
				Hex Value	Sumbal	Meaning
				varue	Symbol	Wearing
				80	CFGSYM	Symbolic files supported
				40	CFGPUC	Program requests counted
				20	CFGTF	Reserved
				Bits 3-4	CFGSEC	No terminal sign- on security if 0
				10	CFGCPW	CCP-supplied password routine
				08	CFGUPW	User-supplied security routine
				04	CFGDME	Data mode escape supported
				02	CFGFMT	3270 display formatting supported
				01	CFGRUF	• •
09-0A	CFGRV2	2	_	Reserved	i	
ОВ	CFGPLG	1	Bit	Program	ming langua	ge support:
				Hex		
				Value	Symbol	Meaning
				80	CFGCOB	COBOL
				40		FORTRAN
				20	CFGASM	Assembler
				10	CFGRPG	RPG II
0C-0D	CFGCBO	2	Disp			f CCP branch et of \$@COIH

Disp Hex	Label	Lng Dec	Form	Description
0E-13	CFGESC	6	Mix	Data mode escape string (If CFGDME is 1, these 6 by tes contain the comparand for data mode escape. These are user-specified and can be EBCDIC characters of hexadecimal digits — hex 40 if CFGDME is 0.)
14-15	CFGLUS	2	Bin	Length of user security information (Nonzero only if CFGUPW is 1; number of bytes to be moved to user security work area from \$CC4Z9)
16-19	CFGRV3	4	-	Reserved
1A	CFGNS	1	Bin	Maximum number of sets planned for \$CCPFILE
1B	CFGNPM	1	Bin	Maximum number of programs in a set (from generation)
1C	CFGNDF	1	Bin	Maximum number of disk files in a set (from generation)
1D	CFGNT	1	Bin	Maximum number of terminals in a set (from generation)
1E	CFGDMP	1	Bin	Maximum number of dynamic storage dumps
1F-20	CFGCOR	2	Bit ,	Object program CPU size (Models 4, 8, and 10):
				Hex Value Meaning
				C000 48K 8000 32K 6000 24K 0000 64K
21	CFGTRC	1	Bin	Number of tracks for CCP trace to disk
22	CFGSRT	1	Bit	Bit 0 is 1 for sort (Model 12 only)
23	CFGSIZ	1	Bit	All bits off, 48K. Bit 7 on, 64K. Bit 3 on, 80K. Bits 7 and 3 on, 96K (Model 12 only).

				•		
Disp Hex	Label	Lng Dec	Form	Descrip	otion	
24	CFGTP	1	Bit	Telepr	ocessing adap	ter information:
				Bit	Symbol	Meaning
				0-3	CFGMLA	Binary number o
				4-7	GFGBSC	Binary number of BSCA lines
25	CFGMD1	1	Bit	MLTA	device suppor	rt:
				Hex		
				Value	Symbol	Meaning
				80	CFG50	1050
				40	CFG50D	1050D
				20	CFG40	2740
				10	CFG40S	2740S
				08	CFG40C	2740C
				04	CFG4SC	2740SC
				02	CFG40D	2740D
				01	CFG4DT	2740DT
26	CFGMD2	1	Bit	MLTA	device suppo	rt:
				Hex		
				Value	Symbol	Meaning
				80	CEC4DC	2740DC
				40	CFG4DC CFGDTC	
				20	CFG2S	2740M2S
				10	CFG2SB	2740W2S 27402SB
				08	CFG2SB CFG2SC	27402SB 27402SC
				04	CFGSCB	2740Z3C 2740M2SCB
				02	CFG41	2740W23CB
				01	CFG41D	2741D
27	CFGMD3	1	Bit		device suppo	
				Hex Value	Symbol	Meaning
				value	Зуливы	caming
				80	CFG7C	System/7 as a 2740C
				40	CFG7SC	System/7 as a 2740SC
				20	CFG7DC	System/7 as 2740DC
				10	CFGCMC	CMCST on dial line
				08	CFG705	2970M5
				04	CFG708	2970M8
				02	CFG709	2970M9
				01	CFG795	2970M95
1 20						

_	Disp Hex	Label	Lng Dec	Form	Description	on	
	28	CFGMD4	1	Bit	MLTA de	vice suppor	t:
					Hex Value	Symbol	Meaning
					80	CFG30	5930 (WTC only)
	29	CFGRV5	1	-	Reserved		
	2A	CFGMXC	1	Bit	MLTA tr	ansmission o	codes:
					Hex Value	Symbol	Meaning
					80	CFGMCO	Correspondence code
					40	CFGPEB	PTTCEBCD code
					20	CFGPBC	PTTCBCD code PTTCEBCD 1050
					10	CFGSPB	code
					01	CFGXBF	MLTA translation required
	2B-2C	CFGRV6	2	-	Reserved	i	
	2D	CFGBLT	1	Bit	BSCA lir	ne support:	
					Hex Value	Symbol	Meaning
					80	CFGBPP	Point-to-point
					40	CFGBMP	Multipoint
					20 10	CFGBCS CFGBD	Control station Dial (switched)
					10	Crabb	line
	2E	CFGBFA	1	Bit	BSCA fa	cilities supp	ort:
					Hex		
					Value	Symbol	Meaning
					80	CFGGET	GET message
					40	CFGITB	Intermediate text blocks
					20	CFGSEP	Record separators
					10	CFGRSP	Resident polling
_					08 04	CFGARS CFGELC	Auto response EBCDIC line code
					02	CFGALC	ASCII line code
					01	CFGBXP	BSCA transparency

Disp Hex	Label	Lng Dec	Form	Descript	ion				
2F-30	CFGRV7	2	-	Reserved	Reserved				
31	CFGRSB	1	Bin	Record s	eparator by	te			
32	CFGBD1	1	Bit	BSCA de	vice suppor	t byte 1:			
				Hex Value	Symbol	Meaning			
33	CFGBD2	1	Bit	80 40 20 10 08 04 02 01 BSCA de <i>Hex</i> <i>Value</i> 80 40 20	CFG351 CFG371 CFG341 CFG362 CFG372 CFG362 CFG362 Vvice suppor	Meaning 3735 CPU to CPU 3741 (as a			
(33)	CFGEND	1	_	End of c	onfiguration	terminal) n record			
34	CFGLEN	34	_		. •	iguration record			

### DIRECTORY

The directory of \$CCPFILE is the second sector of \$CCPFILE and is initialized by \$CC1BF. The assignment build program (\$CCPAS) maintains most of the information in this sector. However, startup initializes the following fields for each CCP run: DIRSRS, DIRMEM, DIRMXD, DIRDB@, DIRBT@, DIRET@.

	Disp Hex	Label	Lng Dec	Form	Description			
<b>\</b>	00	DIRNSA	1	Bin	Binary number of sets assigned in this \$CCPFILE			
	01-02	DIRSRS	2	C/S	Beginning disk address of \$CCPFILE, current run			
	03-05	DIRDAT	3	Bin	Date \$CCPFILE last modified by assignment			
	06	DIRDID	1	Char	Execution default set ID			
	07	DIRNFX	1	-	Reserved			
	08-09	DIRMEM	2	Bits	Storage size of the object CPU, current run			
					Model 12 only:			
					Hex			
					Value Meaning			
					00C0 48K			
					0100 64K			
					0140 80K			
					0180 96K			
	0A	DIRMXD	1	Bin	Maximum number of disk storage dumps during current run			
	0B-0C	DIRBD@	2	C/S	Disk address of start of storage dump area			
	0D-0E	DIRED@	2	C/S	Disk address +1 of end of storage dump area			

### DIRECTORY (Continued)

DIRPCT

1 Bin

80

DINECT	DINECTORY (CONTINUED)								
Disp Hex	Label	Lng Dec	Form	Description					
(0D-0E)	DIRBT@	2	C/S	Disk address of start of CCP trace area					
0F-10	DIRET@	2	C/S	Disk address +1 of end of CCP trace area (If CCP trace is not invoked, DIRBT@ = DIRET@.)					
There is one directory entry for each set in \$CCPFILE:									
00	DIRID	1	Char	Set identification character					
01	DIRSIT	1	Bin	Number of sectors in system information table (SIT)					
02	DIRTAT	1	Bin	Number of sectors in terminal attribute table (TAT)					
03	DIRLCT	1	Bin	Number of sectors in line control table (LCT)					
04	DIRTUT	1	Bin	Number of sectors in terminal unit table (TUT)					
05	DIRTNT	1	Bin	Number of sectors in terminal name table (TNT)					
06	DIRSTT	1	Bin	Number of sectors in switched terminal table (STT)					
07	DIRFCT	1	Bin	Number of sectors in file control table (FCT)					

Number of sectors in program control

table (PCT)

### FILE CONTROL TABLE (FCT)

- This table contains information about all physical disk files specified to CCP by assignment.
- Information from the // DISKFILE and // SYMFILE assignment statements is used to create this table.
- To locate, add the number of sectors of the preceding six tables for this assignment set as specified in the directory entry for this set.

Disp Hex	Label	Lng Dec	Form	Descrip	tion				
00	FCTJMP	1	Bin	Length	Length of this entry in binary				
01	FCTMCL	1	Bit	Miscellaneous flag byte:					
				Hex					
				Value	Symbol	Meaning			
				80	FCT45	5445 resident file			
				40	FCTIHO	Inhibit open, set by startup			
				20	FCTSYM	Symbolic file name associated with a physical file name			
				10	FCTMIX	Master index used			
02-09	FCTNAM	8	Char	File nar	ne left-justifi	ied			

FILE CONTROL TABLE (FCT) (Continued)										
Disp Hex	Label	Lng Dec	Form	Description						
Symbolic File Name Entries Only										
0A-nn	FCTPYS	n	Bin	A series of one-byte index pointers, each pointing a FCT physical file entry						
Physical File Name Entries Only										
0A	FCTAT1	1	Bit	Attribute	s byte 1:					
				Hex Value	Symbol	Meaning				
				80 40 20 08 04 02 01	FCTIND FCTCNS FCTDIR FCTIN FCTOUT FCTUPD FCTADD	Indexed Sequential Direct Input Output Update Add				
ОВ	FCTAT2	1	Bit	Attribute	s byte 2:					
				Hex Value 40 20 10	Symbol FCTORD FCTRND FCTLMT	Meaning Ordered Random Limits				
0C-0D	FCTRCL	2	Bin	Record le	ngth					
Indexed I	iles Only									
0E	FCTKYL	1	Bin	Key lengt	h					
0F-10	FCTKYD	2	Bin	Key posit	ion in recor	d, leftmost byte				

Indexed Files with Master Index Only

11-12 FCTMTX 2 Bin Master index area size

### LINE CONTROL TABLE (LCT)

- This table contains information about all teleprocessing lines specified to CCP by assignment.
- Information from the // BSCALINE and // MLTALINE assignment statements are used to create this table.
- To locate, add the number of sectors of the preceding two tables for this assignment set as specified in the directory entry for this set.

Disp Hex	Label	Lng Dec	Form	Descript	tion				
00-01	LCTJMP	2	Bin	Length	Length of this entry in binary				
02	LCTNLN	1	Bin	Line number and type:					
				Hex					
				Value	Symbol	Meaning			
				88	LCTBS2	BSCA line 2			
				81	LCTBSC	BSCA line 1			
				80	LCTL8	MLTA line 8			
				40	LCTL7	MLTA line 7			
				20	LCTL6	MLTA line 6			
				10	LCTL5	MLTA line 5			
				80	LCTL4	MLTA line 4			
				04	LCTL3	MLTA line 3			
				02	LCTL2	MLTA line 2			
				01	LCTL1	MLTA line 1			
03	LCTDEV	1	Bit	MLTA	device type o	on this line:			
				Hex					
				Value	Symbol	Meaning			
				03	LCT741	2741 or CMCST			
				02	LCT740	2740 or System/7			
				01	LCT050	1050 ·			
04	LCTAT1	1	Bit	Line att	ributes byte	1:			
				Hex					
				Value	Symbol	Meaning			
				80	LCTTRC	Transmit control			
				20	LCTLRC	LRC checking or any 1050			
				10	LCTSWT	Switched line			
				08	LCT600	600 or 1200 bps MLTA line			
				04	LCTSC	Station control or any 1050			
				01	LCTAPL	Auto-poll feature			

## LINE CONTROL TABLE (LCT) (Continued)

Disp Hex	Label	Lng Dec	Form	Description					
05	LCTAT2	1	Bit	Line att	Line attributes byte 2:				
				Hex Value	Symbol	Meaning			
				80	LCTBFR	Buffer receive feature			
				10	LCTRI	Receive interrupt feature			
				80	LCTSU	This line sup- pressed by startup			
				04	LCTOLT	Online test			
				02	LCTDBL	supported  Double buffering  supported			
				01	LCTAC	Auto-call feature			
06	LCTTCD	1	Bit	Line tra	nsmission co	ode:			
				Hex					
				Value	Symbol	Meaning			
				80	LCTCOR	CORR			
				40	LCTPEB	PTTCEBCD			
				20	LCTPB	PTTCBCD			
				10	LCTSPB	PTTCEBCD 1050			
				08	LCTE	EBCDIC			
				04	LCTET	EBCDIC traps-			
						parency			
				02	LCTA	ASCII			
				01	LCTITB	ITB, BSCA	_		
07	LCTNRT	1	Bin	Numbe	r of retries fo	or line error			
08	LCTLNA	1	Bin	Line co	nfiguration:				
				Hex					
				Value	Symbol	Meaning			
				05	LCTCW	Switched with 1050 having station control			
				04	LCTSW	Switched			
				03	LCTCS	Control station			
				02	LCTMP	Multipoint			
				01	LCTPP	tributary Point-to-point			
09	LCTDLY	1	Bin		<ul> <li>Delay af</li> </ul>				
				BSCA		of times through poll			
					list				

## LINE CONTROL TABLE (LCT) (Continued)

Lng

Disp

	Hex	Label	Dec	Form	Descript	ion		
	0A-0B	LCTBLK	2	Bin	Block lei	ngth for this	line	
	0C-0D	LCTMAP	2	Bin	DFF out	put hold are	ea size	
	0E-0F	LCTWAT	2	Bin	BSCA lir	ne active wai	t time	
	10	LCT#PL	1	Bin	Number	of entries in	poll list	
	11-12	LCTDAT	2	Bin	Maximus line buff		f data characters in	
_	13	LCT#RI	1	Bin	Number LCT ent		O entries in this	
	14	LCTAT3	1	Bits	Line attr	ibutes byte	3:	
					Hex Value	Symbol	Meaning	
					80	LCTM2	2740 Model 2 supported	
					40	LCTIDS	ID to send con- tained in this LCT	
	15-18	LCTRV3	4	-	Reserved	I		
	Control S	Station Lines	Only					
	19-nn	LCTPLL	n	Bin	Polling list (this entry is variable length and contains a series of one-byte entries that are the relative positions of the TUT entries that describe the terminals in the poll list)			
	Switched	BSCA Lines	Only (0	Optional)				
	(19)	LCTSIL	1	Bin	Length +	1 of ID cha	racters to send	
	(1A-nn)	LCTSID	n	Char		cters to send characters	d, variable length,	
	Displacer	nents for Eacl	n ID to	Receive (	Optional)			
	(00)	LCTTID	1	Bin	tion of T	'UT that des	al ID, relative posi- cribes the terminal	
					associate	d with this	ID to receive	

### LINE CONTROL TABLE (LCT) (Continued)

Disp Hex	Label	Lng Dec	Form	Description
(02-nn)	LCTRCH	n	Char	ID to receive, variable length, up to 15 characters
(nn)	LCTSKP	1	Bin	Hex 80: Skip byte on

### PROGRAM CHARACTERISTICS TABLE (PCT)

- This table describes programs and all system resources used by the program.
- Information from the // PROGRAM assignment statement is used to create this table.
- To locate, add the number of sectors of the preceding seven tables for this assignment set as specified in the directory entry for this set.

Disp Hex	Label	Lng Dec	Form	Description
00-01	PCTJMP	2	Bin	Length of this PCT entry (disk and initial input only); hex FFnn indicates last PCT in sector
02-07	PCTNAM	6	Char	Name of the user program defined by this PCT entry
08-09	PCTCS	2	C/S	Disk address (C/S) of this user program *
0A	PCT#S	1	Bin	Number of text sectors (on disk) of this user program
0B-0C	PCTLNK	2	Addr	Link-edited address of this program
0D .	PCTRLD	1	Bin	Offset to the RLDs in the last text sector
0E-0F	PCTENT	2	Addr	Entry point address of the program after link-editing
10-11	PCTSIZ	2	Bin	Size of the user program in total main storage requirements
(10)	PCTLNG	1	Bin	Size of the user program in number of 256-byte blocks

## PROGRAM CHARACTERISTICS TABLE (PCT) (Continued)

Disp Hex	Label	Lng Dec	Form	Description	on	
12	PCTAT1	1	Bin	Program a	attributes by	rte 1:
				Hex Value	Symbol	Meaning
				Bits 0, 1	_	00: RPG program 01: COBOL program 10: Assembler program 11: FORTRAN program
				20	PCTDPL	Program requires a dedicated program level
				10	PCTMTS	Program supports multiple request- ing terminals
				80	PCTNEP	Program is a never- ending program
				04	PCTPRT	Program requires the line printer during execution
				02	PCTMFU	Program requires the MFCU during execution
				01	PCT142	Program requires the 1442 during execution
13	PCTAT2	1	Bin	Program	attributes b	yte 2:
				Hex Value	Symbol	Meaning
				80	PCTSU	Program sup- pressed during CCP startup
				40	PCTSDB	Program uses DSM shared disk I/O buffering
				20	PCTPAK	Program is to be loaded from DSM system pack; otherwise, from the same pack that CCP was loaded from
				10	PCTEMG	End-of-job release message to be sent to requesting terminals

## PROGRAM CHARACTERISTICS TABLE (PCT) (Continued)

Disp Hex	Label	Lng Dec	Form	Descript	ion	
				Hex Value	Symbol	Meaning
13 (continue	d)			08	PCTCOM	Program requires common area
Continue	u,			04	PCTSER	Program is serially reusable and may be reexecuted without being reloaded
				02	PCTDAT	Input data is allowed (but not required) with program request
				01	PCTN41	Program requires 3741
14	PCTAT3	1	Bin	Program	attributes b	yte 3:
				Hex Value	Symbol	Meaning
				80	PCTSRT	CCP sort program
15	PCTMAX	1	Bin			f requesting rogram can support
16	PCTFDT	1	Bin	longest		e blocks in the descriptor table
17	PCTDFF	1	Bin	Nonzero required appende	for the DF	of 256-byte blocks F work area to be r program area
1A-1B	PCT\$Z	4	Char	Program	request une	der format name
10	PCTNLT	1	Bin		d to the pro	terminals to be gram prior to
1D	PCTNDT	1	·Bin		r of disk files gram prior to	to be allocated to execution
1E	PCTAT3	1	Bin	Program	n attributes b	byte 3:
				Hex Value	Symbol	Meaning
				80	PCTSRT	Sort program

### PROGRAM CHARACTERISTICS TARLE (PCT). (Continued)

PROGI	RAM CHARAC	TERIS	TICS TAI	BLE (PCT)	(Continued	)
Disp Hex	Label	Lng Dec	Form	Descrip	tion	
There a	are as many of es:	the follo	owing fiel	ds as the v	alue in the fi	eld PCTNLT
00	PCTLTD	1	Bin		o the entry ir r this require	n the terminal name od terminal
01	PCTTAS	1	Bin		es set for the	n the terminal attributes of this
	lowing fields for the field PCT			al entries.	There are as	many entries as the
00	PCTDTD	1	Bin		e short DTF e orresponds	entry to which this
01	PCTMDE	1	Bit	File use	attributes by	yte:
				Hex Value	Symbol	Meaning
				80	PCTMDE	Symbolic file reference; other- wise direct short DTF reference
				20	PCTNRU	
				10	PCTSHR	The file is not shareable during the execution of this program
				08	PCTREF	Access is reference only
				04	PCTLOD	Access if file load (implies nonsharing)
				02	PCTUPD	Access is update
				01	PCTADD	Access if add (implies non sharing with another adder); is zero for access IRANA or IRUANA except in a one-task
						system

### PROGRAM CHARACTERISTICS TABLE (PCT) (Continued)

Lng

Disp

Hex	Label	Dec	Form	Description
02	PCTDTA	1	Bin	Assignment relative DTF (value used during execution is in PCTDTD and can be different from this value if files are suppressed during startup)
03	PCTCRL	1	_	Reserved
The follo files:	wing two field	ds follo	w any enti	ries for required terminals and/or disk
00-01	PCTDCT	2	Bin	Offset into the program request count table in main storage during execution of this program

Number of times this program has been requested successfully during execution (reset to zero by an option of assign-

ment list program)

### SYSTEM INFORMATION TABLE (SIT)

02-03 PCTNUM 2

- This table describes the system resources available and/or used by CCP for this set.
- Information from the // SYSTEM statement is used to create this table.

Bin

• It is the first table in the assignment set.

Disp Hex	Label	Lng Dec	Form	Descrip	tion			
00	SITMXP	1	Bits	Maximu program		of concurrent user		
01	SITMUA	1	Bits		m number o gram area	f blocks for CCP		
02-03	SITMTB	2	Bits		m number o hold buffer a	f bytes for telepro- area		
04-09	SITCPW	6	Char	CCP pas	CCP password is used; otherwise, hex 40			
0A	SITDED	1	Bits	Devices	initially allo	cated to CCP:		
				Hex Value	Symbol	Meaning		
				80	SITPRT	Printer allocated		
				40	SITMFU	MFCU allocated	4	
				20	SIT142	1442 allocated		
				10	SITN41	3741 allocated	•	

## SYSTEM INFORMATION TABLE (SIT) (Continued)

	Disp Hex	Label	Lng Dec	Form	Description	on	
	ОВ	SITFLG	1	Bits	Flag byte informati	for display on:	format
					Hex Value	Symbol	Meaning
					40	SITDFU	Display formats are on system pack; otherwise, program pack DFF supported on this set
	oc	SITTRC	1	Bin	Number of trace	of blocks fo	r CCP in-storage
	0D	SITSQB	1	Bin	Number	of sector en	queue blocks (SQB)
	0E	SITFSB	1	Bin	Number ( (FSB)	of file speci	fication blocks
	0F	SITRQL	1	Bin	Maximun and data	n length of	program request
	10	SITNQL	1	Bin	Maximun request c	-	nonprogram
	11-12	SITMCL	2	Bin	Maximun	n terminal o	ommand length
	13	SITTAS	1	Bin	Highest t	erminal attr	ibute set ID value
	14	SITSTT	.1	Bin	Number entries	of switched	terminal table
	15	SITNPC	1	Bin	Number	of program	control table entries
	16	SITLPC	1	Bin	Length o entry	f longest pr	ogram control table
	17	SITSID	1	Char	Set ID of	f this set	
	18-19	SITRUF	2	Bin	Program length	request und	ler format maximum
_	1A-1B	SITRV1	2	-	Reserved	l	

### TERMINALS USED TABLE (TUT)

- This table describes physical terminal attributes.
- Information from the // BSCATERM and // MLTATERM statements is used to create this table.
- To locate, add the number of sectors of the preceding three tables for this assignment set, as specified in the directory entry for this set.

Disp Hex	Label	Lng Dec	Form	Descript	tion		
00	TUTLNG	1	Bin	Length	of this entry	in binary	
01-02	TUTID	2	Char	Termina	al physical ide	entifier	
03	TUTIID	1	Bin			relative position the TUT table	
04	TUTCHR	1	Bit	Termina	al characteris	tics:	
				Hex Value	Symbol	Meaning	
				80	TUTLNE	BSCA line; otherwise MLTA	
				20	TUTTYP	Typewriter device	
				08	TUTCMN		
				04	TUTMCT	Multicomponent terminal	
				02	TUTOUT	Output capable terminal	
				01	TUTINP	Input capable terminal	
05	TUTAT1	1	Bit	Attribut	tes byte 1:		
				Hex			
				Value	Symbol	Meaning	
				80	TUTSU	Terminal was sup- pressed by startup	
				20	TUTONL	Available online	
				02	TUTSWC	Switched line	
				01	TUTOFF	Sign-off default is HOLD	

## TERMINALS USED TABLE (TUT) (Continued)

Disp Hex	Label	Lng Dec	Form	Description	on	
06	TUTAT2	1	Bin	1050 prin componer	cipal input nt:	and output
				Hex Value	Meaning	
				30 20 10	Input dev Reader 2 Reader 1 Keyboar Output de	2 I d
				08 07 06 05	Punch 2 Punch 1 Printer 2 Printer 1	·
07-08	TUTLIN	2	Bin	Line num	ber and typ	e:
				Hex Value	Symbol	Meaning
				8888 8081 0080 0040	TUTBS2 TUTBS1 TUTL8 TUTL7	BSCA line 2 BSCA line 1 MLTA line 8 MLTA line 7
				0020 0010 0008	TUTL6 TUTL5 TUTL4	MLTA line 6 MLTA line 5 MLTA line 4
				0004 0002 0001	TUTL3 TUTL2 TUTL1	MLTA line 3 MLTA line 2 MLTA line 1
09	TUTPHY	1	Bin	Physical c	haracteristi	cs of terminal:
				Hex Value	Symbol	Meaning
				09 08 07	TUTN41 TUTCPU TUT375	3741 CPU 3735
				06 05 04	TUT5M2 TUT5M1 TUT7M2	3275 M2-1980 3275 M1-480 3277-84-86
				03	TUT7M1	M2-1920 3277-84-86 M1-480
				02 01	TUT105 TUTMLT	MLTA 1050 MLTA (all machines except
				00	TUTCON	1050) Console

### TERMINALS USED TABLE (TUT) (Continued)

Disp Hex	Label	Lng Dec	Form	Description
0A	TUTTAS	1	Bin	Index of standard attributes set
0B-0E	TUTRV3	4	_	Reserved

### BSCA Terminals on Control Station or Multipoint Lines Only (Optional)

0F-nn	TUTADD	n	Char	Terminal address characters, variable in length, 2 to 7 characters
nn-nn	TUTPOL	n	Char	Terminal poll characters, variable in length, 2 to 7 characters

### MLTA Terminals on Control Station or 1050 Switched Lines Only (Optional)

OF TUTADR 1 Char MLTA address character

# TERMINAL NAME TABLE (TNT), TERMINAL UNIT BLOCK (TUB), SWITCHED TERMINAL TABLE (STT)

The following areas, which are also a part of \$CCPFILE, are listed under Execution Data Areas:

- Terminal name table (TNT)
- Terminal unit block (TUB)
- Switched terminal table (STT)

## \$CCPLOG File (Model 4 Only)

The CCP console messages are written on the \$CCPLOG file on disk. The messages are compressed by removing all blanks on the right. A separator byte and two length bytes are added to this compressed message to give a console log file entry.



FF = Separator byte

L = Total length (message plus 3)

When CCP is started, the first message, P/000 CCP STARTED, is always written at the beginning of the file. Each message is not written to the disk individually. The console log file entries are written to the disk each time there is more than one sector (256 bytes) of entries held in memory. Therefore, if CCP terminates by other than cancel or shutdown, the newest messages will still be in memory. The next available entry in the file is always marked on disk by a special four-byte entry.

FF 04 00 04

The newest entry in the file is the one before the special entry. The file automatically wraps when it is full.

The oldest entry in the file is usually the P/000 CCP STARTED message at the beginning of the file. However, if the file has wrapped, the newest information is indicated by the separator byte and the next sector is the oldest entry in the file.

- L FF L MESSAGE	1047 L FF 04 00 04	FF L MESSAGE 20 L
Sector 201	Sector 202	Sector 203

Message 1047 is the newest entry. Message 20 is the oldest entry.

### Startup Data Areas

### PHASE ROLLER LIST

The startup phase roller list is a 256-byte area containing a maximum of twenty-five ten-byte entries. Each entry consists of the last two characters of the startup module name (phase ID) and eight bytes reserved for the load list (directory parameters: cylinder/sector address (two bytes long), number of text sectors (one byte long), link-edit address (two bytes long), displacement to first RLD (one byte long), entry point address (seven bytes long)).

The roller list, except the entry for LO, initially resides in module \$CC3PI, which is link-edited with \$CC3LO. \$CC3LO, initiated as the first phase after \$CCP, performs the directory search for the modules, then transfers the directory information to the load list part of the entries. When the roller list is completed, it is moved to the roller list area in \$CC3RO as the contents of the last sector of the program level.

The last four bytes of the program level (last four bytes of roller list) contain a two-byte eyecatcher and a two-byte address of the beginning of the startup save area. The eyecatcher is initially defined as a two-byte field containing blanks. Just prior to the passing of control to each phase, the phase ID is moved into the field by \$CC3RO. This field is set to hex 0001 by \$CC3EL just prior to the final passing of control to \$CC4.

Label	Lng Dec	Form	Description	
ROLIST	0		Startup phase ro	oller list.
	10	Char	'LOxxxxxxxx'	Roller list builder
	10	Char	'FXxxxxxxxx'	Free C/S and index format
	10	Char	'CRxxxxxxxx'	Cross reference transients
	10	Char	'USxxxxxxxx'	Unsuppress facilities
	10	Char	'FSxxxxxxxx'	Suppress facilities
	10	Char	'IPxxxxxxxx'	Initialize PCT
	10	Char	'LDxxxxxxxx'	Load base module
	10	Char	'UBxxxxxxxx'	Build user TCBs in main storage
	10	Char	'TAxxxxxxxx'	Load terminal attribute table
	10	Char	'TBxxxxxxxx'	TP control blocks
	10	Char	'TCxxxxxxxx'	Build TUBs and terminal names
	10	Char	'DLxxxxxxxx'	Build skeleton short DTFs
	10	Char	'DMxxxxxxx'	Disk file access method of diagnostics

### PHASE ROLLER LIST (Continued)

	Lng			
Label	Dec	Form	Description	
	10	Char	'DFxxxxxxx' Open files and compress DTFs	
	10	Char	'PXxxxxxxxx' Build PCT index in main storage	è
	10	Char	'Elxxxxxxxx Build MLTA poll list	
	10	Char	'EJxxxxxxxx' End of phase 3	
	10	Char	'LTxxxxxxxx' Load TP I/O trace modules	
	10	Char	'EKxxxxxxxx' Allocate TPBUF and UPA	
	10	Char	'EMxxxxxxxx' Allocate BSCA line buffers	
	10	Char	'ELxxxxxxxx' Open teleprocessing lines	
	10	Char	'CXxxxxxxx' 'CYxxxxxxx' 'CZxxxxxxxx'	
	10	Char	'MVxxxxxxx' Load \$CC4DF/\$CC4#3 Init \$@9CIN/\$@@BIN/AIR routine in \$CC4DP	
		Bin	Hex 00 - Reserved for any future expansion	
	2	Char	'xxxx' - Eyecatcher (phase ID placed here and modified for each phase	
	2	Addr	Pointer to startup save area	

### STARTUP SAVE AREA

- Pointed to by the last two bytes of the phase roller list.
- Used to pass information from one phase to the next during startup.

Disp Hex	Label	Lng Dec	Form	Description
00	SSA#RS	1	Bin	Binary number of sectors reserved between phase roller (\$CC3RO) and next phase to be loaded
01	SSAERR	1	Bit	Startup error switch; all bits on (hex FF) indicates that an abort error occurred
02	SSAQST	1	Bit	Flag byte:
				Hex Value Symbol Meaning
				80 SSACEX Storage exhausted during startup
03-36	SSACFG	52	Mix	CCP configuration record area
37-60	SSADIR	42	Mix	Compressed \$CCPFILE directory area
61-7C	SSASIT	28	Mix	System information table save area
7D-84	SSALDP	8	Mix	Base module load parameters — C/S/N/LE/D/EP
85-86	SSANB@	2	Addr	Address of where to build next control block

# STARTUP SAVE AREA (Continued)

_	Disp Hex	Label	Lng Dec	Form	Description	on	
	87-88	SSAHB@	2	Addr	Highest co	ntrol block	build address +1
	89	SSAMS1	1	Bit	Miscellane switch:	eous startup	information
					Hex Value	Symbol	Meaning
					80 40	SSADPF SSALVL	DPF system CCP operating in program level 2
					20 10	SSAM04 SSAECS	Model 4 system ECS supported on Model 4
					01	SSAPRQ	Program request counting on
	8A	SSAMS2	1	Bit	tion switc		s startup informa-
					Hex Value	Symbol	Meaning
					20	SSATTD	Set CCP trace-to- disk on
					10 08 02	SSATBS SSATML SSASUP SSAOFL	Set BSCA trace on Set MLTA trace on Ask user about suppression Ask user about
					01	SSAUFL	offline terminals
_	8B-8C	SSAIAR	2	Addr	Saved IAF	R for other	level in DPF system
	8D	SSA\$CQ	1	Bin	Q byte fo	r unit \$CCP	FILE is on
	8E-8F	SSA\$XA	2	C/S	C/S disk a	ddress of st	art of \$CCPFILE
	90-91	SSA\$XB	2	C/S	C/S disk a		past end of
	92	SSACOR	1	Bin	Storage si is running		nt object that CPU
	93-94	-SSAFF@	2	C/S	C/S addre \$CCPF1L		ee sector in
	95-96	SSAFX@	2	C/S	C/S of dis	play forma E	t index in
	97-98	SSABDF	2	Addr	Storage address	ddress for fi	rst BSCA DTF

#### STARTUP SAVE AREA (Continued)

Disp Hex	Label	Lng Dec	Form	Description
99	SSALPC	1	Bin	Length of longest unsuppressed PCT entry
9A	SSAML#	1	Bits	Bit significant MLTA line trace mask
9В	SSA\$LQ	1	Bits	O byte for unit \$CCPLOG is on

#### SCAN CONTROL BLOCK USED WITH \$CCSCN

Used by \$CCSCN to pass information back to the requestor with information on the scanned field and delimiter.

Disp Hex	Label	Lng Dec	Form	Description
00	SCACTL	1	Bin	Length -1 of field preceding delimiter (set by \$CCSCN)
01-02	SCACTA	2	Addr	Address of rightmost byte of field preceding delimiter (set by \$CCSCN)
03	SCLIML	1	Bin	Length —1 of remaining area to be scanned, including current delimiter (set by invoker to total area —1 before beginning scans of an area, updated on each scan by \$CCSCN)
04-05	SCLIMA	2	Addr	Address of rightmost byte of total area to be scanned (set by invoker, never changed by \$CCSCN)
06	SCDLEL	1	Bin	Length of each delimiter's entry in a delimiter list; the delimiter itself must be only one byte, but additional control information might accompany each delimiter (set by invoker, never changed by \$CCSCN)
07	SCDELX	1	Bit	Bit configuration of the stopper byte that marks the end of a delimiter list (set by invoker, never changed by \$CCSCN)

# TRANSIENT RELOCATION LIST

Lng Dec	Form	Descript	tion
2	Char	AB	Accept BSCA check
2	Char	AC	Accept input satisfied
2	Char	AD	Disk allocation transient
2	Char	AL	Command processor allocate module
2	Char	AN	Second allocation transient
2	Char	AP	Third allocation transient
2	Char	ΑQ	Terminal acquire
2	Char	AS	Assign command
2	Char	AT	Second assign processor
2	Char	AU	Second assign transient
2	Char	AX	Second terminal acquire
2	Char	AY	Third terminal acquire
2	Char	Α1	Allocation control transient
2	Char	A2	Second allocation control routine
2	Char	ВА	BSCA 3270 sense/status
2	Char	вв	BSCA record format (blank)
2	Char	BC	BSCA stop/cancel invite
2	Char	BD	BSCA ERP clean-up
2	Char	BE	BSCA error handler
2	Char	BF	BSCA FREEMAIN invite buffer analysis
2	Char	BG	3284/3286/3288 error handler
2	Char	ВІ	BSCA DME inquiry
2	Char	BL	BSCA error log to operator
2	Char	BP	BSCA purge/abort line
2	Char	BQ	BSCA stop II Q analysis
2	Char	BR	CCP BSCA
2	Char	BS	Switched BSCA line purge
2	Char	вт	Start online test for BSCA
2	Char	во	BSCA CCP format of 3270
2	Char	В1	BSCA minimum system function 1
2	Char	В2	BSCA minimum system function 2
2	Char	В3	BSCA minimum system function 3
2	Char	B5	CCP 3735 sense/status
2	Char	В9	BSCA error check trace dump
2	Char	CA	Display user transient 3
2	Char	CG	Console message command
2	Char	CJ	System operator cancel
2	Char	CN	Terminal operator cancel
2	Char	CR	First main storage allocation transient
2	Char	CS	Second main storage allocation transient
2	Char	ст	Third main storage allocation transient
2	Char	CX	Console cancel CCP
2	Char	C1-C6	Display commands
2	Char	C7	Display system by ID
2	Char	C8	Display terminal transient 2

# TRANSIENT RELOCATION LIST (Continued)

Lng Dec	Form	Descripti	on
2	Char	C9	Display user transient 2
2	Char	DA-DD	DFF
2	Char	DK	DFF
2	Char	DM	Data mode escape routine
2	Char	DR	DF,F
2	Char	EA	First error message routine
2	Char	EB	Second error message module
2	Char	EC	Third CCP message module
2	Char	ED EE-EF	File command processor error
2	Char	EE-EF	Message modules
2	Char	EG	Error message module, CCP
2	Char	EH	Message module
2	Char	EJ	Shutdown module
2	Char	EL	Message module
2	Char	EP	Message module
2	Char	EU	Message module
2	Char	E1-E5	Message modules
2	Char	FL	File command processor
2	Char	F2	Second file command processor
2	Char	GA	Get attributes
2	Char	GB	Second get att, utes transient
2	Char	HF	CCP RPG II halt/syslog processor
2	Char	нн	Halt/syslog halt check
2	Char	H1	CCP halt/syslog processor for TID-1
2	Char	H2	CCP halt/syslog processor for TID-2
2	Char	J1- <b>J</b> 9	Translate transients
2	Char	JA-JC	Translate transients
2	Char	JD-JE	BSCA translate transients
2	Char	KA-KB	Console management
2	Char	K1-K9	Console management
2	Char	LT	Termination close interface
2	Char	L2-L4	Close
2	Char	MA	First level MLTA error handler
2	Char	MB	Handles disconnection of MLTA
2	Char	MC-ME	MLTA error handlers
2	Char	MF	Part of MLTA switched line disconnect
2	Char	MG	Command processor teleprocessing message routine
2	Char	MP	Ignore put to terminal in ERP
2	Char	MT	Start online test for \$CC4CM
2	Char	MZ	MLTA online test
2	Char	м9	MLTA error check trace dump
2	Char	NC	Cancel transient out of \$CC4II
2	Char	NM	Name command processor
2	Char	OF	Terminal sign-off
2	Char	OG	Second sign-off routine

# TRANSIENT RELOCATION LIST (Continued)

	Lng Dec	Form	Description	on
	2	Char	ОН	FORTRAN pseudo open
	2	Char	OP	Open/close
	2	Char	OR	Open/close return
	2	Char	OS	Open shared I/O
	2	Char	ОТ	Tape pseudo open
	2	Char	01	Open/close
	2	Char	02-09	Open
	2	Char	PC	Command processor first load
	2	Char	PF	Command processor
	2	Char	PG	MLTA purge I/O
	2	Char	PK	Command processor console command validator
_	2	Char	PR	Command processor return routine
	2	Char	PT	Command processor term command validator
	2	Char	QQ	Q/NOQ command processor
	2	Char	RC	TUB rechain after program request
	2	Char	RE	Resume command
	2	Char	RF	Resume transient 2
	2	Char	RL	First release module
	2	Char	RN	Run processor
	2	Char	RP	Teleprocessing error recovery routine
	2	Char	RX	Second release module
	2	Char	RY	Third release transient
	2	Char	R1	\$CC4R1 (program request)
	2	Char	R2	\$CC4R2 (program request)
	2	Char	R3	Third program request routine
	2	Char	R4	Fourth program request routine
	2	Char	R5	Fifth program request routine
_	2	Char	R6	Sixth program request routine
	2	Char	R7	Seventh program request routine
	2	Char	R8	Eighth program request routine
	2	Char	SB	Stop polling-bad abort start code
	2	Char	SC	\$CC4CM bad start code analysis
	2	Char	SF	Handles stop polling failure
	2	Char	SH	Shutdown command
	2	Char	sĸ	Poll skip bit routine for \$CC4CM
	2	Char	so	Terminal sign-on
	2	Char	SP	Console management stop polling transient—MLTA
	2	Char	SQ	Op end handler for stop polling
	2	Char	SS	Command processor suspend module
_	2	Char	SU	Startup end, CCP control begin
	2	Char	S0	BSCA CCP format of 3275 switched
	2	Char	S2	Second level of \$CC4SP
	2	Char	TB	Terminal allocation routine
	2	Char	TD	First termination transient
	2	Char	TE	Trace-to-disk command

# TRANSIENT RELOCATION LIST (Continued)

Lng Dec	Form	Descripti	on
2	Char	TF	Termination files deallocation
2	Char	TN	Termination main transient
2	Char	TP	Termination polling restart 1
2	Char	TS	Online test command from console
2	Char	TW	Termination dump transient
2	Char	TY	Teleprocessing polling restart 2
2	Char	TZ	Online test command—XCTL/BSCA
2	Char	T1	Handle online parameter list for console management
2	Char	T2	Handle online test op end
2	Char	UR	Unit record allocation transient
2	Char	VA	Vary command
2	Char	VB	Second vary command processor
2	Char	WC	Switched line message to system operator
2	Char	WD	Second level switched line message to system operator
2	Char	WR	Translation error in \$CC4CM
2	Char	YA	User first sign-on transient
2	Char	YB-YZ	User transients
2	Char	Y0-Y9	User transients
2	Char	Y\$	User transient
2	Char	Y@	User transient
2	Char	Υ#	User transient
1	Bin	FF	End of ID list

#### **XREF TRANSIENT LIST**

Lng Dec	Form	Descripti	on
2	Char	AD	Disk allocation transient
2	Char	AL	Command processor allocate module
2	Char	AN	Second allocation transient
2	Char	AP	Third allocation transient
2	Char	AQ	Terminal acquire
2	Char	AS	Assign command
2	Char	ΑT	Second assign
2	Char	ΑU	Second assign transient
2	Char	AX	Second terminal acquire
2	Char	A1	Allocation control transient
2	Char	ВА	BSCA sense status-3270
2	Char	BC	BSCA cancel/stop invite
2	Char	BD	BSCA ERP clean-up
2	Char	BE	BSCA error recovery
2	Char	BF	BSCA FREEMAIN of invite buffer
2	Char	BL	BSCA error log to operator
2	Char	BP	BSCA purge/stop II transient
2	Char	BQ	BSCA stop II Q analysis
2	Char	B2	Minimum system transient 2
2	Char	B5	3736 status log
2	Char	В9	BSCA dump
2	Char	CA	Display user transient 3
2	Char	CG	Console message command
2	Char	CJ	System operator cancel
2	Char	CN	Terminal operator cancel
2	Char	CR	First main storage allocation transient
2	Char	CS	Second main storage allocation transient
2	Char	CT	Third main storage allocation transient
2	Char	C1-C6	Display commands
2	Char	C7	Display system by ID
2	Char	C8	Display terminal transient 2
2	Char	C9	Display user transient 2
2	Char	DA	DFF
2	Char	DK	DFF
2	Char	FL	File command processor
2	Char	F2	Second file command processor
2	Char	GA	Get attributes
2	Char	HF	CCP RPG II halt/syslog processor
2	Char	H1	Halt/syslog
2	Char	H2	Halt/syslog processor for TID-2
2	Char	KA-KB	Console management
2	Char	K2-K4	Console management
2	Char	K6	Console management
2	Char	K8 K9	Console management

# XREF TRANSIENT LIST (Continued)

Lng Dec	Form	Descripti	on
2	Char	L2-L4	Close
2	Char	MA	MLTA error handler
2	Char	MB	MLTA switched line disconnect
2	Char	MD-ME	MLTA error handler
2	Char	MF	Part of MLTA switched line disconnect
2	Char	MG	Command processor teleprocessing message routine
2	Char	MP	Ignore put to terminal in ERP
2	Char	MT	Start MLTA online test
2	Char	MZ	MLTA online test
2	Char	M9	MLTA dump
2	Cital	IVIS	WETA dump
2	Char	NM	Name command processor
2	Char	OF	Terminal sign-off
2	Char	OP	Open/close
2	Char	OR	Open/close return transient
2	Char	os	Open shared I/O
2	Char	ОТ	Tape pseudo open
2	Char	01	Open/close
2	Char	02-09	Open
2	Char	PC	Command processor first load
2	Char	PF	Command processor
2	Char	PG	MLTA purge I/O
2	Char	PK	Command processor console command validator
2	Char	PT	Command processor term command validator
2	Char	RE .	Resume command
2	Char	RF	Resume transient 2
	01		First of the second de
2	Char	RL	First release module
2	Char Char	RP RX	Teleprocessing error recovery routine
2		R1	Second release module
2	Char Char	R2	Program request routine 1
2	Char	n2	Program request routine 2
2	Char	R3	Program request routine 3
2	Char	R4	Program request routine 4
2	Char	R5	Program request routine 5
2	Char	R6	Program request routine 6
2	Char	R7	Program request routine 7
2	Char	R8	Program request routine 8
2	Char	SH	Shutdown command
2	Char	SK	MLTA, set all poll skip bits on
2	Char	so	Terminal sign on command processor
2	Char	SP	MLTA user stop polling
2	Char	SS	Suspend commands routine
2	Char	ST	Suspend command (Model 4)
2	Char	TB	Terminal allocation routine
2	Char	TD	First termination routine
2	Char	TE	Trace-to-disk command

# XREF TRANSIENT LIST (Continued)

Lng Dec	Form	Descripti	on
2	Char	TF	Termination files deallocation
2	Char	TN	Second termination routine
2	Char	TP	Termination polling restart 1
2	Char	TS	Online test command from console
2	Char	TW	Termination dump routine
2	Char	TY	Teleprocessing polling restart 2
2	Char	TZ	Online test commandXCTL/BSCA
2	Char	T2	MLTA online test op end
2	Char	UR	Unit record allocation transient
2	Char	VA	Vary command
2	Char	VB	Second vary command processor
2	Char	WC	Switched line message to system operator
2	Char	WD	Connect switched line
2	Char	WR	Translate error transient
2	Char	XA-XC	Model 4 console management
2	Char	XF-XG	Model 4 console management
2	Char	X1-X9	Model 4 console management
2	Char	YA	User first sign-on transient
2	Char	YB-YZ	User transients
2	Char	Y0-Y9	User transients
2	Char	Y\$	User transient
2	Char	Y@	User transient
2	Char	Υ#	End of ID list

#### XREF TRANSIENT LIST (Continued)

Lng Dec

Form Description

The following area is generated in the last 128 bytes of the second CCP transient area. The addresses contained within it are dependent on the MLTA and BSCA support being provided. These addresses are placed in DTFs during startup.

2	Bin	0000, reserved.
2	Addr	Address of \$\$BSMD if auto-response is supported.
		Hex 0000 if auto-response is not supported.
2	Addr	Address of \$\$BSMA if resident polling is supported.
		Hex 0000 if resident polling is not supported.
2	Addr	Address of \$\$BSMC if resident polling is supported.
		Hex 0000 if resident polling is not supported.
2	Addr	Address of \$\$MLRR-MLTA error recovery routine.
		If MLTA is supported this address must be here.
		If MLTA is not supported, this field contains hex 0000

2 Addr Address of MLTSPO—common area in \$\$MLDI. If MLTA is being supported this address must be here. If MLTA is not supported, this field contains hex 0000.

The following entries exist if MLTA is supported. Also only those devices being supported under MLTA have their support module addresses and IDs in the table.

1	Char	A ID for \$\$MLTM-1050 support
2	Addr	Address of \$\$MLTM
1	Char	B ID for \$\$MLTB-1050D support
2	Addr	Address of \$\$MLTB
1	Char	C ID for \$\$MLTC-2740/2740M2S(B) support
2	Addr	Address of \$\$MLTC
1	Char	D ID for \$\$MLTD-2740 support
2	Addr	Address of \$\$MLTD
1	Char	F ID for \$\$MLTF-2740D support
2	Addr	Address of \$\$MLTF
1	Char	G ID for \$\$MLTG-2740C/SYS7C support
2	Addr	Address of \$\$MLTG
1	Char	H ID for \$\$MLTH-2740DC/SYS7DC support
2	Addr	Address of \$\$MLTH
1	Char	I ID for \$\$MLTI-2740DT support
2	Addr	Address of \$\$MLTI
1	Char	L ID for \$\$MLTL-2740DTC support
2	Addr	Address of \$\$MLTL
1	Char	M ID for \$\$MLTM-2740(M2)SC(B)/SYS7SC support
2	Addr	Address of \$\$MLTM
1	Char	O ID for \$\$MLTO-2741 support

P ID for \$\$MLTP-2741D/CMSTD support

Address of \$\$MLTO

Address of \$\$MLTP

Hex 00 End of table indicator

2

1

2

Addr

Char

Addr Bin

# **CCP Execution Data Areas**

# CCP COMMUNICATION AREA - \$CCCOM

- Located at start of CCP program level.
- Length is 256 bytes (hex 100).

1	Disp		Lng			
	Hex	Label	Dec	Form	Description	



00-01	@CMWK	2	Addr	Communication management work area address
02-03	@KMWK	2	Addr	Console management work area address
04-05	@CPWK	2	Addr	Command processor work area address
06-07	@AMWK	2	Addr	Allocation work area address
08-09	@TMWK	2	Addr	Termination work area address

# Addresses of System Task Control Blocks (TCBs)

0A-0B	@СМТСВ	2	Addr	Address of communication management task control block (TCB)
0C-0D	@КМТСВ	2	Addr	Address of console management TCB; same as @CMTC
0E-0F	@ТМТСВ	2	Addr	Address of termination task TCB
10-11	СРТСВ	2	Addr	Address of command processor TCB

Disp Hex	Label	Lng Dec	Form	Descripti	ion	
System I	_evel Flags					
12	\$FLGA	1	Bits	Common	n flag byte:	
				Hex Value	Symbol	Meaning
				80 40	#DFFOK CPSOB1	DFF is supported CCP sign-on pass- word required
				20	CPSOB2	User sign-on password check-
				10	CPSHUT	ing is done System operator has requested
				08	CPSU	shutdown Initial entry to command
				04	#DSKFS	processor  Disk file sharing supported
				02 01	#MODL4 CPISNW	System/3 Model 4 CC4IS should not wait after post- ing communica- tion manager
13	\$FLGB	1	Bits	Second f	flag byte:	
				Hex Value	Symbol	Meaning
				80	#SUALL	Suspend all user tasks in effect
				40	#suint	Suspend initia- tion in effect
				20	#SUCMD	Suspend commands in effect
				10 08	#TDISK #TDOFF	Disk trace is on Trace-to-disk off is pending
				04	#TDERR	repertury  Permanent I/O  error occurred  while writing  trace to disk;  trace-to-disk  suppressed
				02	#CPCAN	Cancel CCP received
				01	#PUCNT	Program-use count maintained

Disp Hex	Label	Lng Dec	Form	Descripti	on	
14	\$FLGC	1	Bits	Third flag	g byte:	
				Hex Value	Symbol	Meaning
				80 40 20	#MTRAC #BTRAC #NPDEF	MLTA trace on BSCA trace on DFF in use by an NEP ECS supported
				10	#ECSUP	on Model 4
15	\$FLGD	1	Bits	Fourth fl	ag byte (rese	erved)
16	#MAXUS	1	Bin		n number of is CCP execu	user tasks allowed ution
17	#CURUS	1	Bin	Current r	number of us	er tasks
18	#LSTSZ	1	Bin	Size of fi	rst level tran	sient list
System C	onstants					
19-1A	X\$0000	2	Bin	Constant	XL2'0000'	
18	X\$0001	1	Bin	Constant Hex 00 0		Note 19-1B =
1C-1D	X\$0002	2	Bin	Constant	XL2'0002'	
1E-1F	X\$0004	2	Bin	Constant	XL2'0004'	
Common	Register Save	Areas				
20-21	\$CCARR	2	Addr	CCP com	mon ARR sa	ave area
22-23	\$CCXR1	2	Addr	CCP com	mon register	1 save area
24-25	\$CCXR2	2	Addr	CCP com	ımon register	2 save area
Addresses	s of Disk I/O	nterce	pt Points i	n CCP Dis	patcher	
26-27	CC@DID	2	Addr	Address of entry poi		isk IOS intercept
28-29	CC@DIW	2	Addr	Address of entry poi		lisk wait intercept

Disp Hex	Label	Lng Dec	Form	Description
Queue/L	ist Origin Add	iress Po	ointers	
2A-2B	@TALST	2	Addr	Address of first level transients disk address list
2C-2D	@CDORG	2	Addr	Address of the first contents directory entry (CDE)
2E-2F	@КМОТВ	2	Addr	Address of the first parameter list on the console output queue
30-31	@KMRTB	2	Addr	Address of first parameter list on the console input queue
32-33	@KMQPL	2	Addr	Address of console task parameter list
34-35	@SQB	2	Addr	Address of the first sector queue block
36-37	@Т∪ВQ	2	Addr	Address of the first terminal unit block
38-39	@R4QUE	2	Addr	Address of the first terminal unit block being held during never-ending-program allocation
3A-3B	@TUSTG	2	Addr	Address of the terminal unit block currently (or last) processed by the command processor
3C-3D	@TUPST	2	Addr	Address of the current terminal unit block being processed by allocation
3E-3F	@DFCT	2	Addr	Address of the first CCP short disk DTF
Addresse	es of CCP, ML	TA, an	d BSCA T	race Routines
40-41	@CTRAC	2	Addr	Address of CCP dummy trace routine, \$CC4TT or, if real trace is loaded, the address of the three, trace table, descriptor constants
42-43	@MTRAC	2	Addr	Address of CCP MLTA trace routine
44-45	@BTRAC	2	Addr	Address of CCP BSCA trace routine
46-47	@FSBFR	2	Addr	Address of first available file specification block
48-49	@TNT	2	Addr	Address of first terminal name table entry

	Disp Hex	Label	Lng Dec	Form	Description
	Buffer St	orage Allocat	ion Cor	ntrol Block	4
	4A-4B	@BUFA	2	Addr	Address of communication line buffer first free area descriptor
	4C-4D	#NBND	2	Addr	Two bytes of 0
	4E-4F	@LOBND	2	Addr	Address of start of communication line buffer
	50-51	#HIBND	2	Addr	Address of end of communication line buffer
	52-53	@GMS	2	Bin	Size of largest available segment in the communication buffer
	54-55	#TPBUF	2	Bin	Original size of communication buffer area —4
	User Prog	gram Area All	ocation	Control E	Block
	56-57	@UPA	2	Addr	Address of first free block of user program area; note leftmost addressing
	58-59		2	Addr	Used by GETMAIN/FREEMAIN
	5A-5B	@UABGN	2	Addr	Address of start of user program area
_	5C-5D	@UAEND	2	Addr	Address of end of user program area
	5E-5F	#UMAX	2	Bin	Size of largest currently free area in the user program area
	Console I	Buffer Contro	l Block		
	60-69	@KBCB	10	_	Console buffer control block

Lng

Disp

Disp Hex	Label	Lng Dec	Form	Description			
Dispatch	er Work Area					`	
6A	\$DPFLG	1	Bits	First disp	atcher cont	rol byte:	
				Hex Value	Symbol	Meaning	
				80	DPREG	Dispatcher is to store the ARR, XR1 and XR2 into the current save area in the current task control block when entered	
				40	DPDSP	Make the current task nondispatch- able upon entry to the dispatcher	
				10	DPFSMC	Current task is currently processing a function that must complete before any other task can run (with the exception of the communications task)	
				08	DPXSMC	Current task is exiting through the dispatcher to to allow processing of any interrupts that may have occurred while it was processing	
6В	\$DPFLH	1	Bits	Second d	ispatcher co	ontrol byte:	
				Hex Value	Symbol	Meaning	
				80	DPDSX	DSM supervisor has been entered by some task (the particular task has its TCBDSM bit = 1)	

	Disp Hex	Label	Lng Dec	Form	Description	on	
					Hex Value	Symbol	Meaning
•	6B (continue	d)			40	DPNTRC	CCP trace routine is not to put an entry into the trace table on the current entry to it (reset by trace upon each exit from it)
					20	DPPOST	CCP post routine (CC4PS) has not made a task dispatchable
					10	DPRIT	An interrupted user task exists that is to be resumed once all system tasks have completed processing
					08	DPSMC	Some task is cur- rently processing a must complete function (dispatch only that task or the communications task)
					04	DPHALT	Systems are generated with MINRES-NO only (dispatcher is halted awaiting interrupts to process)
					02	DPCI	A console inter- rupt exists that needs to be processed
•					01	DPINT	Current dispatcher entry is due to CCP program level IAR reset from the common interrupt handler (\$CC4IH) and an interrupted user task exists

Lng

Disp

Hex	Label	Dec	Form	Description
Task Co	ntrol Block D	ynamic	Addresses	
6C-6D	@CURTB	2	Addr	Address of current (or last) active task control block
6E-6F	@PUCNT	2	Addr	Address of program-use count table
70-71	@LUSTB	2	Addr	Address of last active user task control block
72-73	@RITCB	2	Addr	Address of interrupted user task control block to be resumed (if DPRIT = 1)
General	Work Area			
74-75	@PRL	2	Addr	Address of the communication task parameter list
76	#OPEND	1	Bin	Counter for teleprocessing op end interrupts
77	#TT#IC	1	Bin	Number of console interrupts since last 01 trace entry (indeterminate if trace not in use)
78	#TT#IM	1	Bin	Number of MLTA interrupts since last 01 trace entry (indeterminate if trace not in use)
79	#ТТ#ІВ	1	Bin	Number of BSCA interrupts since last 01 trace entry (indeterminate if trace not in use)
7A-7B	@PCA	2	Addr	Address of CCP program level communication area
7C-7D	@PTX	2	Addr	Address of program characteristics table master index
7E-7F	@PTXCS	2	C/S	Disk C/S address of origin of program control table portion of \$CCPFILE
80-81	@CC4WT	2	Addr	Entry point of wait routine (\$CC4WT)
82-83	@DMP	2	Addr	Entry point of DSM dump routine
84-85	@IOS	2	Addr	Address of DSM disk I/O supervisor entry point
86-87	@IOW	2	Addr	Address of DSM disk I/O wait entry point

Disp Hex	Label	Lng Dec	Form	Description	on.	
88-89	@CPDTF	2	Addr			olic disk file table
				(XDI)		
8A-8B	#CCMCL	2	Bin	Maximum	command	ength
8C		1	-	Reserved		
Unit Rec	ord Allocation	n/Usage	Bytes			
8D	\$DV\$UP	1	Bit	Unit reco	rd support:	
				Hex Value	Symbol	Meaning
				08	\$DVN41	Directly attached 3741 indicator
				04	\$DVPRT	Printer supported
				02 01	\$DVMFU \$DV142	MFCU supported 1442 supported
				U (	<b>40 V 142</b>	1442 supported
8E	\$DVALC	1	Bit	Unit reco	rd allocation	ո:
				Hex		
				Value	Symbol	Meaning
				08	\$DVN41	Directly attached 3741 indicator
				04	\$DVPRT	Printer allocated to CCP
				02	\$DVMFU	MFCU allocated
				01	\$DV142	to CCP 1442 allocated to CCP
8F	\$DVPST	1	Bit	User prog	ram unit re	cord allocation:
				Hex		
				Value	Symbol	Meaning
				08	\$DVN41	Directly attached 3741 indicator
				04	\$DVPRT	User program awaiting alloca-
				02	\$DVMFU	tion of printer User program awaiting alloca- tion of MFCU
				01	\$DV142	User program awaiting alloca- tion of 1442

Disp Hex	Label	Lng Dec	Form	Description				
Password	I Save Area							
90	CPLPWD	1	Bin	Length of sign-on password				
91-96	CPPSWD	6	Char	Terminal sign-on password (right- adjusted padded with blanks)				
Disk Addresses of DSM Data Management Routines								
97-98	@CLRP	2	C/S	Disk C/S address of DSM printer error recovery procedure (ERP) routine				
99-9A	@CLPRT	2	C/S	Disk C/S address of DSM 5213 DM module on Model 4				
(99-9A)	@CLE1	2	C/S	Disk C/S address of DSM MFCU ERP routine				
9B-9C	@CLER	2	C/S	Disk C/S address of DSM 1442 ERP routine				
9D-9E	@ODLM	2	C/S	Disk C/S address of DSM 5444 limits processor				
9F-A0	@ODLT	2	C/S	Disk C/S address of DSM 5445 limits processor				
User Pro	gram Dump A	rea Int	ormation					
A1-A2	@CSTRT	2	C/S	Disk C/S address of dump area in \$CCPFILE				
А3	#NSEC	1	Bin	Number of sectors ¬1 to dump all of storage				
A4	#MXDMP	1	Bin	Maximum number of dumps that can be taken				
A5	#CPFLQ	1	Bin	Q byte of \$CCPFILE disk unit				
A6	#DUMP#	1	Bin	Number of dumps that were taken				
Α7		1	-	Reserved				
A8	#RUFCL	1	Bin	Maximum program request under format command length				

	Disp Hex	Label	Lng Dec	Form	Description	1	
	Miscellan	eous Pointers					
	A9	#ніѕтт	1	Bin	Number of table	entries in	switched terminal
	AA-AB	@COIH	2	Addr	Address of handler (\$@		ole interrupt
	AC-AD	@TAS	2	Addr	Address of	terminal a	ttribute set table
	AE-AF	@UALFA	2	Addr			area (not changed storage allocation)
	во	#HITAS	1	Bin	Highest teri system	minal attri	bute set index in
	B1-B2	#DFEND	2	Addr	Address of	end -1 of	\$CC4DF
	B3-B4	#DFBEG	2	Addr	Address of	beginning	of \$CC4DF
	B5-B6	@CSSTT	2	C/S	Disk addres	s of switch	hed terminal table
· I	B7-B8	@LCB#1	2	Addr	Address of system	first line c	ontrol block in
	в9-ва	@MLTAD	2	Addr			apter DTF; hex .TA adapter
	вв-вс	@CKLST	2	Addr	Address of	teleproces	sing checklist
	BD	#PCTLN	1	Bin	Length of I \$CCPFILE		gle PCT entry in
	BE	#SETID	1	Char	Assignment	t set ID use	ed in current run
	Expansion	n Area					
					Hex Value S	Symbol	Meaning
	BF	#TIMEX	1	Bit	80 7	TXOPND	Op end since last polling
	C1-C2	@DUB0	_	-	C/S of tran	sient \$\$Dl	JB0
	C3-C4	@DUB1	_	-	C/S of tran	sient \$\$Dl	JB1

Page of SY21-0048-1 - Issued 30 June 1978 - By TNL: SN21-7972

# CCP COMMUNICATION AREA - (\$CCCOM) (Continued)

1-80

					,					
	Disp Hex	Label	Lng Dec	Form	Description	on				
	Expansion	n Area (Conti	nued)							
	C5	\$MVFLG	-	-	Movemen	t flag byte				
					Hex Value	Symbol	Meaning			
					Bit 0	\$MVOUT	1-DFF/#3 loaded in PL1			
					Bit 1	\$HLDAR	1-OHA allocated			
١					Bit 2	\$MVPRT	in UPA 1-BSYPRT-YES			
	C6	#PLWK1	1	Bin	DFF parameter list work area					
	C7	#PLWK2	1	Bin	DFF parameter list work area					
	C8	#PLWK3	1	Bin	DFF parameter list work area					
	C9	#PLWK4	1	Bin	DFF parameter list work area					
	CA-CB	MVREAL	2	Bin	Logical to real conversion factor					
	CC-DB	IIPL	16	Mix	Invite input parameter list for 3284/3286/ 3288					
	DC-E8	-	13	-	Reserved					
	Display F	ormatting Fa	cility V	Vork Area						
	E9-EA	@DFFIX	2	C/S	Disk C/S	address of [	OFF formats index			
	ЕВ	#DFQ	1	Bit	Device Q	byte for Di	F display formats			
	EC-ED	#DF1@	2	Addr	Address of BSCA line		out hold area for			
	EE-EF	#DF1LN	2	Bin	Length of BSCA line		ut hold area for			
	F0	#DF1ID	1	Char			ing space in DFF BSCA line 1			
	F1-F2	#DF2	2	Addr	Address of BSCA line		out hold area for			
	F3-F4	#DF2LN	2	Bin	Length of BSCA lin		ut hold area for			
	F5	#DF2ID	1	Char			ing space in DFF BSCA line 2			
	1 00									

FE-FF #DFLOD 2 Addr

Disp Hex	Lng Label Dec Form Description		Form	Description
TIEX	Laber	Dec	1 01111	Beschpton
Display	Format Facili	ty Load	d Paramete	er List
F6-F7	#DFCS	2	C/S	Disk C/S address of DFF load module
F8	#DF#s	1	Bin	Number of sectors of text data
F9-FA	#DFLNK	2	Addr	Link-edited address of DFF module
FB	#DFRLD	1	Disp	Displacement of RLD data in last text sector
FC-FD	#DFENT	2	Addr	Entry point address of DFF module

Load point of DFF module if loaded;

otherwise, hex 00XX

#### TASK CONTROL BLOCK (TCB)

- There is one TCB for each system task (communication, termination, command processor) pointed to by \$CCCOM at hex 0A, 0E, and 10.
- There is one TCB for each user task (maximum = 8; maximum = 4 for Model 4), the first is pointed to by \$CCCOM at hex 70, and the rest are chained in the TCB at hex 0B.

Disp Hex	Label	Lng Dec	Form	Descrip	Description					
00	TCBTSK	1	Bit	Task ma	nagement co	entrol byte:				
				Hex Value	Symbol	Meaning				
				80	TCBATV	Active indicator; task is executable if TCBDSP = 1; otherwise, sus- pended by system operator (user task only).				
				40	TCBDSP	Dispatchable indicator				
				20	TCBRSM	Task suspended indicator (applies only if TCBATV = 0); task was suspended while in the interrupted state (user task only).				
				10	TCBSYT	System task indicator; other- wise, user task				
				08	TCBDSM	Task use of disk systems manage- ment. Task is current owner of DSM in this program level.				
				04	TCBDSV	Register save indictor. Registers save area address in Toto be decreased when task is dispatched.				
				02	TCBRUN	Task control block use (user TCB on Task control bloc is in use by user				
				01	тсвкао	program. System operator re				

quest bit (user TCB only). User task requested by CCP system operator.

Disp Hex	Label	Lng Dec	Form	Description			
01	TCBID	1	Char	Task ide	ntification b	yte:	
				C T P S User n is ti	Command Shutdown tasks: A sin	n task processor task task gle digit (1-n) whe f tasks allowed in	
02-03	TCBWMK	2	Bit	Task wai Byte 1:	it mask		
				Hex Value	Symbol	Meaning	
				80	WPAAII	(Communication task) Waiting for I/O service request (Any other task Waiting for con munications task to service an I/O request	
				40	WPADIO	Task is waiting for disk I/O completion	
				20	WPACP	Task is waiting for completion of an accept input from an I/O service request	
				10	WPASHD	Task is waiting for shutdown to be requested	
				08	WPATA	(Noncommunica tions tasks only Waiting for CCI transient area t become availab	
				04	WPASQB	(User task only) Task is waiting for enqueued data sectors	
				02	WPABSY	(User task only) Printer busy	

Reserved

Bit 7

TASK CONTROL BLOCK (TCB) (Continued)							
Disp Hex	Label	Lng Dec	Form	Descripti	on		
			Bit	Byte 2:		_	
				Hex Value	Symbol	Meaning	
02-03 (continue	ed)			80	WPBFR	(Communications task) Waiting for storage availability in communications buffer area (Any other task) Waiting for main storage availability in user program area (User task in allocation) Waiting for storage availability in user program area	
				40	WPBDA	(User task in allocation) Waiting for disk file(s) availability	
				20	WPBUR	(User task in allocation) Wait- ing for unit record device(s) availability	
				10	WPBTUB	(User task in allocation) Waiting for required terminal(s) availability	
				80	WPBDSX	(All tasks) Task is waiting for the availability of DSM	
				04	WPBTIO	(User task only) Task waiting for unit record device ready	
				02	WPBOHA	(User task using DFF only) Waiting for space in DFF output	

hold area

	Disp	Labal	Lng	E	Description
	Hex	Label	Dec	Form	Description  Note: The termination task does not
					use these wait mask definitions when waiting for work. Its wait mask is hex BFFF and its count is 255. Termination is made dispatchable by a direct setting of TCBDSP by an invoker.
	04	TCBECT	1	Bin	Task event count (the number of unique events that must occur prior to the task being marked dispatchable)
	05-06	ТСВРМК	2	Bit	Task post mask (This byte is set by post to indicate the type of event completed. The bit definitions are the same as TCBWMK, the task wait mask byte.)
	07	TCBRCT	1	Bin	Residual event count (This count is decreased by 1 for each unique event completion. The task is made dispatchable when this value becomes 0.)
	08	TCBFLG	1	Bit	Save byte for \$DPFLG when the task loses control or given control to the CCP dispatcher (the bit definitions for this byte are the same as those in \$DPFLG in \$CCCOM, CCP communications area)
	09-0A	ТСВІОВ	2	Addr	The address of the disk input/output block being waited for (IOB)
_	0B-0C	TCBNXT	2	Addr	The address of the next task control block for the dispatcher (TCB)
	0D-0E	TCBIAR	2	Addr	Instruction address register save area for an interrupted user task
	0F-10	TCBSPR	2	Bits	Program status register save area
	11-12	TCBSAV	2	Addr	The address of the register save area for the current level of control for this task (initially contains the address of high- order byte of TCBARR-8)
	13-14	TCBARR	2	Addr	Level 1 address recall register save area
	15-16	TCBXR1	2	Addr	Level 1 index register 1 save area
	17-18	TCBXR2	2	Addr	Level 1 index register 2 save area
	19-1A	-	2	Addr	Level 2 address recall register save area
	1B-1C		2	Addr	Level 2 index register 1 save area

Disp Hex	Label	Lng Dec	Form	Description
1D-1E	-	2	Addr	Level 2 index register 2 save area
1F-20	_	2	Addr	Level 3 address recall register save area
21-22	_	2	Addr	Level 3 index register 1 save area
23-24	-	2	Addr	Level 3 index register 2 save area
25-26	_	2	Addr	Level 4 address recall register save area
27-28	-	2	Addr	Level 4 index register 1 save area
29-2A		2	Addr	Level 4 index register 2 save area
The follo	wing apply to	Model	s 8, 10, an	d 12 only.
2B-2C	-	2	Addr	Level 5 address recall register save area
2D-2E	_	2	Addr	Level 5 index register 1 save area
2F-30	_	2	Addr	Level 5 index register 2 save area
31-32,	-	2	Addr	Level 6 address recall register save area
33-34	-	2	Addr	Level 6 XR1 save area
35-36	_	2	Addr	Level 6 XR2 save area
37-38	-	2	Addr	Level 7 address recall register save area
39-3A	-	2	Addr	Level 7 XR1 save area
3B-3C	-	2	Addr	Level 7 XR2 save area
BD-BE	-	2	Addr	Level 8 address recall register save area
3F-40	_	2	Addr	Level 8 XR1 save area
41-42	-	2	Addr	Level 8 XR2 save area
43	TCBSYS	nn	-	End of system TCB

Reserved

44

	Disp Hex	Label	Lng Dec	Form	Descripti	on	
	Task Con	trol Block Us	er Area				
	45-46	ТСВТ∪В	2	Addr		of the first to located to the	erminal unit block nis task
	47-48	TCBINQ	2	Addr	(this field	l addresses t k queued fo	s TUB input queue he oldest terminal r input to be
	49	TCBIIC	1	Bin			ocessing invite tanding for this
	<b>4</b> A	TCBMAX	1	Bin	of termin terminal under the	als that the support pro	maximum number multiple requesting gram running this TCB can
	4B	TCBATR	1	Bin	(User task only) The number of terminals currently active for the multiple requesting terminal support program running under the control of this TCB		
	4C-4D	TCBDTF	2	Addr		of the first o ser program	pen nondisk DTF
	4E	TCBFBM	1	Bit	Task con	trol block fi	le bit mask
	4F	TCBDMG	1	Bit	Data mar	agement co	ntrol byte:
					Hex Value	Symbol	Meaning
					80	тсвѕно	Shutdown requested return code was given to the user pro- gram on an accept input operation
					40	TCBACC	Program issued an accept input
					20	TCBRUF	PRUF program
•					10	TCBNEP	Program running under this task control block is never-ending

Disp Hex	Label	Lng Dec	Form	Descript	tion		
				Hex		4	
				Value	Symbol	Meaning	
4F (continu	ued)			08 04	TCBIT4 TCBMTS	User is a sort The user program is a multiple requester terminal program	
				02	TCBDA	Disk files are allocated	
				01	TCBOCF	Close is purging buffers	
50	тсвјов	1	Bit	Job mar	nagement cor	ntrol byte:	_
				Hex Value	Symbol	Meaning	
				80	TCBALC	Task is the alloca- tion task	
				40	TCBTRM	Task is in termina- tion or has been marked for termination	
				20	TCBCAN	Cancel requested by CCP	
				10	TCBCON	Cancel requested by CCP operator	
				08	TCBN41	Directly attached 3741 allocated	
				04	TCBPRT	Printer is allocated to this task	
				02	TCBMFU	MFCU is allocated to this task	
				01	TCB142	1442 is allocated to this task	
51	TCBCMP	1	Bin	Task co	mpletion co	de	
52-53	TCBCDE	2	Addr	Address	s of CDE for	this program	
54-55	TCBDFF	2	Addr	DFF PA	AS address		
56	TCBWRK	1	Bit	CCP wo	ork byte:		
				Hex Value	Symbol	Meaning	
				80	TCBMAP	Map ATRs to moveout area	
57-58	TCBPL@	2	Addr	Addres	s of saved pu	t parameter list	

#### COMMAND PROCESSOR WORK AREA

- Located hex 500 into CCP program level.
- Pointed to by \$CCCOM disp hex 04.
- Length is 60 bytes (hex 3C).
- Contains message output area

Disp Hex	Label	Lng Dec	Form	Descrip	tion	
00	\$CPFLG	1	Bit	Comma	nd processo	r (CP) flag byte:
				Hex Value	Symbol	Meaning
				80	\$CPFR	CP return transien does FREEMAIN following process ing routine return
				60	\$CPPC	CP return routine does put no-wait and invite input after subroutine return; data to write is in \$CPMSG area. NEP allocation is pending.
				40	\$CPII	Invite input is scheduled by return routine.
				20	\$CPPUT	CP return routine does put no-wait after subroutine return; data is in \$CPMSG area.
				08	\$CPR4H	\$CC4R4 request hold queue contains entries for validation.
				04	\$CPUCT	CP return routine counts this program request.
01-02	\$CPLMG	2	Bin	Length	of message t	o write
03-3В	\$CPMSG	57	-	output area is N is the m also use	to terminals. INN message	

# ALLOCATION WORK AREA

- Located hex 53C into CCP program level.
- Pointed to by \$CCCOM at hex 06.
- Length is 40 bytes (hex 28).

Disp Hex	Label	Lng Dec	Form	Descript	Description				
00-01	\$AMEPA	2	Addr		Entry point address of allocation mainline \$CC4AM				
02	\$AMFLG	1	Bit	Allocation flag byte:					
				Hex Value	Symbol	Meaning			
				80 40	\$AMBSY \$APEND	Allocation busy Allocation task post pending			
				20	\$AMDFF				
				10	\$AMDPL	Runalone program in allocation			
03-05	\$AMNCS	3	_	Reserved	i				
06-08	\$AMWMK	3	Bit	Wait mask set by allocation transients for resident allocate to use as a wait argument. Used to route control between allocation transients					
09-0A	\$AMPCT	2	Addr	Address	of PCT curr	ently in allocation			
0В	\$AM#LT	1	Bin	released		s to be deallocated/ ting allocation that lable			
OC	\$AM#DA	1	Bin	deallocat	Number of direct access files to be deallocated prior to posting allocation that all files are available				
0D-0E	\$AMTCB	2	Addr	Address	of current a	llocation TCB			
0F-10	\$AMPMK	2	Bit	Allocatio	on post masi	k			

# **TERMINATION WORK AREA**

- Located hex 564 into CCP program level.
- Pointed to by \$CCCOM at hex 08.
- Length is 40 bytes (hex 28).

Disp Hex	Label	Lng Dec	Form	Descrip	tion				
00	\$TMFLG	1	Bits	Termina	Terminator flag byte:				
				Hex					
				Value	Symbol	Meaning			
				80	\$TMBSY	Termination task active			
				40	\$TMDMP	Dump taken during current termination processing			
				20	\$TMEJ	\$CC4TD, the termination control routine, has invoked \$CC4EJ (CCP end of job)			
01-02	\$TMTCB	2	Addr	Address of TCB currently (or last) being processed by the termination task					

Reserved

24 -

03-27

#### COMMUNICATION MANAGEMENT WORK AREA

- Located hex 58C into CCP program level.
- Pointed to by \$CCCOM at hex 00.
- Length is 30 bytes (hex 14).
- Labels with command displacements indicate bytes shared by more than one function.

Disp Hex	Label	Lng Dec	Form	Description			
00-01	#CMDTF	2	Addr	Save area for DTF address			
02-03	#CMPL	2	Addr	Save area for parameter list address			
04-05	#CMTMA	2	Addr	Save area for terminal address			
(04-05)	#CMBK1	2	Addr	Save area for BSCA operator error identification			
06	#CMTFT	1	Bit	Save area for terminal features			
(06)	#CMBK2	1	Bit	Message format indicator:			
				Hex Value Meaning			
				04 BSCA message 2 (invalid OLT) 02 BSCA message 1 (POLLLOOP)			
				01 BSCA message 0 (error log)			
07-08	#CMPTR	2	Addr	Save area for previous pointer			
09-0A	#CMFPL	2	Addr	Save area for parameter list address			
0B-0C	#CMPTX	2	Addr	Save area for previous pointer			
0D-0E	#СМТИВ	2	Addr	Address of terminal unit block being used			
0F-10	#CMERP	2	Addr	Address of DTF to be rescheduled after return from ERP routine			
11	#cmswt	1	Bit	Control switch byte:			
				Hex Value Symbol Meaning			
				80 #CMARR Okay to modify TCBARR field in task control block			

# CONSOLE MANAGEMENT WORK AREA FOR MODELS 8, 10, AND 12

- Located hex 5A0 into CCP program level.
- Pointed to by \$CCCOM at hex 02.
- Length is 115 bytes (hex 73).
- Contains console input buffer.

Disp Hex	Label	Lng Dec	Form	Descrip	tion		
00	#KMSWT	1	Bit	Console	management	switch:	
				Hex Value	Symbol	Meaning	
				80 40	#KMBSY #KMERQ	Console is busy Enable request key	
				20	#KMPFX	Output prefix being printed	
				10	#KMSWL	Ignore next outp op end; there is no parameter li to dequeue	
				08	#KMXXE	Set on when a communication management transient transfers control to \$CC4K9 and wants a transfer of control to the transient whose C/S is in #KMXCT	
				04	#KMACT	with an exclar tion mark	
				02	#KMSCH	Output is from the transient a	
				01	#KMIOW	Do not let non- console CCP ru until all consol output comple	
01-0	2 #KMPL	2	Addr	Console	request parar	meter list	
(03)	#KMPFA	-	-	Beginni	ng of the outp	out prefix area	
(03)	#KMPFR	1	Char	Respon	se indication o	character	
04	#KMPFT	.1	Char	Task ide	entification ch	naracter	
05	#KMPFC	1	Char	Colon (	:)		
06-0	3 #KMPFP	6	Char	User pro	ogram name		

# CONSOLE MANAGEMENT WORK AREA FOR MODELS 8, 10, AND 12 (Continued)

•	•								
Disp Hex	Label	Lng Dec	Form	Description	on				
Console IOB Work Area for Models 8, 10, and 12									
ос	#KMQ	1	Bin	Input/out	put block C	byte			
0D	#кмв	1	Bin	Input/out	put block R	byte			
0E-0F	#KMSNS	2	Bit	Input/out	put block se	ense bytes			
10-11	#KMBUF	2	Addr	Buffer ad	dress				
12	#KMCTL	1	Bin	Control c	ount				
13	#KMFLG	1	Bit	Flag byte					
14	#KMCNT.	1	Bin	Running	count				
15	#KMCON	1	Char	Continue	character				
Data Fields Passed to the Console Manager to Handle Console Requests from \$CC4CM Transients									
16-17	#KMCPL	2	Addr		of information	on needed to be printed			
18-19	#кмхст	2	C/S	C/S of the transient to transfer control to after printing a message if $\#\text{KMXXE}$ of $\#\text{KMSWT}$ is on					
1A	#MKDSP	1	Bin	Console management dispatcher byte (if nonzero the console controller [\$CC4KA] is in control of the CCP system)					
18	#KMFFF	1	Bit	Second c	onsole mana	gement switch:			
				Hex Value	Symbol	Meaning			
				80	#KMHLT	Secondary halt to be issued by MFCU error recovery module			
Console Input Buffer									

1C-6E #KMBFL 82 Char Console input buffer

### **CONSOLE MANAGEMENT WORK AREA FOR MODEL 4**

- Located at hex 0500 into CCP program level.
- Pointed to by \$CCCOM at hex 02-03.

Disp Hex	Label	Lng Dec	Form	Descripti	on	
00	#KMSWT	1	Bit	Console r	management	switch:
				Hex		
				Value	Symbol	Meaning
				80	#KMBSY	Console is busy
				40	#KMERQ	Enable request key
				20	#KMPFX	Output prefix being printed
				10	#KMSWL	Swallow next output op end (no parameter list to dequeue)
				80	#KMXXE	Transfer control to \$CC4K9
				04	#KMACT	Prefix message with exclamation
				02	#KMSCH	Output is from transient ARPA
				01	#KMIOW	CCP must await completion of all console output
01-02	#KMPL	2	Addr	Address	of console re	quest parameter list
03	#KMSW2	1	Bit	Keyboard	d switch:	
				Hex Value	Symbol	Meaning
				80 40	#KMWAT #KMSTP	Wait on disk IOB Stop display backward
				20	#KMENK	Enable keyboard after op end on console
				10	#KMCMF	Display first line after D command
					#KMCMN	Display current command
				Bit 4	Reserved	_
				04	#KMSMG	Issue start of log message
				02	#KMTHR	Next console log printer went past current screen end point


# CONSOLE MANAGEMENT WORK AREA FOR MODEL 4 (Continued)

Disp Hex	Label	Lng Dec	Form	Descript	ion					
				Hex Value	Symbol	Meaning				
03 (continu	ed)			01	#кміто	Next console log printer went past current screen start point				
04	#KMSW3	1	Bit	Keyboar	d switch:					
				Hex Value	Symbol	Meaning				
				80	#KMSHD	Shutdown console				
05-06	#KMFST	2	C/S	C/S of st	tart of conso	le log file				
07-08	#KMFED	2	C/S	C/S of e	nd of console	e log file				
09-0B	#KMFSS	3	C/S/D	C/S/D o	f start of cur	rent screen				
0C-0E	#KMFSE	3	C/S/D	C/S/D o	C/S/D of end of current screen					
0F-11	#KMFD1	3	C/S/D	C/S/D o	C/S/D of line 1 of display command					
12-15	#KMFNX	4	C/S/DD	C/S/DD	of next cons	ole log entry				
16-17	#KMCPL	2	Addr		of informations	on needed to handle nted				
18-19	#KMXCT	2	C/S		message (if =	ass control to after = 0, do not transfer				
1A	#KMDSP	1	Bin	If nonze	ro, KM is in	control of system				
1B	#KMFFF	1	Bit	Console	management	switch:				
				Hex Value	Symbol	Meaning				
				80	#KMHLT					
				40	#кмсмс	syslog request CM transient must wait for console output completion				
1C-1D	#кмвои	2	Addr	Address	of console fi	le output buffer				

### CONSOLE MANAGEMENT WORK AREA FOR MODEL 4 (Continued)

	CONSOL	.E MANAGE	VIENT	WURK AF	EA FUR	MODEL 4 (C	ontinuea)				
	Disp Hex	Label	Lng Dec	Form	Descript	ion					
	1E-1F	#KMBIN	2	Addr	Address	of console fil	e input buffer				
	20-21	#KMBSO	2	Addr	Address	of console sc	reen output buffer				
	22-39	#кміов	23	Mix	Console	Console log file IOB					
	3A-4A	#KMDPL	16	Mix	Console	parameter lis	t				
	4B	#KMLIT	1	Bit	Console field indicator light mask:						
					Hex Value	Symbol	Meaning				
					80 40 20 10 08 04 02	#KMLT1 #KMLT2 #KMLT3 #KMLT4 #KMLT5 #KMLT6 #KMLT7	CCP incrementing light indicators not used Reserved User task awaiting reply Console screen in ERP Page backward in console log file available Page forward in console log file available available				
	4C-4D 4E-4F 50-51	#KMWK1 #KMWK2 #KMWK3	2 2 2	Mix	Internal routines	work areas fo	or console support				
l	52-53	#KMWK4	2 )								
	54-5B	#KMMPL	8		Move rou	utine parame	ter list:				
١				Bin Addr Bin Addr	56-57 58-59	5 To field len 7 To field add 9 From field 13 From field	dress address				
	5C-AC	#KMBFR	80	Char	Console	input buffer					
	00AD- 02AC 01AD-	#кмоит	512								
,	04AC 02CD-	#KMIN	768	<b>-</b>	See Cons	sole Buffer L	ayout.				
	02CD- 04AC	#KMSCR	480								

#### Console Buffer Layout



Hex 0000-0200 is output buffer Hex 0100-0400 is input buffer Hex 021F-0400 is screen buffer

# FILE SPECIFICATION BLOCK (FSB)

- Pointer to first FSB associated with a given terminal in TUB at hex 22.
- Pointer to first available FSB in \$CCCOM at hex 46.

Disp Hex	Label	Lng Dec	Form	Description
00	FSBSYM	1	Bin	Relative XDT entry
01	FSBPHY	1	Bin	Relative SDF entry
02-03	FSBNXT	2	Addr	Address of the next file specification block in the chain (hex 00xx is last)

# CONSOLE IOB FOR MODELS 8, 10, AND 12

- Located in DSM supervisor module \$@COIH at hex 26.
- Length is 14 bytes (hex 0E).

Disp Hex	Label	Lng Dec	Form	Descrip	tion	
00	CIOQ	1	Bin	Console	Q-byte:	
				Hex Value	Symbol	Meaning
				10 08	KEYBRD PRINTR	Keyboard Q code Printer Q code
01	CIOR	1	Bit	Console Printer	R byte:	
				Hex Value	Symbol	Meaning
				80 40	PRINT NEWLIN	Print a character Return the carriag
				04	NABLED	Printer enabled
				Keyboa	rd	
				Hex		
				Value	Symbol	Meaning
				20	REQLIT	Request light off
				10	PROLIT	Proceed light off
				04	REQKEY	Request key enabled
				02	OTRKEY	Other keys enable
				Printer :	and keyboard	ı
				Hex		
				Value	Symbol	Meaning
				01	RESET	Reset interrupt

00

level

DISABL Disable the device

# CONSOLE IOB FOR MODELS 8, 10, AND 12 (Continued)

Disp Hex	Label	Lng Dec	Form	Descripti	ion	
02-03	CIOSNS	2	Bit	Console : Printer	sense byte:	
				Hex		
				Value	Symbol	Meaning
				20	SNSNOP	Nonprintable character
				80	SNSEOL	End of line
				04	SNSFRM	End of forms
				02	SNSXLT	Printer translator check
				01	SNSMLF	Printer
						malfunction
				Keyboar	d	
				Hex		
				Value	Symbol	Meaning
				40 20	SNSENC SNSCAN	End or cancel key Cancel key
				10	SNSEND	End key
				08	SNSRTD	Return or data key
				04	SNSRTN	Return key
				03	SNSKER	Keyboard errors
04-05	CIOBUF	2	Addr	Console	operation b	uffer address
06	CIOCTL	1	Bin	Console	control cou	nt
07	CIOFLG	1	Bit	Console	operation fl	ag byte:
				Hex		
				Value	Symbol	Meaning
				80	FLGIN	Input operation
				60	FLGWTR	•
				40	FLGOUT	with reply Output operation
				20	FLGSYS	System user
						indicator
				10	FLGRON	
				08	FLGCMP	Completion post bit
				04	FLGERR	•
				02	FLGEXT	Exact length input
				01	FLGNOP	Halt on nonprint-

ables

### CONSOLE IOB FOR MODELS 8, 10, AND 12 (Continued)

Disp Hex		Label	Lng Dec	Form	Description	on				
Cons	ole A	dditional Cel	ls							
80		CIOCNT	1	Bin	Count for	operation				
09-0	Α	CIODTF	2	Addr	DTF (parameter list) pointer					
ОВ		CIOINQ	1	Bin	Inquiry status byte					
ос		CIOSAV	1	Bin	Data management save area					
Cons	ole S	tatus Byte								
0D		CIOSTS	1	Bit	Input/output block (IOB) status byte:					
					Hex Value	Symbol	Meaning			
					80	STSNOW	Start operation; return;			
					40	STSCHK	On recall return; otherwise, wait			
					20	STSREN	Recall; otherwise,			
					10 08	STSASM STSFRM	Assembler user End of forms			

### **KEYBOARD IOB FOR MODEL 4**

Located in DSM supervisor module \$COIH at hex 04.

• Length is 12 bytes (hex 0C).

Disp Hex	Label	Lng Dec	Form	Descrip	tion	
01	CIOO	1	Bin	Keyboa	rd Q byte:	
				Hex Value	Symbol	Meaning

10

0F

STSHLT Halt identification

KEYBRD Keyboard Q-code

# KEYBOARD IOB FOR MODEL 4 (Continued)

Disp Hex	Label	Lng Dec	Form	Descript	tion	
01	CIOR	1	Bit	Keyboa	rd R byte:	
				Hex		
				Value	Symbol	Meaning
				10	RESPCK	Reset parity check
				80	LOCK	Lock keyboard
				04	UNLOCK	Unlock keyboard (lite keyb rdy)
				02	ENABLE	Enable keyboard interrupts
				01	RESET	Reset interrupt
						ievei
02	CIOSN1	1	Bin	Sense b		
					or key presse	
				Data ke	y translated t	to EBCDIC
				Hex		
				Value	Symbol	Meaning
				91	ENTERP	Enter plus key
				81	PROGST	Program start key
				80	ENDKEY	Input end indicator
				16	BACKSP	Backspace key
				15	RETURN	Return key
				11	INQREQ	Inquiry request
				05	TAB	Tab key
				03	ERASE	Field erase key
				02	ENTERM	Enter minus key
03	CIOSN2	1	Bit	Sense b	yte 2:	
				Hex		
				Value	Symbol	Meaning
				80	SNSPCK	Parity check
				40	SNSDAT	Data key
				20	SNSCOM	Command key
				10	SNSFUN	Function key
				80	SNSWTC	World Trade bit
				02	SNSTYP	Typamatic function
04	CIOCNT	1	Bin	Length	of input	
05	CIOCRT	1	Bin	Contro	count	

### **KEYBOARD IOB FOR MODEL 4 (Continued)**

_	Disp Hex	Label	Lng Dec	Form	Description	on	
	06	CIOFLG	1	Bit	Flag byte		
					Hex Value	Symbol	Meaning
					40	KBRDY	Keyboard is ready
_					80	NUMFLD	Numeric field
					02	DISPLY	Display mode (off blind key)
					01	MANMOD	Manual mode
	07	СІОСОМ	1	Bin	Completi	on code:	
					Hex		
					Value	Symbol	Meaning
					46	COMERR	Parity check error
					45	COMBUF	Buffer full
					44	COMNA	Not allowed (character in number field)
					40	COMOK	Normal (function or command key)

# DISK IOB

08-09

0A-0B

- Pointed to by disk I/O queue.
- Length is 26 bytes (hex 1A).

CIODUF

CIODTF

2

2

Addr

Addr

Disp Hex	Label	Lng Dec	Form	Description
00-01	IOBCHN	2	Addr	IOS queue chain pointer Address of next IOB in the queue of IOBs awaiting release of data sectors, hex 0000 if last IOB in queue (CCP file sharing system only)

Buffer address

DTF address

### **DISK IOB (Continued)**

Disp Hex	Label	Lng Dec	Form	Descript	ion		
02	IOBCMP	1	Bin	IOB con	npletion cod	e:	
				Hex Value	Symbol	Meaning	
				80 40	SKSTR1 CMPBIT	Seek started Operation complete	
				20	DTPND	Data transfer pending	
				10	DXFRST	Data transfer started	
				80	IOWAIT	A wait has been issued	
				05	IOERR	Permanent error on associated IOB	
				04 02	SCEQFN	Scan equal found	
				01	SCNTFN IOPERM	Scan not satisfied Permanent error	
03	IOBQB	1	Bin	Q-byte f	or SIO		
04	IOBRB	1	Bin	R-byte f	or SIO		
05	ЮВСВ	1	Bin	Cylinder	number (5	444 only)	
(05)	IOBFL2	1	Bin	Flag byt	e (5445 on)	y)	
06	IOBSB	1	Bin	Track ar	nd sector nu	mber (5444)	
07	IOBNB	1	Bin	Number	of sectors -	-1 (5444 only)	
(06-07)	IOBDAD	2	Addr	Pointer	to disk addr	ess (5445)	
08-09	IOBDAT	2	Addr	Data add	dress		
0A-0B	IOBSNS	2	Bit	Sense by	yte store are	a	
0C	IOBERR	1	Bin	Error re	try counts		
0D	IOBFLG	1	Bit	Flag bits	s:		
				Hex Value	Symbol	Meaning	
				08	NODTF	IOB has no associated DTF	
				04	NOLIO	No LIO of DFDR	
0E-0F	IOBARR	2	Addr	ARR sa	ve area		
10-11	IOBXR2	2	Addr	XR2 sav	/e area		

### DISK IOB (Continued)

	Disp Hex Label		Lng Dec Form		Description		
)	(10-11)	IOBTCB	2	Addr	Address of the TCB waiting for enqueued data sectors (CCP file sharing system only)		
	12-13	IOBDCH	2	Addr	Data management chain pointer		
_	14-15	IOBDTF	2	Addr	Address of associated DTF		
•	16	IOBCC	1	Bin	Cylinder address (5445 only)		
	17	ІОВНН	2	Bin	Head address (5445 only)		
	18	IOBR	1	Bin	Record address (5445 only)		
)	19	IOBN	1	Bin	Number of records -1 (5445 only)		

### BSCA LINE CONTROL BLOCK (LCB)

- Pointer to first LCB in \$CCCOM at hex B7.
- LCBs (MLTA and BSCA) are chained by address at hex 67 in LCBs.
- Contains line DTF, SDR tables, and polling list (if any).

Lng

- There is one LCB for each line.
- Length is 125 bytes (hex 7D).

Disp

1	Hex	Label	Dec	Form	Descripti	on		
	00	\$BDDEV	1	Bin	Device ID: Hex 88 for BSCA 2 Hex 80 for BSCA 1			
	01	\$BDUPS	1	Bit	UPSI: U1-U8			
)	02	\$BDATT	1	Bit	Attribute byte 1:			
•					Hex			
					Value	Symbol	Meaning	
					CO	\$BCCNV	Conversational file	
					80	\$BCINP	Input file	
,					40	\$BCOUT	Output file	
					20	\$BCITB	ITB mode	
					10	\$BCRAN	Transparent mode	
					80	\$BCGET	GET file	
					04	\$BCASK	On-ASCII file Off-EBCDIC file	
					01	\$BCASM	Assembler DTF	

Hex Label Dec Form Description  03 \$BDATR 1 Bits Attribute byte 2:  Hex				
****				
Value Symbol Meaning				
88 \$BCMCN Control sta	ition			
80 \$BCMPT Tributary s				
40 — DTF alloca				
20 \$BCMAN Manual line				
10 \$BCANS Answer line				
08 \$BCSWI Switched Ii	ine			
04 \$BCUSD File used 02 \$BCACT File active				
01 \$BCOPN File opened	d			
04-05 \$BDCHN 2 Addr Chaining pointer to postopen DT	Fs			
06-07 \$BDNXT 2 Addr Chaining pointer to next DTF, property or postopen	Chaining pointer to next DTF, preopen or postopen			
08-09 \$BDWK1 2 Mix Work area for MLMP routines				
0A-0B \$BDWK2 2 Mix Work area for MLMP routines				
OC-OD \$BDWKB 2 Addr Address of user's logical buffer	Address of user's logical buffer			
OE \$BDCMP 1 Bin Completion codes:				
Hex				
Value Symbol Meaning				
59 CPURGE Purge comp for CCP	plete			
58 \$BCRLE Maximum i length exc				
57 \$BCACD No active E				
56 \$BCCMP No comple in checkli				
55 \$BCADP Adapter ch				
54 \$BCRSP Invalid resp received	onse			
53 \$BCCON Lost conne	ction			
52 \$BCLOS Lost data o record sep found in i blocks	oarator			
51 \$BCDAT Data check	:			
50 \$BCTIM Na respons				
4F \$BCERR Permanent	error			

Disp Hex	Label	Lng Dec	Form	Description	on	
				Hex Value	Symbol	Meaning
0E				4E	\$BCLST	Delay count
(continue	ed)			7.2	<b>\$</b> B020.	(DLYCT in \$DTFB) exceeded
				4D	\$BCCAL	Invalid request
				4C	\$BCNCN	No connection
				4B	\$BCASC	Invalid ASCII character
				4A	\$BCIGN	Request ignored
				49	\$BCNAC	No active entry in polling list
				48	\$BCOLT	Invalid \$RFT (request for online test)
				47	\$BCNDT	No data for conversational GET (null message received)
				46	\$BCCRP	Conversational reply pending
				45	\$BCNON	No response to poll/address
				44	\$BCNEG	Negative response to poll/address
				43	\$BDBID	Invalid ID
				42	\$BCEOT	End of file
				41	\$BCUER	User error
				40	\$BCDNE	Normal completion
				00	\$BCREQ	Request accepted
0F	\$BDOPC	1	Bin	Operatio	n code:	
				Hex		
				Value	Symbol	Meaning
				81	\$BOGBK	GET a block
				80	\$BOGET	GET
				44	\$BOPEW	PUT EOT to WACK response
				42	\$BOPEF	PUT end of file
				41	\$BOPEB	PUT end of block
				40	\$BOPUT	PUT
10-11	\$BDMRL	2	Bin	Save area	for maxim	um record length
		2	Bin	RJE save	area	

Disp Hex	Label	Lng Dec	Form	Description				
12	\$BDLGC	1	_	BSC IOS:	BSC IOS:			
				Hex Value	Symbol	Meaning		
				80	ADSWID	Switched ID list is being used		
				10	EOBTWO	•		
				80	SPNRCL			
				04	MAXOFL	Truncate record indicator		
				02	POL1ST	First time poll resident indicator		
				01	ADARA1	First add on area included		
13-14	\$BDDCH	2	Addr	Address of line is bei	per if a switched			
(13-14)	\$BDPSC	2	Char	Polling/addressing characters if a tributary station is receiving data				
(13-14)	\$BDLST	2	Addr	Address of polling/addressing list if a control station is receiving data				
15	\$BDDCC	1	Bin	Length o		er if a switched		
(15)	\$BDIND	1	Char		ddressing lis tation is rec	st entry ID if a eiving data		
16-17	\$BDRID	2	Addr		neter list if a	O field or switched a switched line is		
(16-17)	\$BDCNT	2	Bin			go through a polling es are negative		
18	\$BDRLN	1	Bin	Length o	f receive ID	field or entry		
(18)	\$BDLID	1	Char		-	ing ID or last unction (hex F0		
19-1A	\$BDSID	2	Addr	Address	of send ID f	ield		
1B	\$BDSLN	1	<u> Ein</u>	Length o	f send ID fi	eld		

Disp Hex	Label	Lng Dec	Form	Description	on	
1C-1D	\$BDDLY	2	Bin	Delay cou	int (DLYCT	in \$DTFB)
1E-1F	\$BDREL	2	Bin	Record le	ngth	
20-21	\$BDBKL	2	Bin	Block len	gth	
22-23	\$BDIOB	2	Addr	Address o	of IOB in pro	ocess
24-25	\$BDBKX	2	Addr	Pointer to	data in BS	CA buffer
26-27	\$BDITB	2	Bin	ITB chara	cter count	
28-2A	\$BDPRM	3	_	Reserved		
2B-2D	\$BDRVI	3	Mix	displacem		ot request) mask and yte is mask; next s)
2E	\$BDNDX	1	Bin	Index for	line initiali:	zation
2F-30	\$BDWKA	2	Addr	Address o	of BSCA wo	rk area
31-32	\$BDINT	2	C/S	Disk addr	ess of line i	nitialization module
33	\$BDDED	1	Mix	Work area	a for MLMP	routines
34	\$BDAT1	1	Bit	Terminal	attribute by	rte:
				Hex Value	Symbol	Meaning
				40 10	\$BCPLR \$BCRES	Resident polling Restore after spanning
				08 04	\$BCPUT \$BCNOW	PUT span file Spanning in process
				02	\$BCSPN	Spanned records used
				01	\$BCSEP	Record separator used
35	\$BDSEP	1	Char	Record se	parator cha	racter
36-37	\$BDSBF	2	Addr	Save area	for user's lo	ogical buffer address
38-39	\$BDSRL	2	Bin	Save area	for record I	ength
3A-3B	\$BDRFT	2	Bin	Save area paramete		of online test

BSCA LINE CONTROL BLOCK (LCB) (Continued)										
Disp Hex	Label	Lng Dec	Form	Description	on					
3C-3D	\$BDTSA	2	Addr	Address o	f terminal s	statistics logging				
	owing are in t or retry count			orage reside	nt poiling,	auto response, or				
3E-3F	\$BDRL0	2	Addr	Storage re	Storage resident \$\$B\$L0					
40-41	\$BDRCL	2	Addr	Storage re	esident \$\$B	SCL				
42-43	\$BDARA	2	Addr	Auto resp	Auto response module \$\$BSMD					
44	\$BDERR	1	Bin	Retry cou	Retry count					
45-46	\$BDT1A	2	C/S	Save addr	Save address of online test cylinder/sector					
47-48		2	-	Reserved						
End of	DTF									
4C-4D	LCBPOL	2	Addr	Address o	f the pollin	ng list				
4E-4F	LCBSEL	2	Addr	Address o	of the select	ion list				
50	LCBID	1	Char	Identifica selected t		last polled/				
51-52	LCBPL@	2	Addr	Save area	for current	parameter list				
53-54	LCBWRK	2	Mix	Work area	a address fo	r subroutines				
55	LCBAT1	1	Bit	BSCA att	ribute byte	1:				
				Hex Value	Symbol	Meaning				
				80	LCBCRI	Cancel receive input, stop				
				40	LCBPRI	Cancel receive input, handle priority put				
				10	LCBINT	Interrupt with no parameter list is queued				
				08	LCBNTQ	Active parameter list has been removed from				

the queue

Disp

	Hex	Label	Dec	Form	Description	on	
					Hex Value	Symbol	Meaning
	55 (continue	ed)			04	LCBDEQ	end of text is
					02	LCBEOT	found Search for end of text
	56	LCBAT2	1	Bit	BSCA att	ribute byte	2:
_					Hex Value	Symbol	Meaning
					80	LCBTRC	Truncate the block, bump DTFBKX (a field in the DTF) to the end
					40	LCBSET	Send end of text on the line
					20	LCBACT	Line is active with work
					10	LCBRFT	Request for test started
					08	LCBABT	Abort the line connection
					04	LCBSEC	Second block indicator
					02	LCBPUT	Put pending on the line
					01	LCBRCI	Receive initial on the line
	57-58	LCBADJ	2	Bin	Adjusted	output leng	jth
	59-5A	LCBATL	2	Addr	Address	of ASCII tra	nslate buffer
	5B-5C	LCBOWN	2	Addr		trol block a	ddress of task of the line
	5D-5E	LCB\$LO	2	C/S	Disk addi transient	ress of line i	nitialization
	5F- <b>6</b> 0	LCBSRT	2	Addr	Start add	ress of the I	ine buffer area
	61-62	LCBBND	2	Addr	End addr	ess of the li	ne buffer area
	63-64	LCBKLC	2	Bin	Block len operation	-	current input

Disp Hex	Label	Lng Dec	Form	Descripti	on		
65-66	LCBPLQ	2	Addr		Address of the first parameter list in the line queue		
67-68	LCBCHN	2	Addr		Chain address of all line control blocks in the CCP system		
69	- •	1	_	Reserved			
6A	LCBELC	1	Disp	which tra	Displacement of the translate table, which translates from line code to EBCDIC.		
6B	-	1	-	Reserved			
6C	LCBOPE	1	Bin	Operation-end count for this BSCA line (BSCA only)			
6D	LCBLID	1	Char	Save area for last terminal ID			
6E	LCBLLE	1	Disp	Displacement of the translate table, which translates from line code to lowercase EBCDIC			
6F	LCBOLT	1	Bin		on this tele	ount (running and processing line	
(6F)	LCBAT3	1	Bit	BSCA at	tribute byte	3:	
				Hex Value	Symbol	Meaning	
				80	CLBITB	Intermediate text block (ITB) is supported for this DTF	
				40	LCBTSP	Transparency supported	
				20	LCBENB	BSCA line enabled (switched line)	
				10	LCBATO	Auto-call hardware	

is supported

Disp Hex	Label	Lng Dec	Form	Descrip	tion	
70	LCBATR	1	Bit	Line co	ntrol block a	ttribute byte:
				Hex Value	Symbol	Meaning
				80	LCBNIT	Had a successful initial operation on the line. (If a switched line is being used, this indicates that the line is connected.)
				40	LCBOLR	Online test currently running
				20	LCBGMN	GETMAIN needed
				10	LCBSTP	Abort has been issued to stop the read
				80	LCBSWL	Ignore input from the next operation
				04	LCB1PL	Next parameter list issued to this line should be put at the top of the line queue
				02	LCBTBK	Save the data from the read operation set for the 2741 to do the read initial when write is the first operation issued to the terminal (If both LCBSWL and LCBTBK are 1, ignore the next op end whether input
				0A	_	or output.) Ignore the next op

01

LCBAPP

input or output

Line control block allocation pending

Disp Hex	Label	Lng Dec	Form	Descripti	ion					
Second E	SCA Only Se	gment								
71-72	LCBBFL	2	Bin	Length of data area in line buffer						
73-74	LCBMCL	2	Bin	Maximur	Maximum command length					
75-76	LCBIBL	2	Bin	Length o	Length of current invite input buffer for this line					
77-78	LCBIBA	2	Addr	Address of invite input buffer (hex 00XX = no invite buffer)						
79-7A	LCBTCB	2	Addr	Address of TCB to which line is allocated (switched line)						
7B	LCBATC	1	Bin	Terminal unit block count (switched line)						
7C	LCBOPC	1	Bit	Last ope	ration code	on BSCA:				
				Hex Value	Symbol	Meaning				
				80	LCBMVD	Data moved indicator on				
				40	LCBERP	Line is in ERP mode (ignore the				
				20	LCBRVI	Reverse interrupt indicator Send/receive reverse interrupt				
				Bits 4-7	-	Save area for CCP operation code				
				02 01	OPPUT OPGET	Put operation Get operation				
7D-87	LCBADN	11	Mix		ection list (o					
(7D)	LCBADL	1	Bin		line selectio					
(7D-7E)	LCBMRL	2	Bin		nt area for m essage only)	nessage length				
(7F-80)	LCBMIL	2	Bin	Original message		ut length (GET				
(81-82)	LCBMR@	2	Bin	Original message	-	ord address (GET				

Hex	Label	Dec	Form	Description				
The following apply to BSCA auto-call switched lines only.								
(7D)	LCBTEL	1	-	Beginning of auto dial number				
(7D-8B)	LCBTLC	15	Char	Auto-dial telephone number				
(00)	STR#LN	1	_	Length of the STT entry				
(01-nn)	STTPHN	nn	_	Phone number (label refers to leftmost				

byte.)

### BSCA INPUT/OUTPUT BLOCK (IOB)

- 10B in process pointed to by LCB at hex 22.
- Length is 21 bytes (hex 15).

Disp

• First IOB in I/O area is pointed to by LCB at hex OC.

	Disp Hex	Label	Lng Dec	Form	Descr	iptio	on			
•	00-01	IOBNXT	2	Addr	Address of next IOB					
	02	IOBQ	1	Bin	SIO Q-byte of last op				era	ation:
					Hex Value Symi			Symbo	0/	Meaning
					BSCA Line					
					84 83 82	8C 8B 8A		DIALO RCVI TROP	ЭP	Auto-dial Receive initial Transmit and
)					81	89		RCVO		receive Receive only
	03-04	IOBDBL	2	Bin	Data i	buff	er le	ength		
	05	IOBFLA	1	Bit	Flag b	yte	:			
)					Hex Value		Syr	nbol	М	eaning
					80 40			QSNT /ACK	In	NQ has been sent valid ACK eceived
					20		TD	LAY	T١	vo-second imeout started
)		,			10		LS	ГВLК	In E	dicates last block for ITB and transparent nodes

### BSCA INPUT/OUTPUT BLOCK (IOB) (Continued)

Disp Hex	Label	Lng Dec	Form	Description					
				Hex Value	Symbol	Meaning			
05 (continue	od)			08	EXCL	Execute channel program			
10011111111	,			04	FIRST	Indicates first- time logic in current file			
				02 01	DELAY TXTSNT	Delay IOB bit Data has been sent from this buffer			
06	IOBLFG	1	Bit	Flag byte	9:				
				Hex Value	Symbol	Meaning			
				C0	CONV	Conversational file			
				80	INPUT	Input file			
				40	OUTP	Output file			
				20	ITBBIT	ITB mode			
				10	TRANSP	Transparent mode			
				80	GET	Primary receive file			
				04	ATTCOD	ASCII code			
				02	ATT78	Remote 2770 or 2780			
				01	ATTASM	Assembler user			
07	IOBCMP	1	Bin	IOB com	pletion cod	e:			
				Hex Value	Symbol	Meaning			
				88	ONLINE	IOB being trans- mitted			
				84	READY	IOB ready for transmit			
				80	PROC	IOB in process			
				55	CMPADP	Adapter check			
				54	CMPRSP	Invalid response from remote device			
				53	CMPCON				
				52	CMPLOS	Lost data			
				51	CMPDC	Data check			
				50	CMPTIM	No response from remote device			

### BSCA INPUT/OUTPUT BLOCK (IOB) (Continued)

Disp Hex	Label	Lng Dec	Form	Description	on	
				Hex		
				Value	Symbol	Meaning
07				4F	PRMER	Permanent error
(continue	d)			4E	LSTCNT	Delay count exceeded
				4D	INVCAL	Invalid request
				4C	NOCON	No connection
				4B	ASCERR	Invalid ASCII character
				4A	CMPIGN	Request ignored
				49	NOACTV	No active entry in poll/address list
				48	CMPOLT	Invalid request for test (RFT)
				47	NODATA	No data for conversational GET (null message received)
				46	CRPEND	Conversational reply pending
				45	NORSP	No response to poll/address
				44	NEGRES	Negative response to poll/address
				43	NONTRY	Invalid ID
				42	EOTRCV	End of file
				41	CMPUER	User error
				40	DONE	Normal
				40	DONE	completion
				00	OPACC	Request accepted
08-09	IOBDAT	2	Addr	Address o	of BSC data	buffer
0A-0B	IOBSNS	2	Bin	Sense are	a:	
				Hex		
				Value	Symbol	Meaning
(High-sto	rage byte)			02	DSR	Data set ready
	,			80	TIMOUT	Timeout error
				40	DATCHK	
				30	ADCHK	Adapter check, receive
				20	TADCHK	
				08	ASCII	Data contains invalid ASCII character
				06	LSTDIS	Lost connection or disconnect
				04	-	Abortive disconnect
				02	BSCABT	Disconnect timeout
				CCE	Evecution	Data Areas 1-117

### BSCA INPUT/OUTPUT BLOCK (IOB) (Continued)

Disp Hex	Label	Lng Dec	Form	Description
0C	IOBERR	1	Bin	Retry count
0D-0E	IOBCAR	2	Addr	IOB current address register save area
0F-10	IOBTAR	2	Addr	IOB transition address register save area
11-12	IOBSAR	2	Addr	IOB stop address register save area
13-14	IOBDTF	2	Addr	Address of associated DTF

### Receive Buffer

The following is a sample of a BSCA receive buffer:

IOB (21 bytes)	Acknowledgement to Preceding Block Received	S	Data	E T or X		E T B	One Byte Reserved
	Transmitted Before Receiving Data						

Note: Each buffer contains one block of data.

# Transmit Buffer

The following is a sample of a BSCA transmit buffer:

IOB (2° bytes)	STX	Data	E T X	or	Acknowledgement Received to Block Transmitted	One Byte Reserved	
					Received Subs		•

Note: Each buffer contains one block of data.

### **BSCA WORK AREA**

- Pointed to by LCB at hex 2F.
- · Preceded by eyecatcher WKA.
- Length is 179 bytes (hex B3).

Disp Hex	Label	Lng Dec	Form	Description
0-12	DLYIOB	19	Mix	BSC IOB used to send delay messages and termination sequences (DLYIOB includes WRKDTF)
13-14	WRKDTF	2	Addr	Address of the BSC DTF
15	BSRJF1	1	Bit	RJE indicator byte 1:
				Hex
				Value Symbol Meaning
				80 JF1RCI RJE RCVI going
				40 JF1TOS RJE Timeout before
				RCVI
				20 JF1ETR RJE RCV only before
				writing EOT  10 JF1SOH RJE Writing
				SOH-R-ETX
				08 JF1SHD RJE SOH-D sent
				04 JF1WRT RJE Writing EOT
				02 JF1ETS RJE EOT sent
				01 JF1SHR RJE SOH received
16	BSRJF2	1	Bit	RJE indicator byte 2:
				Hex
				Value Symbol Meaning
				80 JF2GET Last file was an RJE receive file
17	BSPOL1	1	Bit	Polling indicator byte:
				Hex
				Value Symbol Meaning
				80 PL1POL Polling being done
				40 PL1EOT Excessive record length data
				20 PL1ACT Active terminal in the list
				10 PL1RES Reset poll requested
				08 PL1PAD Off = addressing
				04 PL1CNC Cancel

Disp Hex	Label	Lng Dec	Form	Descript	tion					
				Hex Value	Symbol	Meaning				
17 (continu	ed)			02	PL1CIH	Common interrupt handler sup- ported by this module				
				01	PH1CHS	Common interrupt handler being used during this job				
18-19	WKLIST	2	Addr	Pointer	Pointer to the current polling entry					
1A	WKERRD	1	Bin	Error re	try count					
1B-1C	WKIOB@	2	Addr	Address of the last IOB						
1D	BSFLG3	1	Bit	Flag byte:						
				Hex Value	Symbol	Meaning				
				80 40 20	F3RVI F3SRVI F3OLTE F3HALT	RVI sent Sending RVI ERP disable for online test Error post to DTF				
				08 04	F3OLT F3MOVE	Online test Data moved				
				02 01	F3RFTA F3AUTO	Online test allowed				
1E	WKPCT	1	Bin	Count of the times through the polling list						
1F-20	@CC4BN	2	Addr	Address of common interrupt handler (Model 4)						
21-22	ADRIOB	2	Addr	Address of the delay IOB used by interrupt and data management to locate BSC work area						

	Disp Hex	Label	Lng Dec	Form	Description	on	
	23	BSCFLG	1	Bit	Flag byte	:	
					Hex Value	Symbol	Meaning
					80	WTRTN	Signals wait to re- turn via ARR after permanent errors (set by line initial- ization and close)
					40	TTDRCV	Signals error recovery procedures that a TTD message was the last message received from a remote station
					20	TROPID	Signals error recov- ery procedures to transmit and receive rather than receive only
					10 08	BSCDSC	BSCA enabled Signals interrupt that a disconnect sequence is being effected by error recovery proce- dures (when this bit is on, interrupt reenters error recovery proce- dures at BSDISC)
•					04	FWDABT	Signals interrupt that a forward abort sequence is being effected by error recovery procedures (when this bit is on, interrupt reenters error recovery procedures at WRTEOT)
					02	NEWBUF	Signals close that a new file is being opened, and that close should not disable the BSCA
					01	ERRMSG	i Used by error recov- ery procedures to force reading of an error message after an abort sequence

Lna

Disp

Disp Hex	Label	Lng Dec	Form	Descript	ion	
24	ACKS	1	Bit	Flag byt	e:	
				Hex Value	Combat	<b>M</b>
				Value	Symbol	Meaning
				80 ·	NULSNT	NULL message has been sent and the data management is waiting for a conversational reply
				40	AKDPF	DPF system
				20	IDHALT	Invalid ID exchange has occurred
				10	EOTRCD	Signals IOS that EOT has been received on a get file
				80	SWICH	A switched line being used
				04	AKERR	Error posted, line disabled
				02	RCVACK'	Alternating acknowledgments
				01	SNDACK	last received and last sent by this station
25	BSFLG2	1	Bit	Flag byt	:e:	
				Hex		
				Value	Symbol	Meaning
				80	CLOSET	Close in progress
				40	BADCAL	Invalid call by user
				20	NULL78	Send NULL mes- sage for IBM 2770 or 2780
				10	LG2LOG	Error already logged
				08	RJEBIT	RJE is running
				04	HLTY9	Issue Y9 halt from close
				02	NAKSNT	NAK was the last message sent by this station
				01	IDXCH	Signals wait to return to line

initialization (after an error occurred during line initialization)

	Disp Hex	Label	Lng Dec	Form	Description
	26-27		2	Addr	Save area for the address of the new DTF on multiple file BSC jobs
	28-29		2	Addr	Address of entry to interrupt
	2A-2B		2	Addr	Address of entry to IOS
	2C-2D		2	Addr	Address of entry to wait
	2E-2F		2	C/S	Cylinder/sector address of close
	30-31	ACKEVN	2	Bin	Even acknowledgment (constant)
	32-33	ACK1	2	Bin	Odd acknowledgment (constant)
	34-35	DLESTX	2	Bin	DLE STX sequence (constant)
	36-37	SINEOT	2	Bin	SYN EOT sequence (constant)
	38-39	WACK	2	Bin	WACK sequence (constant)
	3A-3B	TTD	2	Bin	STX ENQ sequence (constant)
	3C-3D	RVI	2	Bin	RVI sequence (constant)
	3E-3F	DISCON	2	Bin	Disconnect sequence (constant)
	40	ETBDC	1	Bin	ETB sequence (constant)
	41	NAKDC	1	Bin	NAK sequence (constant)
	42	PERCT	1	Bin	Constant for percent (%)
	43-44	WKLICS	2	C/S	Cylinder/sector address of line initialization
	45-46		2	Addr	Address of the VTOC read/write parameter list in either \$\$BSEL or \$\$BSMF statistic logging module
	47		1	Bin	First character received
	48		1	Bin	Second character received
	49		1	Bin	Next to last character received
_	4A		1	Bin	Last character received
	4B-4C	ZERO	2	Bin	Constant of 0
	4D-4E	ONE	2	Bin	Constant of 1


Disp Hex	Label	Lng Dec	Form	Description						
4F		1	Bin	2770-278	0 blank					
50		1	Bin	2770-278	0 escape					
51		1	Bin	2770-278	30 space 1					
52		1	Bin	2770-278	2770-2780 space 2					
53		1	Bin	2770-278	2770-2780 space 3					
54		1	Bin	2770-278	2770-2780-device select 4					
55-56		2	Bin	Terminal	Terminal successful I/Os					
57-58		2	Bin	Terminal unsuccessful I/Os						
59		1	Bit	Display a	Display adapter indicator byte:					
				Hex Value	Symbol	Meaning				
				20 10	LDATT LDTXT	Attachment check Display adapter data received				
				04	LDAMCR	Microcode loaded successfully				
				02 01	LDADCK LDASUP					
5A-5B		2	C/S	Address of	of MLTERF	IL for MLMP				
5C-5D		2	Bin			length when ransparent mode				
5E-5F		2	Bin		for TAR wansparent m	then transmitting				
60-7B	STABLE	28	Mix		statistics c s two bytes	ounters (each long):				
				Symbol	Meaning					
				SNTTXT RCVTXT NAKTBL DATTBL FABTBL	Text block NAKs rec	cks received ceived				

	Disp Hex	Label	Lng Dec	Form	Description
					Symbol Meaning
•	60-7B (continu	ed)			ABRTBL Aborts received TADTBL Adapter checks on receive INVTBL Invalid responses received ENOTBL ENOs received to ACKs sent LSTTBL Lost data errors LATBUF Disconnect timeouts and abortive disconnects TOTBL Receive timeouts DCOUNT Delay time count
	7C-7F	DSENTD	4	Mix	Display message sent
)	80-81	ETABLE	2	Addr	Address of HPL/APL instruction in wait
	82-83		2	_	Reserved
	84-8B	ERLIST	8	Mix	Error logging parameter list
	8C-90	HLTLST	5	Addr	Y7, Y8 halt parameter list
	91-9E	OLTPRM	14	Mix	Save area for the online test parameters
	9F-A0	TOLTCS	2	C/S	Cylinder/sector area for online test parameters
	A1-AE	OLTSAV	14	Mix	Online test save and work area
	AF-B2		4	Bin	Online test counter area

### BSCA I/O AREA

- BSCA formats the allocated I/O area into IOBs and line buffers.
- Area starts at hex 22-23 in the BSCA LCB.

### Organization of BSCA IOBs and Buffers in BSCA I/O Area



### MLTA ADAPTER DTF

- Pointed to by \$CCCOM at hex B9.
- Length is 33 bytes (hex 21).
- There is one adapter (DTF) per system.

Disp Hex	Label	Lng Dec	Form	Description
00	\$MDDEV	1	Bin	Device ID-hex 28 for MLTA lines
01	\$MDUP	1	Bit	UPSI U1-U8 customer controlled program switches
02	\$MDAT1	1	Bit	File attribute by te 1
03	\$MDAT2	1	Bit	File attribute byte 2
04-05	\$MDCHA	2	-	Reserved
06-07	\$MDCHB	2	Addr	DTF chain pointer—all DTFs
08-09	\$MDARR	2	Addr	Address recall register save area
0A-0B	\$MDXR1	2	Addr	Register 1 save area
0C-0D		2	-	Reserved
0E	\$MDCMP	1	Bin	Completion code hex 41 for permanent MLTA error
0F-10	\$MDUWA	2	Mix	User work area
11-12	\$MDLNO	2	Bin	Adapter DTF; always hex 0000
13-14	\$MDCMA	2	Addr	Address of the MLTA supervisor
15-16	\$MDERA	2	Addr	Address of IBM error recovery routine
17-18	\$MDUSA	2	Addr	Address of user interrupt level PCI processing routine
19-1A	\$MDDEA	2	Addr	Address of user disaster exit subroutine
1B-20	\$MDFIL	6	Char	Name of file containing the MLTA microcode

### MLTA LINE CONTROL BLOCK (LCB)

- Pointer to first LCB in \$CCCOM at hex B7.
- LCBs (MLTA and BSCA) are chained by address at hex 67 in LCB.
- Length is 125 bytes (hex 7D).
- There is one LCB for each MLTA line (maximum = 8).

Disp Hex	Label	Lng Dec	Form	Description				
00	\$MDDEV	1	Bin	Device ID—hex 28 for all MLTA lines				
01	\$MDUP	1	Bit	UPSI U1-U8				
02	\$MDAT1	1	Bit	File attr	:			
				Hex Value	Symbol	Meaning		
				80	\$MAPCI	Allow PCI interrupts		
				10	\$MATMI	Allow terminal to interrupt CPU transmission (receive interrupt feature)		
				08		Reserved		
				04	\$MAILT	Inhibit timeout during text entry		
				02	\$MATCF	Terminal control dependent flag		
				01	\$MATCT	Terminal control type		
03	\$MDAT2	1	Bit	File attr	ibute byte 2	:		
				Hex				
				Value	Symbol	Meaning		
				80	\$MAUSR	Allow user PCI exit at interrupt level		
				40	\$MAFUL	Full buffer ready for the user application program		
				20	\$MAERP	Use MLTA error recovery procedure		
				10	\$MARET	ERP has issued a retry on a read operation		

	Disp Hex	Label	Lng Dec	Form	Description	on	
					Hex Value	Symbol	Meaning
	03 (continue	ed)			80		Switch on after first buffer or a
					04	\$MAOLT	read Allow online terminal test
					02 01	\$MABSY \$MAOPN	requests DTF busy DTF opened
	04-05	\$MDCHA	2	-	Reserved		
	06-07	\$MDCHB	2	Addr	DTF chai	in pointer—l	MLTA DTFs
	08-09	\$MDARR	2	Addr	Address r	recall registe	r save area
	0A-0B	\$MDXR1	2	Addr	Register	1 save area	
	0C-0D	\$MDBAA	2	Addr	Address o	of customer	I/O buffer
	0E	\$MFCPC	1	Bin	Completi	on code:	
					Hex Value	Symbol	Meaning
					82	\$MCPC2	Full buffer with
					81	\$MCPC1	Full buffer with PCI and read repeat issued by ERP
•					57	\$MCSKP	All skip bits are on in the check list, lines specified in the check list are closed, there is no activity on any line, or any combination of these conditions (last DTF in list
•					56	\$MCRET	only) No event complete and user request- ed return of control (last DTF in list only)

Disp Hex	Label	Lng Dec	Form	Description			
				Hex Value	Symbol	Meaning	
0E (continue	ed)			53	\$MCOF6	No ERP specified, application pro- gram not able to process full buffer with PCI	
				51	\$MCUER	No ERP specified, operation failed	
				50	\$MCCSL	5471 Printer- Keyboard inquiry request (5471 printer- keyboard DTF only)	
				4E	\$MCCPS	© received with successful completion of a read and PCI was specified for the line DTF. Only one buffer segment is received after an ERP issued read operation.	
				4C	\$MCCP4	Successful completion of a read and PCI was specified for the line DTF. Only one buffer segment is received after an ERP-issued read operation.	
				4B	\$MCOF5	Program not able to process full buffer with PCI and the lost data error condition occurred	
				4A	\$MCCP3	EOT received and program not able to process full buffer with PCI, but data transmission completed without lost data. No error condition occurred.	

	Disp Hex	Label	Lng Dec	Form	Descripti	on	
					riex Value	Symbol	Meaning
	OE (continue	ed)			49	\$MCSDR	Current terminal address does not appear in the SDR table. The line has been closed.
•					48	\$MCCP2	Program not able to process full buffer with PCI, but data trans- mission com- pleted without lost data and no error condition occurred.
					47	\$MCOF4	Operation failed, line closed, loop test failed after a transmission or reception aborted error condition (This is a perma- nent line error.)
•					46 45	\$MCITP \$MCOF3	Terminal interrupt Operation failed, line closed, loop test ran success- fully after a transmission or reception aborted error condition. (This is a perma- nent line error.)
					44	\$MCTNR	Polled terminal not ready:
							Write Addressed terminals not ready Read Poll list completed with nega- tive response
							Successful abort or transmit break.

Disp Hex	Label	Lng Dec	Form	Description				
				Hex Value	Symbol	Meaning		
0E (continu	ed)			43	\$MCOF2	Operation failed, line closed, loop test failed. (This is a permanent line error.)		
				42	\$MCEOT	EOT on receive (LRC terminals only).		
				41	\$MCOF1	Operation failed, line open		
				40	\$MCCP1	Normal comple- tion of operation		
0F-10	\$MDUWA	2	Mix	User wo	rk area			
11-12	\$MDLNO	2	Bit	Line nu	mber (bit sig	nificant)		
						0 1 2 3 4 5 6 7 8 7 6 5 4 3 2 1		
13-14	\$MDCMA	2	Addr	Address of MLTA supervisor (this should be an address constant with corresponding EXTRN)  EXTRN MLTSPO  DC AL2 (MLTSPO)				

	Disp Hex	Label	Lng Dec	Form	Description	on	
)	15	\$MDOPC	1	Bin	Operation	code:	
					Hex Value	Symbol	Meaning
					29	\$MWRTR	Write erase with reset
					28	\$MWTS	Write erase
,					27	\$MWTLR	Write at line address with reset
					26	\$MWTL	Write at line address
					25	\$MWTVR	Write conversa- tional and reset
)					24	\$MWTV	Write conversational
					23	MWTTR	Write continue and reset
					22	MWTT	Write continue
					21	\$MWTIR	Write initial and reset
					20	\$MWTI	Write initial
					1D	\$MRTBR	Read full buffer with reset
					1C	\$MRTB	Read full buffer
					1B	\$MRTRR	Poll request and reset
					1A	\$MRTR	Poll request
					18	\$MRTS	Read skip
					17	\$MRTPR	Read repeat and reset
					16	\$MRTP	Read repeat
					15	\$MRTVR	Read conversa- tional and reset
					14	\$MRTV	Read conversational
					13	\$MRTTR	Read continue and reset
					12	\$MRTT	Read continue
<b>\</b>					11	\$MRTIR	Read initial and reset
,					10	\$MRTI	Read initial
					09	\$MWTN	Write negative acknowledgment
					08	\$MWTA	Write positive acknowledgment
					07	\$MCTSF	Set skip bit off in poll list
					06	\$MCTSN	Set skip bit on in poll list
					05	\$MWTDS	Write disconnect

MLTA LINE CONTROL BLOCK (LCB) (Continued)									
Disp Hex	Label	Lng Dec	Form	Descript	ion				
				Hex Value	Symbol	Meaning			
15 (continu	ed)			04	\$МСТВО	Program-initiated online test request			
				03	\$MCTLT	Loop test			
				02	\$MCTTO	Timeout			
				01	\$MCBRK	Transmit break			
				00	\$MCABT	Abort current operation			
16	\$MDOSC	1	Bin	Open sta	atus code/op	en start code:			
				Hex					
				Value	Symbol	Meaning			
				32	\$MOIIS	Invalid instruction sequence. Read continue (RTT), write continue (WTT), or read repeat (RTP) issued incorrectly			
				2E	\$MOBSE	Buffer too short for program- initiated online test, or switched line not connected			
				2C	\$MOSKP	No match found in polling list for CTSN or CTSF operation			
				28	\$MOER	Zero length speci- fied for write			
				24	\$MOBDC				
				20	\$MOABN	Abort or transmit break operation not accepted because the line was not busy.			

Disp Hex	Label	Lng Dec	Form	Description	on		
				Hex			
				Value	Symbo	o/	Meaning
16 (continue	d)			10	\$MOA	.BE	Transmit break operation not accepted because of an attempt to issue transmit break after a control or write operation
				Abort op	eration	not a	accepted because:
				Abort opera:		supp	orted for this
					ed line		peration on a connection has
				The confollow	urrent o	d ope	tion is one of the erations and data at the CPU.
				Terminal Configura	ation	Ope Cod	ration e
				1050			,RTIR,TRV,RTVR, R,RTRR
				1050D			,RTVR
				2740S			,RTV
				2740B			,RTV
				2740D 2740C		RT\	
				27400		RT\	,RTIR,RTV, /R
				2740DC			/,RTVR
				2740SC		RTI RT\	,RTIR,RTV, /R
				Hex			
				Value	Symbo	<b>o</b> /	Meaning
				18	\$MOC	TE	Current polling list index too large
				14	\$MOA	so	All polling list skip bits on
				10	\$MOU	IOP	Unsupported operation code or unsupported program initiated online test

Disp Hex	Label	Lng Dec	Form	Descript	tion	
				Hex		
				Value	Symbol	Meaning
6 continu	ed)			0C	\$MOIOP	Invalid operation code
				08 04	\$MOBSY \$MONOP	Line is busy Line DTF not open
				00	\$MOCPL	Operation started successfully
				Open de	finitions:	
				AC	\$MOANO	Adapter DTF not open at line open
				A4	\$MOENL	Could not enable line
				AO	\$MOBTS	Logical record length less than 16 bytes
				9C	\$MOLAO	This line already open
				98	\$MOERT	PCI exit or standard ERP was specified, but the respective address field in the adapter DTF contains hex FFFF.
				94	\$MOIEX	Invalid transfer vector for terminal features specified
				90	\$MORTS	I/O buffer area
				8C	\$MOILN	Invalid line
				88	\$MOEXT	Line DTF not opened because UPSI is not on in the system switch byte (UPSI did not appear in the // SWITCH statement.)
				84	\$MOOPL	User provided address is out- side of partition
				00	\$MOCPL	limits Open completed

successfully

	Disp Hex	Label	Lng Dec	Form	Description		
					Hex Value	Symbol	Meaning
					Close def	inition:	
	16 (continue	ed)			A8	\$MODSL	Could not disable
					00	\$MOCPL	Close completed successfully
	17	\$MDTTP	1	Bin	Terminal	type:	
					Hex Value	Symbol	Meaning
					03.		2741
					02		2740
					01		1050
	18	\$MDTFT	1	Bit	Terminal	features by	te 1:
					Hex Value	Symbol	Meaning
					80	\$MTTRC	Transmit control
					40	\$MTINT	Transmit interrupt
					20	\$MTLRC	Longitudinal record checking
					10	\$MMDNT	Switched line
					08	\$MTBPS	Line speed of 600 bps
_					04	\$MTPLT	Station control
					01	MMAUP	MLTA has auto-poll
	19	\$MDTFR	1	Bit	Terminal	features by	te 2:
					Hex		
					Value	Symbol	Meaning
					80	\$MTBFR	Buffer receive
					40	\$MTRSP	Test second byte of addressing response
	1A	\$MDTCT	1	Bit	Transmi	ssion code t	ype:
					Hex		
					Value	Meaning	
_					02 01	Correspor	ndence code
					٥.		· <del>-</del>

Disp Hex	Label	Lng Dec	Form	Description
1B	\$MDRLM	1	Bin	Maximum error retry limit
1C-1D	\$MDBSL	2	Bin	Length of each buffer segment (preopen)
1C-1D	\$MDLNF	2	Bin	Receive length count and flags (postopen)
1E-1F	\$MDBAL	2	Bin	Length of user receive area (This is the amount of storage the user has allocated at TDFBA@)
20-21	\$MDCRL	2	Bin	Current record length
22-23	\$MDCRA	2	Addr	Address, of current record
24-25	\$MDPBA	2	Addr	Address of PCI buffer
26-27	\$MDPBL	2	Bin	Length of PCI buffer
(26)	\$MDOLC	1	Bin	Program initiated online test control byte
(27)	\$MDOLR	1	Bin	Program initiated online test start byte
28-29	\$MDLPA	2	Addr	Address of last PCI buffer
2A-2B	\$MDDIA	2	Addr	Address of transfer vector table for I/O operations
2C-2D	\$MDDLA	2	-	Reserved
2E-2F	\$MDEBA	2	Addr	Address of statistical data recording (SDR) table
30	\$MDEBC	1	Bin	Number of SDR table entries
31	\$MDMOD	1	Bit	MLTA mode at time of error:
				Hex Value Meaning
				80 Receive PCI buffer overrun:

Hex Value	Meaning
80	Receive PCI buffer overru
40	1 = Lowercase shift; othe wise, uppercase shift
Bits 2-3	00 = Control mode 01 = Transmit mode 10 = Receive mode

Disp Hex	Label	Lng Dec	Form	Description	on	
32	\$MDSN6	1	Bit	HDB6 ser	ise byte:	
				Hex Value	Symbol	Meaning
				80 40 20 10 08 04 02	\$MSOUT \$MSDCK \$MSTAB \$MSRAB \$MSOVR \$MSINT \$MSNOP	Timeout Data check Transmit abort Receive abort Overrun Terminal interrupt No operation performed Lost data
33	\$MDSN7	1	Bit	HDB7 ser	·	
33	\$WD3W7	•	ы	Hex Value	Symbol	Meaning
				80 10 Bits 5-7	\$MSMNR \$MSLNR	Modem not ready Line not ready SIO N-code
34-35	\$MDEXP	2	Mix	Expansio	n area	
36-37	TDFEC@	2	Addr	Address f	or error rec	overy control
38	TDFFL1	1	Bit	IOCS flag	byte 1:	
				Hex Value	Symbol	Meaning
				80	FL1ERC	Add 1 to error count for each 2740 Model 2.
				40	FL1PER	Permanent line error online, otherwise; terminal error. (This switch applies only when a permanent error has occurred.)
				20	FL1AUP	Auto-poll switch to first SIO
				10	FL1EOB	End of block transmitted (expect LRC reply)

Disp

Hex	Label	Dec	Form	Descript	ion	
				Hex Value	Symbol	Meaning
38 (continu	ied)			80	FL1ABT	Abort operation code specified
(00)	,			04	FL1LTF	Loop test failure indicator
				02	FL1FBS	First buffer switch
				01	FL1POA	Poli
39	TDFFL2	1	Bit	IOCS fla	g byte 2:	
				Hex		
				Value	Symbol	Meaning
				40	FL2ENA	Line enabled
				20	FL2OLP	Program requested online test
				80	FL2OLT	Online test in progress
3A	TDFFL3	1	Bit	IOCS fla	g byte 3:	
				Hex		
				Value	Symbol	Meaning
	•			80	FL3CHK	Check has called close
				40	FL3SDR	No SDR search for this operation
				20	FL3EOA	EOA received at start of message
				10	FL3LTP	Test mode enabled for loop test
3B-3C	TDFPC@	2	Addr		of program errupt routi	control return ine
3D-3E	TDFFI@	2	Addr	Address	of first IOB	
3F-40	TDFCI@	2	Addr	Address	of current I	ОВ
41-42	TDFSC@	2	Addr	Address	of current e	entry in SDR table
43	TDFEQA	1	Char	D (er	nd of addres	s)

	Disp Hex	Label	Lng Dec	Form	Description		
	44	TDFYES	1	Char	Y (pos	itive response)	
	45	TDFEPC	1	Bin	Event completion code (internal)		
	46	TDFCOP	1	Bin	IOCS cop	y of the user's operation code	
	47-4C	TDFIOB	6	Mix	IOCS wor	k IOB	
	4D-4E	TDFHDB	2	Bin	High dens	ity buffer positions 8 and 9	
	(4D)	TDFHD8	1	Bin	PCI/recei	ve length	
_	(4E)	TDFHD9	1	Bin	HDB flag		
	4F	\$MDOLT	1	Bit	Bit pattern for start of online test requested on this line		
	50	TDFERP	1	Bit	Error rece	overy status switches:	
					Hex Value	Meaning	
					80	ERP has been called.	
	51-53	\$MDPER	3	Bin	Permanen	t error recording area	
	(51)	\$MDPE0	1	Bit	High dens	sity buffer 0:	
					Hex Value	Meaning	
					80 40 20 10 Bits 4-7	PCI overrun Uppercase Text-in mode Text-out mode Bit time count field	
	(52)	\$MDPE6	1	Bit	High dens	sity buffer 6:	
					Hex Value	Meaning	
•					80 40 20 10 08 04 02	Timeout Data check Transmit abort Receive abort Overrun Terminal interrupt No operation performed Lost data	

			,	-, , <u>-</u> - 311tillit	
Disp Hex	Label	Lng Dec	Form	Descript	ion
(53)	\$MDPE8	1	Bit	High der	nsity buffer 7:
	\$MDPE7			Hex Value	Meaning
				80 10	Switch line disconnected 2740 M2 busy with write
				08	(CORR) 2740 M2 busy with write (PTTC)
				04 02	2740 M2 in bid status 2740 M2 in enter status
54-5D	TDFWRK	10	Mix	Work ar	ea
(58-59)	\$MDRSP	2	Char	Respons	e from addressing 2740 Model 2
Device D	Dependent Sec	tion			
5E	\$MDCTN	1	Bin	Current	terminal number in polling list
5F-60	\$MDPLA	2	Addr	Address	of polling list
61-62	\$MDTMA	2	Char		al address and component (in line code):
				Read	Address of the terminal from which text was received
				Write	Address of the terminal to which text is to be transmitted
63-64	\$MDCEA	2	Addr		of current entry in polling list ates last terminal that ed)
65-66	LCBPLQ	2	Addr	Address line que	of first parameter list in the ue
67-68	LCBCHN	2	Addr	LCB cha	ain address
69	LCBATA	1	Bit	Attribut	te byte A:
				Hex Value	Meaning
				80	Ignore op end Reopen line

Disp Hex	Label	Lng Dec	Form	Description	on	
6A	LCBELC	1	Bin	Translate EBCDIC)		ss (line code to
6B		1	-	Reserved		
6C	LCBLCE	1	'Bin		table addre EBCDIC)	ss (line code to
6D		1	-	Reserved		
6E	LCBLLE	1	Bin		table addre EBCDIC)	ss (line code to
6F	LCBOLT	1	Bin		nline test co on this line	unt (running and
70	LCBATR	1	Bit	Line cont	rol block at	tribute byte:
				Hex		
				Value	Symbol	Meaning
				80	LCBNIT	Successful opera- tion on this line (line connected switched)
				40 20	LCBOBR LCBGNN	Online test GETMAIN needed
						for the line queue
				10	LCBSTP	Abort issued to stop the read
				80	LCBSWL	Ignore input from next read operation
				04	LCB1PL	Put next parameter list for this line at top of line queue
				02	LCBTBK	Ignore data for the read opera- tion (set for 2741 read initial, when a write is the first operation requested)
				01	LCBTIM	LCB allocation pending.
				0A		Ignore next op end whether input or output

Disp Hex	Label	Lng Dec	Form	Description
71-72	LCBBFL	2	Bin	Length of data area in line buffer
73-74	LCBMCL	2		Reserved
75-76	LCBIBL	2	Bin	Length of current invite input buffer for this line
77-78	LCBIBA	2	Addr	Address of invite input buffer
79-7A	LCBTCB	2	Addr	Address of TCB to which line is allocated (switched line)
7B	LCBATC	1	Bin	TUB count (switched line)
7C	LCBWTC	1	Bit	World Trade terminal type byte:

Hex Value	Meaning
02	5390 WTC terminal
01	2970 WTC terminal

#### MLTA POLLING LIST

The polling list is pointed to in LCB at hex 5F-60. The polling list is preceded by three parameter bytes, and followed by three bytes indicating end of list. The format of the polling list is:



Byte	Bit	Field Description
1		Index byte
	0	Skip flag (must be set on)
	1	Wrap list indicator
	2	Timeout indicator (used only with wrap list)
	3-7	Reserved
2		Timeout value
3		Number of entries in the polling list

#### Poll Entries

Byte	Bit	Field Description
1		Index byte
	0	Skip flag (indicates not to poll this entry)
	1-7	Polling list entry number (1-127) (must be consecutively numbered for each entry)
2		Terminal address
3		Component selection (1050), space character (other terminals)

Each poll entry must contain an index byte, a terminal address character, and a component selection character. If component selection is not required, a space character must be used for the third byte of the entry. The entry numbers of the index bytes are consecutively numbered beginning with 1.

#### End-of-List Bytes

Byte	Bit	Field Description
1		Hex FF (end of list indicator)
2		Reserved
3		LRC answer code to be inserted by the MLTA IOCS for read repeat (RTP) and read continue (RTT) (with autopoll)

### MLTA IOCS IOB

- First IOB in chain pointed to in LCB at hex 3D.
- Current IOB pointed to in LCB at hex 3P.
- IOBs chained by pointer at hex 06.
- Length is 12 bytes (hex 0C).

Disp Hex	Label	Lng Dec	Form	Description
00	IOBQBT	1	Bin	SIO Q-byte
01	IOBCTL	1	Bin	Control byte for SIO command
02-03	IOBCAB	2	Addr	Current address register save area or interval timeout
04-05	IOBTAB	2	Addr	Transition address register save area
06-07	IOBNX@	2	Addr	Address of next IOB
08-09	IOBBS@	2	Addr	Address of data buffer start
0A-0B	IOBBE@	2	Addr	Address of data buffer end

### MLTA IOCS COMMON AREA

- Located at MLTSP0 in module \$\$MLD1. (See generation listing.)
- Length is 163 bytes (hex A3).

Disp Hex	Label	Lng Dec	Form	Description
00	COMTRA	1	Bin	Trace control switch
01-02	COMIO	2	Bin	Two-byte binary zero constant
03	COMI1	1	Bin	Two-byte binary one constant
04-05	COMI2	2	Bin	Two-byte binary two constant
06-07	соміз	2	Bin	Two-byte binary three constant
08-09	COMFFF	2	Bin	Two bytes with all bits on

# MLTA IOCS COMMON AREA (Continued)

ОВ

COMPCI

Disp Hex	Label	Lng Dec	Form	Descrip	tion
0A	COMSWT	1	Bit	Commo	n switch:
				Hex Value	Meaning
				80 40	PCI interrupt indicator Last operation does not have a current address buffer address
				20	Reserved
				10	Close disaster error exit switch
				80	Close print call switch
				04	Open/close halt call switch
				02	Loop test in progress
				01	Adapter has been disabled

Some of the following fields are used by the adapter open operation after the program is loaded. The fields contain the address of instructions where the adapter open operation stores the cylinder/sector address of the transients. After the first time the adapter open operation is performed, these fields are used for other data.

PCI count for check

Bin

0C-0D	COMDTF	2	Addr	DTF save area for open/close
0E-0F	COMPRT	2	Addr	Address of the interrupt priority table
10-11	COMERP	2	Addr	Address of the MLTA ERP routine
12-13	COMARR	2	Addr	Interrupt level ARR save area
14-15	COMXR2	2	Addr	Storage used by the interrupt level to save the contents of XR2 for the program level
16-17	COMPSR	2	Bit	Storage used by the interrupt level to save the PSR for the program level
18-19	COMPS@	2	Addr	Partition start address
1A-1B	COMPE@	2	Addr	Partition end address
1C-1D	COMIR3	2	Addr	Address of the interrupt level 3 entry
1E-1F	COMLOG	2	Addr	Address of the work area for the permanent error message buffer
20-21	COMCSA	2	C/S	Error file cylinder/sector address
22-23	COMSP@	2	Addr	Address of the branch instruction to the user PCI code at the interrupt level

# MLTA IOCS COMMON AREA (Continued)

Disp Hex	Label	Lng Dec	Form	Description
24-26	COMWRK	3	Mix	Work area
27-28	COMADP	2	Addr	Address of the adapter DTF
29-2A	COMEN@	2	Addr	Address of the halt routine
2B-31	COMHLT	7	Mix	Halt parameter list
32-33	COMOA@	2	Addr	Address of the adapter DTF address saved by the open routine
34-35	COMCAB	2	Addr	Current address buffer
36-37	COMTAB	2	Addr	Transition address buffer
38-39	COMCHR	2	Char	Last two characters in buffer
3A-3B	COMSRC	2	Bin	Line source that caused the interrupt
3C-3D	COMSP1	2	Addr	Address of the start I/O routine used by open/close to issue I/O operations
3E-3F	COMIO@	2	Addr	Address of the I/O entry routine used by online test to issue I/O operations
40-41	COMCL@	2	Addr	Address of the end-of-job close
42-43	COMCK@	2	Addr	Address of the check routine entry point
44-49	COIOB1	6	Char	Exits interrupt level or transmits delete characters to terminals using PKC
4A-4F	COIOB2	6	Char	Transmits delete characters after a switched network is connected and before any text is sent.
50-5E	COMDEL	15	Char	Fifteen delete characters used by I/O modules for switched network connection timing and to keep the line active after a write operation for non-LRC terminals
5F-9E	INTPRT	64	Mix	Interrupt priority tables which can contain up to 16 entries, each comprised of a bit significant line number (two bytes) followed by the line DTF address (two bytes) (a line DTF address of hex FFFF indicates the line is closed.)
9F-A0	COMSV1	2	Addr	Save area for program level 1 IAR
A1-A2	COMSV2	2	Addr	Save area for program level 2 IAR

# CONTENTS DIRECTORY ENTRY (CDE)

- Pointer to first entry in \$CCCOM at hex 2C.
- Entry length is 24 bytes (hex 18).
- Entries occupy contiguous storage.

Disp Hex	Label	Lng Dec	Form	Description
00-05	CDENAM	6	Char	Object module program name
06-07	CDECS	2	C/S	C/S of user program
08	CDE#S	1	Bin	Number of text sectors of program
09-0A	CDELNK	2	Addr	Program link-edit address
ОВ	CDERLD	1	Disp	Displacement of the relocation directory in the last text sector
0C-0D	CDEENT	2	Addr	Program entry point address
0E-0F	CDELOD	2	Addr	Program load address
10	CDELNG	1	Bin	Program length: Number of 256-byte blocks
10-11	CDESIZ	2	Bin	Program length: Number of bytes
12	CDEATR	1	Bit	CDE attribute byte 1:
				Hex Value Symbol Meaning

Hex Value	Symbol	Meaning
80	CDEDAT	Input data allowed on program request.
40	CDECOR	Main storage addressed by CDELOD (Program load address is allocated.)
20	CDEDPL	Program requires dedicated program level.
10	CDEMTS	Program supports multiple request- ing terminals.
08	CDENEP	Program is never-ending.
04	CDESER	Program is serially reusable.
02	CDETCB	The contents directory entry belongs to a TCB (that is, program currently executing).

#### CONTENTS DIRECTORY ENTRY (CDE) (Continued)

Disp Hex	Label	Lng Dec	Form	Descripti	ion	
13	CDEAT2	1	Bit	CDE attr	ibute byte 2	<b>:</b> :
				Hex Value	Symbol	Meaning
				40	CDESDB	DSM shared I/O buffering in use
				20	CDEPAK	Program location (pack) on DSM pack; otherwise, CCP production pack
				10	CDEEMG	Issue end/release message
				08	CDECOM	Program requires common area
14	CDEFDT	1	Bin	Number of 256-byte blocks in the longest display format facility file descriptor table		
15	CDEDFF	1	Bin	Size of program appended storage (PAS) for display format facility in number of 256-byte blocks (This byte is zero if the display format facility is not used.)		
16-17	CDESTA	2	Disp	Offset to	program us	e count table entry

# STATISTICAL DATA RECORDING (SDR) TABLE

The SDR table is pointed to in LCB at hex 2E-2F. The SDR table holds the SDR statistics. Each line DTF contains the address of this table (field TDFEBG) and a count of the number of entries in the table (field TDFEBG). Each entry in the table is five bytes long. The first byte of each entry is the communication terminal address in uppercase notation. For point-to-point lines, the terminal address is hex 80. The remaining four bytes of each entry are set to zero at open time. The format for each entry of the SDR table is:

MLTA IOCS Field Name	Byte	Field Description
SDRCT@	1	Communication terminal address
SDRCER	2	Number of errors (permanent and temporary)
SDRCIO	3-4	Number of successful read/write operations
SDRERC	5	Error retry count for this operation

# COMMUNICATIONS PARAMETER LIST

- Located within the user's program.
- Current or last CPL pointed to by TCB at hex 17.

Disp Hex	Label	Lng Dec	Form	Descrip	tion	
00-01	PLRTC	2	Bin	Return	code passed t	o user program
(00-01)	PLCHN	2	Addr		of next para anding reque	meter list on chain sts
02	PLOPM	1	Bit	Operati	on code mod	ifier:
				Hex Value	Symbol	Meaning
				80	OPREQR	User request; otherwise, system request
				40	OPOLT	(To a terminal) system operator initiated online test
				40	OPCIOW	(To the console) do not let non- console CCP run until all console output is complete
				20	OPDISC	Disconnect switched line
				10	OPNFG	Record area not freed from
				08	OPLIST	program request 3270 DFF specia
				04	OPSTOP	Stop operation specified in
				02	OPSOL	parameter list Suppress start ner line; otherwise, ensure type- writer terminal begins output at
				01	OPEOL	a new line Suppress end new line; otherwise, ensure type- writer terminal ends the output at the start of a

new line

# COMMUNICATIONS PARAMETER LIST (Continued) Lng

Disp

Hex	Label	Dec	Form	Description				
03	PLOPC	1	Bin	Operation	n code:			
				Hex Value	Symbol	Meaning		
				FX	OPXCLM	Precede console output with exclamation point		
				80	OPJRSH	Reschedule only request		
				70	OPRUF	3270 read under format control		
				52	OPEAU	3270 EAU		
				42	OPCOPY	3270 copy		
				3X	OPMSG	Unit of data message		
				2X	OPBLK	Unit of data block		
				0X	OPSTD	Unit of data record		
				1A	OPKPL	On release, keep the line on		
				19	OPSTA	On acquire, set attributes		
				11	OPRVI	On get, send RVI		
				08	OPSTAT	Status operation		
				04	OPNOW	No wait operation		
				02	OPPUT	Output operation		
				01	OPGET	Input operation		
04-05	PLOUTL	2	Bin	Output I	ength			
(04-05)	PLEFFL	2	Bin	Effective	input lengt	th		
(05)	PLASID	1	Char	Terminal character		et identification		
06-07	PLINL	2	Bin	Maximu	n input leng	gth		
08-09	PLRECA	2	Addr	Record a	rea address			
(08-09)	PLDATA	2	Addr	Data are	a address			
0A-0B	PLTUBA	2	Addr	Termina	l unit block	address		
(0A-0B)	PLTCBA	2	Addr	Task cor	ntrol block a	address		

# COMMUNICATIONS PARAMETER LIST (Continued)

	Disp Hex	Label	Lng Dec	Form	Description	on	
	0C	PL\$OPM	1	Bits	Internal c	peration co	de modifier:
					Hex Value	Symbol	Meaning
•					80	OPGETM	(For a terminal) requires successful GETMAIN before the invite input can be started (For the console) GETMAIN failed for put nowait, which is scheduled as a put wait
					40	OPKONS	Request to the console
					20	OPNPST	Do not post upon end of operation associated with this parameter- list.
					10	OPBNOP	BSCA no post upon ERP op end
					04	OPNOW	No wait operation
					02	OPPUT	Output operation
					01	OPGET	Input operation *
	0D	PL\$OPC	1	Bits	BSCA int	ternal opera	tion code modifiers:
					Hex		
					Value	Symbol	Meaning
					80	OPRFSH	Send refresh message to 3270
					40	OPLSNS	Poll for terminal status
					20	OPUSER	System function; otherwise, user function
					10	OPSTCM	Stop invite has been handled for this parameter list

# COMMUNICATIONS PARAMETER LIST (Continued)

Disp Hex	Label	Lng Dec	Form	Description	
(OD)	PL\$MCT	1	Bits	Multicor	mponent terminal indexes:
				Bit	Meaning
				0-3	Index of 1050 input component
				4-7	Index of 1050 output component
0E-0F	PL\$RTC	2	Bin	Internal	return code area
(0E-0F)	PL\$TNT	2	Addr	Address	of terminal name table entry

# GETMAIN/FREEMAIN PARAMETER LIST

This list is built within the program calling GETMAIN/FREEMAIN:

Disp Hex	Label	Lng Dec	Form	Description	
00-01	GMADDR	2	Addr	Address of the segment:	leftmost byte of the
				GETMAIN:	Address of allocated segment is returned here (hex 0000 if no segment could be allocated)
				FREEMAIN:	Address of segment to free is specified here.
02-03	GMSIZE	2	Bin	Length (in byte	es) of the segment:
				GETMAIN:	Segment length required is specified here.
				FREEMAIN:	Length of segment to be freed is specified here.

### GETMAIN/FREEMAIN PARAMETER LIST (Continued)

Disp Lng Hex Label Dec Form Description

# Main Storage Control Block (SCB)

- Two SCBs are normally in main storage.
- The TP buffer SCB is in \$CCCOM at hex displacement 4A-53.
- The user program area SCB is in \$CCCOM at hex displacement 56-5F.

00-01	SCBCHN	2	Addr	Address of leftmost byte of first free segment, or, if no free segment, hex 0000 (initially, address of first byte of storage pool)
02-03		2	Bin	Always hex 0000
04-05	SCBLO	2	Addr	Address of first byte of storage pool
06-07	SCBHI	2	Addr	Address of last byte of storage pool plus 1
08-09	SCBMAX	2	Bin	Length in bytes of largest free segment (initially, length in bytes of storage pool)

#### Free Segment Control Block

Located in the first 4 bytes of a free area of main storage:

00-01	SEGCHN	2	Addr	Address of first byte of next free segment, or, if no free segment beyond this, hex 0000
02-03	SEGLEN	2	Bin	Length in bytes of this segment, including the four bytes occupied by this control block

# STANDARD PARAMETER LIST

- Used by COBOL, FORTRAN, Assembler.
- Set up within calling program.

Disp Hex	Label	Lng Dec	Form	Description				
00-01	_	2	Bin	Return code				
02-03	-	2	Bin	Operation co	ode			
04-05	-	2	Bin	Output Operations	Length of data to be trans- mitted (not including line control or symbolic terminal name)			
				Input Operations	Effective input length calculated by CCP (including record separators, but not including line control, symbolic terminal name, backspace, or truncated data			
				Return Code Hex 08 Present	Number of outstanding invite inputs calculated by CCP			
				Acquire Terminal and Changing Attributes	Desired terminal attribute set			
				Release Terminal Operation	Number of outstanding invite inputs			
06-07	_	2	Bin	Maximum input length (excluding symbolic terminal name)				
08-09	_	2	Addr	Record area address				
0A-0F	_	6	Mix	CCP work a	rea			

# USER RECORD AREA

Pointed	Pointed to at hex 08-09 in the user parameter list in SUBR91, 92, and 93.							
Disp Hex	Label	Lng Dec	Form	Description				
00-05		6	Char	Symbolic terminal name				
06-nn		nn		Data area				
User Re	cord Area for	RPG II	Output					
00-03	OPCODE	4	Bin	Operation code and modifier				
04-07	OUTLNG	4	Bin	Output length, including first 14 positions in record area plus all data (Terminal attribute set ID if acquire operation)				
08-0D	TNAME	6	Char	Symbolic name of terminal for which operation is intended (blanks if for requester of SR program)				
0E	DATA	nn	Char	Data				
User Re	cord Area for	RPG Ir	put					
00-01	INRTC	2	Bin	Input return code 00-11				
02-03	OUTRTC	2	Bin	Return code for last output operation (blanks if not a combined file or if the array is not used for both an output and an input file)				
04-07	EFFL	4	Bin	Effective input length/number of outstanding invite inputs (The effective input length reflects the actual data length, not including the first 14 positions of the input record area.)				
08-0D	TNAME	6	Char	Symbolic name of the terminal from which the data was received				
0E	DATA	nn	Char	Data as received from the terminal				
(OE)	AID	1	Char	If DFF is used with a 3270 terminal and this operation is not an accept input for data with a program request, the first data position contains the attention ID				

(AID) character.

### RPG II AREAS

- For subroutine 91, 92 linkage.
- Pointed to by DTT on input.
- Pointed to by DTF on output.

Disp	Lng	Lng		
1				
Hex	Dec	Form	Description	
1 1107	D00	1 0.111	Dosonption	

# For SUBR91 a 4 x 6 array (all data EBCDIC):

00-03	4.	-	Not used, start first element
04-05	2	Bin	Return code
06-07	2	-	Not used, start second element
08-0B	4	Bin	Operation code
0C-0D	2	-	Not used, start third element
0E-11	4	Bin	See hex 04 in standard parameter list
12-13	2	-	Not used, start fourth element
14-M	4	Bin	Maximum input length (data only)

# For SUBR92 a 5 x 6 array (all data EBCDIC):

00-01	2	-	Not used, start first element
02-03	2	Bin	Input return code
04-05	2	Bin	Output return code
<b>06</b> -07	2	-	Not used, start second element
08-0B	4	Bin	Operation code
OC-OD	2	-	Not used, start third element
QE-11	4	Bin	See hex 04 in standard parameter list
12-13	2	-	Not used, start fourth element
14-17	4	Bin	Maximum input length (data plus 14)
18-1D	6	Char	Symbolic terminal name, fifth element

### SECTOR QUEUE BLOCK (SQB)

- Pointer to first entry in \$CCCOM at hex 34.
- Entry length is 12 bytes (hex 0C).

Disp Hex	Label	Lng Dec	Form	Descrip	tion	
00-01	SQBIOB	2	Addr	Address	of owning in	nput/output block
02-03	SQBTCB	2	Addr	Address	of owning to	ask control block
04	SQBQB	1	Bin	Device (	Q-byte	
05-07	SQBBEG	3	C/S C/H/R	Starting	C/S (left-jus cylinder/hea tified) (5445	
A0-80	SQBEND	3	C/S C/H/R	Ending C/S (left-justified) (5444) Ending cylinder/head/record (left-justified) (5445)		d/record
ОВ	SQBFLG	1,	Bits	Flag by:	te:	
				Hex Value	Symbol	Meaning
				80	SQBOWN	Sector enqueue block is owned (active)
				40	SQBFRE	Sector enqueue block is free (inactive)
				20	SQBLST	Last sector enqueue block in table

### SEGMENT CONTROL BLOCK (SCB)

This four-byte segment control block precedes each assigned or unassigned area in the teleprocessing buffer. Bytes 1 and 2 are a pointer to the next free segment (or hex 0000 if the last free segment) if the block of main storage is unassigned. If assigned, bytes 1 and 2 point to the start of the segment control block.

Disp Hex	Label	Lng Dec	Form	Description
00-01	SEGCHN	2	Addr	Address of first byte of next free segment (If no free segment beyond this, then hex 0000.)
02-03	SEGLEN	2	Addr	Length in bytes of this segment, including the four bytes occupied by this control block

# SHORT DISK DTF (SDF)

- Pointer to first SDF in \$CCCOM at hex 3E.
- Other entries chained in SDF at hex 00.
- Length is 47 bytes (hex 2F).

Disp Hex	Label	Lng Dec	Form	Description
00-01	DFNDTF	2	Addr	Address of next short DTF
02-03	DFCHN	2	Addr	Origin of queue of the open user DTF
04-0B	DFNAME	8	Char	File name
0C	DFUSE	1	Bits	File use indicators (Each bit corresponds to a user task control block that is currently using the file.)
				Hex Value Meaning
				80 Task 8 40 Task 7 20 Task 6 10 Task 5 08 Task 4 04 Task 3 02 Task 2 01 Task 1
0D	DFADD	1	Bits	File add indicators (Each bit corres- ponds to a user task control block that is currently adding to the file. All bits on indicates that the user does not share.)
0E	DFATT	1	Bin	File attributes and status indicators:  Hex  Value Symbol Meaning

Value	Symbol	Meaning
80	DFNCUR	Current file user
		makes the file nonreusable.
40	DFNPND	A pending nonre
		usable request
		exists for the
		file.

# SHORT DISK DTF (SDF) (Continued)

_	Disp Hex	Label	Lng Dec	Form	Description	on	
					Hex Value	Symbol	Meaning
	OE (continue	ed)			20	DFNR4	Program request has processed, through the disk file requirements in \$CC4R4, a request that
							makes the file nonreusable. If the rest of the request is good, the bit DFNPND is turned on by
							\$CC4R6 and this bit turned off. Else it is turned off by \$CC4PR.
					10	DFTAPP	Allocation needs this file when termination deallocates it.
					08	DFXAPP	Allocation requires exclusive use of this file when termination deallocates the last user.
					04	DFAAPP	Allocation wants the file for an ADD to the file when the pro- gram currently adding to the file terminates.
					03	DFLOD	File is indexed load.
					02	DFINX	File is indexed.
					01 Bits 6-7	DFDIR	File is direct.  Mode of CCP open:  00 Consecutive 01 Direct 10 Indexed
							random 11 Indexed load

# SHORT DISK DTF (SDF) (Continued)

Lng

Disp

Hex	Label	Dec	Form	Description	on	
0F	DFFLA	1	Bits			
				Hex Value	Symbol	Meaning
				80	DFORDL	This file can only be opened for ordered indexed load.
				80		File can be opened for input.
				04		File can be opened
				02		for output. File can be opened
				01		for update. File can be opened for add.
10	DFDEV	1	Bin	Device Q	bytes	
11	DFSWA	1	Bin	Schedule DSM clos		value saved for
12-13	DFRCL	2	Bin	Record le	ength	
14-15	DFADTF	2	Addr		of the user [ adding to t	
16-17	DFXTA	2	C/S	Start exte	ent C/S dire	ct or sequential
18-19	DFXTB	2	C/S	End exte files	nt C/S for i	ndexed or sequential
5444/54/	17 Disk Drive					
		2	D:	F-4-46	1- C/C/D f-	r a direct file
	DFEOF	3	Bin			
1A-1D	DFNXR	4	C/S/D/D	Next reco		r/sector/long
1 E	DFKL	1	Bin	Key leng	th	
1F-20	DFKD	2	Bin	Key disp	lacement	
21-22	DFKXA	2	C/S	Start of i	ndexed C/S	for indexed files
23-25	DFNXK	3	C/S/D	Next ind	ex record in	a file C/S/D
26-27	DFKXB	2	C/S	End of ir	ndex portion	n C/S

### SHORT DISK DTF (SDF) (Continued)

Disp Hex	Label	Lng Dec	Form	Description
28-2A	DFKXP	3	C/S/D	End of added index records C/S/D
2B-2C	DFMIX	2	C/S	Address of master track index
5445 Disk	c Drive			
(1A-1D)	DXEOF	4	C/H/R/D	End-of-file C/H/R/D
1A-1E	DXNXR	5	C/H/R/ D/D	Next record in file C/H/R/DD
1 F	DXSPC	1	Bin	Split cylinder number of tracks
(1F)	DXKL	1	Bin	Key length
20-21	DXKD	2	Disp	Key displacement
22-23	DXKXA	2	C/H	Start of indexed file C/H
24-27	DXNXK	4	CHRD	Next indexed record in file C/H/R/D
28-2A	DXKXB	3	CHR	End of indexed portion C/H/R
2B-2E	DXKXP	4	CHRD	End of added index records C/H/R/D
2F-30	DXMIX	2	Addr	Address of master index or high key

bucket if add file

### SWITCHED TERMINAL TABLE (STT)

- Contains switched line telephone numbers.
- Read from disk when needed during execution.

	T	T
Length	Number (up to 25 characters)	FF

Entries do not span sectors.

### SYMBOLIC FILE TABLE (XDT)

- Pointer to first entry in \$CCCOM at hex 88.
- Entries are variable in length and occupy contiguous storage.
- Each entry is delimited by hex FF.
- The table is delimited by hex FFFF.

Disp Hex	Label	Lng Dec	Form	Description
00-07	XDTNAM	8	Char	Symbolic file name
08	XDTREF	1	Disp	A series of one-byte entries that index the relative short DTFs that can be associated with the symbolic name (numbering from 1)

### **TERMINAL ATTRIBUTES TABLE (TAT)**

- A table of five-byte terminal attribute sets.
- Pointed to by \$CCCOM at hex AC.
- Number of sets in table located in \$CCCOM at hex B0.
- Individual sets referenced by relative entry number.
- Table referenced by TUB.
- In-storage table is identical to TAT in \$CCPFILE assignment sets.

# TERMINAL ATTRIBUTES SET (TAS)

- TAS is pointed to by the CCP communication area (\$CCCOM) at hex 12F-130.
- Indicates the attributes that are valid for one or more terminals.
- Each TUB points to its attributes set in the TUB fields, TUBCMA at hex 1B and TUBTAS at hex 1C.

Disp Hex	Label	Lng Dec	Form	Description			
00	TASAT1	1	Bits	Attribu	Attribute byte 1:		
				Hex Value	Symbol	Meaning	
				80	TASTRN	Do not translate	
				40	TASCAS	Do not force uppercase	
				20	TASCNC	Perform call	
				10	TASAUT	Auto-connect	
				01	TASDEE	Use display format	

facility

# TERMINAL ATTRIBUTES TABLE (TAT) (Continued)

	Disp Hex	Label	Lng Dec		Description	on	
	01	TASAT2	1	Bits	Attribute	byte 2:	
					Hex Value	Symbol	Meaning
					80	TASREC	Data format is record mode
					40	TASBLK	Data format is block mode
					20	TASMSG	Data format is message mode
_					10	TASITB	Intermediate text block (ITB) checking support
					08	TASTSP	Transparency mode
					04	TASVFY	No exchange identification verification
					02	TASPAN	Spanned records supported
					01	TASVRL	Variable length records supported
	02-03	TASRCL	2	Bin	Record le	ength	
	04	TASBKF	1	Bin	Blocking	factor	

# TERMINAL NAME TABLE (TNT)

- Pointed to by \$CCCOM at hex 48.
- Entry length is 11 bytes.
- Specific entries pointed to by associated TUB at hex 20.

Disp Hex	Label	Lng Dec	Form	Description			
00-05	TNTNAM	6	Char	Symbolic terminal name			
06-07	TNTTUB	2	Addr	Address of associated TUB			
(06-07)	TNTTNT	2	Addr	Address of master TNT entry (for subterminal)			
08	TNTFLG	1	Bits	Flag byte for diagnostics:			
				Hex Value	Symbol	Meaning	
				80	TNTPRI	Primary name; otherwise, secon- dary name	
				40	TNTBLK	Blank name entry	
				20	TNTKNS	CONSOL name entry	
				10	TNTR5	TNT entry is used by current program request (\$CC4R5)	
09	TNTMCT	1	Mix	Multicomponent terminal indexes:			
				Bits	Meaning		
				0-3 4-7		nput component output component	
0A	TNTSTT	1	Bit	Index to STT (switched terminal table)			

#### **TERMINAL UNIT BLOCK (TUB)**

- Pointed to by \$CCCOM at hex 36.
- Entry length is 51 bytes.
- One TUB for each terminal in system.
- Built from TUT in \$CCPFILE.
- Pointed to by TCB at hex 39 if allocated to a task.
- All TUBs occupy contiguous storage.

Disp				
Hex	Label	Lng Dec	Form	Description
System P	arameter Lis	t within	TUB	
00-01	TPRTC	2	Bin	Return code
(00-01)	TPCHN	2	Addr	Parameter list chain address
02	TPOPM	1	Bin	Operation code modifiers
03	TPOPC	1	Bin	Operation code
04-05	TPOUTL	2	Bin	Output length
(04-05)	TPEFFL	2	Bin	Effective input length
06-07	TPINL	2	Bin	Maximum input length
08-09	TPRECA	2	Addr	Record area address
(08-09)	TPDATA	2	Addr	Data area address
0A-0B	TPTUBA	2	Addr	Terminal unit block address
(0A-0B)	ТРТСВА	2	Addr	Task control block address
0C	ТР\$ОРМ	1	Bin	Internal operation code modifier
0D	TP\$OP€	1	Bin	Internal operation code work area
(OD)	ТР\$МСТ	1	Bin	Multicomponent indexes
0E-0F	TP\$RTC	2	Bin	Internal return code work area Displacement in record area of data that accompanied a program request

## Terminal Identification and Address Characters

10-11	TUBID	2	Char	\$K =	physical ide Console mai Console SUI	n TUB
12	TUBSID	1	Bin		ternal termin 01 for Mode	nal identification I 4 console)
13	TUBSCS	1	Bits	BSCA sta	atus byte:	
				Hex		
				Value	Symbol	Meaning
				80	TUBCLR	Operator hit 3270 clear key
				40	TUBDME	Data mode escape check success
				20	TUBDMF	Data mode escape check failed
				10	TUBSWA	Switched line terminate handled
				08	TUBSSP	Started status
				04	TUBRUF	PRUF data on screen (3270 DFF)
(12-13)	TUBTMA	2	Addr	MLTA to	erminal addı	ress

Disp Hex	Label	Lng Dec	Form	Description	on	
14	TUBCHR	1	Bit	Terminal	characterist	ics:
				Hex Value	Symbol	Meaning
				80	TUBLNE	BSCA line; otherwise, MLTA line
				40	TUB@SL	Typewriter device at start of line
				20	TUBTYP	MLTA typewriter device
				10	TUBNID	Need identification at beginning of line
				08	TURCMN	Command capable terminal
				04	TUBMCT	Multicomponent terminal
				02	TUBOUT	Terminal capable of output
				01	TUBIMP	Terminal capable of input
15	TUBAT1	1	Bit	Terminal	attributes b	yte 1:
				Hex		
				Value	Symbol	Meaning
				80	TUBKNM	This TUB is the main console TUB
				40	TUBKNS	Subordinate console TUB
				20	TUBONL	Terminal online
				10	TUBSGN	Command terminal is signed on
				80	TUBQUE	Command terminal in /Q status
				04	TUBREQ	Terminal is requester of program
				02	TUBSWC	Terminal on switched
				01	TUBOFF	Command terminal sign-off default is HOLD
16	TUBAT2	1	Bit	Terminal	l attributes b	byte 2:
				Hex		
				Value	Symbol	Meaning
				со		Terminal in command interrupt mode
				80	TUBDTA	Terminal in data mode
				40		Terminal in command mode
				20	TUBIMI	Outstanding data from program request

Disp Hex	Label	Lng Dec	Form	Description	on	
16 (continue	d)			Hex Value	Symbol	Meaning
				10	TUBIIS	Invite or get scheduled
				80	TUBIIQ	Completed invite outstanding
				04	TUBOLT	Running online test on terminal
				02	TUBAPP	Allocation pending on this TUB
				01	TUBOWN	Terminal com- municating on BSCA line. EOT not sent or re- ceived
17	TUBAT3	1	Bit	Terminal	attributes b	yte 3:
				Hex		
				Value	Symbol -	Meaning
				40	TUBSPF	Stop polling failed
				20	TUBCNC	/RELEASE com- mand entered by terminal operator
				10	TUBERP	Terminal error; awaiting error recovery pro- cedures (ERP)
				04	TUBVFP	Vary offline pending
				02	TUBSPP	Stop polling pending to terminal in com- mand interrupt mode
				01	TUBSWL	Discard input data, terminal
					TUBINV	can be reinvited

Disp Hex	Label	Lng Dec	Form	Description	on	
Queue Ch	ain Fields					
18-19	TUBINQ	2	Addr	queue. D	uring progra , the addres	on invite input am request or s of the next TUB ame MRT program
1A-1B	TUBTCB	2	Addr	Address o	of task contr	ol block of owning
1C-1D	ТИВТИВ	2	Addr	Address o same task		belonging to
(1C-1D)	TUBPST	2	Addr	Address o		on allocation
1E-1F	TUBLCB or TUBDTF	2	Addr	Address o	of line DTF :	and line control
20-21	TUBTNT	2	Addr			ame table entry usiness as name)
22-23	TUBFSB	2	Addr		of first entry ecification b	for this terminal lock
24	тивотс	1	Bit	Terminal MLTA:	online test o	control byte for
				Hex Value	Symbol	Meaning
				FF 80	TUBLOP	Stop test Looping test specified
				40	TUBALL	Multiple tests specified
				(Bits 4-7)	TUBTNR	Binary number of single test

Lng

Disp

Hex	Label	Dec	Form	Description
Data Mo	de Escape Fie	lds		
25-26	TUBDML	2	Mix	If invite, saved input length. If get, saved address of parameter list
27	TUBCMA	1	Bin	Multicomponent terminal index for online test. The low-order bits (03) contain the displacement into the multicomponent terminal table for the input component. The high-order bits (4-7) contain the displacement into the multicomponent terminal table for the output component
28	TUBDMO	1	Bit	Operation code indicator for data mode escape: Hex Value Symbol Meaning
				00 Get operation; any other value indicates an invite operation
Current <sup>2</sup>	Terminal Attr	ibute S	et Fields	
29	TUBTAS	1	Bin	Index to the standard attribute set for this terminal in the terminal attributes set table
2A	TUBTA1	1	Bit	First byte of attributes in current attribute set. See definition of TASAT1 field of terminal attributes set for bit definition
2B	TUBTA2	1	Bit	Second byte of attributes in current attribute set. See definition of TASAT2 of terminal attributes set for bit

definition

attribute set

BSCA record length from current

2C-2D TUBRCL 2 Bin

Disp Hex	Label	Lng Dec	Form	Description	on	
(2D)	TUBVCS	1	Bin	area. The the displa compone input con bits (4-7) into the r	e low-order acement into terminal mponent. To contain the	table for the he high-order displacement nent terminal
2E	TUBBKF	1	Bin	BSCA blo		r from current
(2A-2E)	TUBCAS	5	Mix	currently	terminal att in use for t attribute set	his terminal
Terminal	Type Fields					
2F	TUBPHY	1	Bit	Physical 1	terminal typ	e:
				Hex Value	Symbol	Meaning
				09 08 07 06	TUB374 TUBCPU TUB375 TUB5M2	3741 CPU 3735 3275 Model 2
				05	TUB5M1	(1920) 3275 Model 1 (480)
				04	TUB7M2	3277/84/86 Model 2
				03	TUB7M1	(1920) 3277/84/86 Model 1 (480)
				02	TUB105	MLTA 1050
				01	TUBMLT	MLTA non- 1050
				00	TUBCON	Console

Disp Hex	Label	Lng Dec	Form	Descript	ion	
30	TUBPCS	1	Bin	compon order bi- into the table for as the pr order bi- into the for the co	multicompo input comp imary input ts (4-7) conta multicompo	The low- sin the displacemen nent terminal onent to be used device. The high- ain the displacement nent terminal table onent to be used
31	TUBVHR	1	Bin	Save are	a for TUBCH	IR for MLTA
32	TUBAT4	1	Bin	Termina	al attribute b	yte 4:
				Hex Value	Symbol	Meaning
				80	TUBBSY	Printer busy
				40	TUBWAT	Task waiting
				20	TUBPRT	Printer TUB
				10	TUBRSP	Stop polling
						successful

#### TRANSIENTS

Disp Hex	Label	Lng Dec	Form	Description
Beginnin	g of a CCP Ti	ransient		
00-01	TARLD@	2	Disp	Offset from the beginning of the transient to the relocation address tabl (After fetch by the transient area handler, it is replaced with a hex F287 (jump op code + Q byte).)
02	TAJUMP	1	Disp	Offset from the beginning of the transient to the first instruction to be executed
03	TAID	1	Bin	Transient area ID value:
				Hex Value Meaning
				02 Communications task transient area 01 All other tasks transient area
04-05	TAXPRM	2	Mix	Parameter passed from one transient to another during an XCTL operation
06-07	TAXTID	2	Disp	Offset from the beginning of the transient to the disk address of the routine that can be called (Initially contains value to first disk address field TAXNCS.)
08-09	TAXCID	2	Char	Two-character suffix of the name of the first transient that can be called
0A-0C	TAXNCS	3	-	Three-byte disk address and length of first called transient
(0A)		1	Bin	Number of text sectors in the called transient
(0B-0C)	2	2	C/S	Disk address of called transient
0D+		1	Char	Stopper at end of transient list is \$
0E+		2	Char	Two-character suffix of this transient's name
10+		1	Bin	Distribution level number of this transient

#### TRANSIENTS (Continued)

Disp Lng
Hex Label Dec Form Description

#### Relocation Address Table in a CCP Transient

The relocation address table is found in every CCP transient and is located following the user code and preceding its RLDs. All the numbers are absolute. There are three possible types of addresses in the relocation address table. They are:

TYPE 1 2 Bin LABEL -P is hex 0XXX
Where P (defined as EQU \$CC4xx,
where \$CC4xx is the module name on
the START statement) Refers to the
beginning of the module and is for
reference within the module

TYPE 2 2 Bin COM + LABEL is hex COXX
Where COM (defined as EQU hex C000)
refers to the beginning of CCP communication area

TYPE 3 2 Bin PGM + LABEL is hex 80XX
Where PGM (defined as EQU hex 8000)
refers to the beginning of CCP resident
module entry points address table for
references to resident CCP routines
(That table is defined at the beginning
of CCP transient area and is overlaid by

the first transient loaded.)

#### DFF Data Areas

#### DEGRICOMMON AREAS

- Bytes 00-84 (hex) are internal constants.
- Used to pass information from \$CC2CF to \$CC2CP.
- Contains information about the FDT and text stream that is being built.

Disp Hex	Label	Lng Dec	Form	Description
85	смтот#	1	Bin	The length, in sectors, of the display format
86	CMFDTL	1	Bin	The length, in sectors, of field descripto table
87	CMTXTL	1	Bin	The length, in sectors, of 3270 data stream
88-8D	CMNAME	6	Char	Display format name (\$Z)
8E-8F	CMSFDT	2	Addr	Address of the field descriptor table
90-91	CMNDFT	2	Addr	Address of field descriptor table end
92-93	CMSTTX	2	Addr	Address of 3270 data stream
94-95	CMTEXT	2	Addr	Address of 3270 data stream end
96	CMERRT	1	Bin	Indicator of errors in format generation
97-98	CMAXDS	2	Bin	Maximum line/position address for this format
99	CMQCOD	1	Bin	$\boldsymbol{\Omega}$ code of pack on which to put display format

#### PFGR COMMON AREA

Disp Hex	Label	Lng Dec	Form	Description
8B-90	CMNAME	6	Char	Printer format name (\$Z)
91	CMTOT#	1	Bin	The length, in sectors, of the printer format
92	CMFDTL	1	Bin	The length, in sectors, of field descriptor table
93	CMTXTL	1	Bin	The length, in sectors, of 3270 data stream
94-95	CMSFDT	2	Addr	Address of the field descriptor table

#### PFGR COMMON AREA (Continued)

Disp Hex	Label	Lng Dec	Form	Description
96-97	CMNDFT	2	Addr	Address of field descriptor table end
98-99	CMSTTX	2	Addr	Address of 3270 data stream
9A-9B	CMTEXT	2	Addr	Address of 3270 data stream end
9C-9D	CMTMTX	2	Addr	Temporary address of 3270 data stream end
9E	CMERRT	1	Bin	Indicator of errors in format generation
9F	CMQCOD	1	Bin	Qcode of pack on which to put printer format

#### DFF FIELD DESCRIPTOR TABLE (FDT)

FDT is pointed to by PAS at hex 06-07. The FDT describes the fields associated with the current 3270 format attached to this particular user program.

Disp		Lng			1
Hex	Label	Dec	Form	Description	١

## First Entry (Format Physical Attributes)

00	FDTTSN	1	Bin	Number occupies		ne text stream
01-02	FDTTSL	2	Bin		to put this	output hold area entire format in
03-04	FDTTSI	2	Bin		to receive a	input record area Il fields for an
05	FDTM#	1	Bits	Format a	attributes:	
				Hex		
				Value	Symbol	Meaning
				04	FDTNDT	Data should be given for put message of format
				02	FDTM#2	Model II (1920 format
				01	FDTM#1	Model I (490) format

## DFF FIELD DESCRIPTOR TABLE (FDT) (Continued)

Disp Hex	Label	Lng Dec	Form	Descript	tion	
06	FDTNS	1	Bin	Number object li		ne FDT occupies in
07-08	FDTWRK	2	Mix	Calculat	ion/work are	ea
09	FDTWK2	1	Mix	Calculat	ion/work are	ea .
0A	FDTCFG	1	Bits	Format	attributes:	
				Hex Value	Symbol	Meaning
				80	FDT11	This format has a field whose first data position is in row 1, column 1.
				08	FDTPRT	Format generated by PFGR
Field E	ntry (14 Bytes	Each:	17 Entries	s in First S	Sector, 18 in	All Other Sectors)
00-05	FDTNAM	6	Char	Name of	f this field, le	eft-justified
06	FDTFLG	1	Bits	Field ch	aracteristics	:
				Hex Value	Symbol	Meaning
				80 40 20 10	FDTIF FDTOF FDTOIF FDTDSF	Input field Output field Output/input field Selector pen detectable/attention field
				08 04	FDTANF FDTSBF	Numeric field Source data for this field pro- vided during put message
07	FDTLNG	1	Bin	Length	of data for ti	his field
08-09	FDTAT@	2	Addr	3270 te: attribute		field defining
0A-0B	FDTDT@	2	Addr	characte is SPD/S	er of data for	leftmost (first) this field (If field he address of .)
0C-0D	FDTDTD	2	Disp			270 text stream to of noninput type field

## DFF TERMINAL TABLE (TT)

- Pointed to by PAS at hex 00-01.
- The TT describes the terminal and the format currently in use by this terminal.

Disp		Lng		
Hex	Label	Dec	Form	Description
00-01	TTCHN@	2	Addr	Address of next TT entry (High-order byte contains zero if it is the last entry.)
02-07	TTNAME	6	Char	Terminal name
08-09	TTFT@	2	Addr	Address of display format table (FT) entry currently used by this terminal
0A-22	TTIFT	25	Bits	Input format table (IFT) (Contains 200 bits, one for each possible nonoutput field used to determine if field should be returned in input record area in user's program. The first nonoutput field corresponds to bit 7 in rightmost byte hex 22 in IFT. The next nonoutput field (as described in the FDT) corresponds to bit 6, etc.)  Bit On = Data for this field should be placed in input record area.  Bit Off = Data for this field is not expected in the input record area. If data is received from the terminal for this field, ignore it.
23-24	TTINLH	2	Bin	Length of hold area space needed for 3270 text for next input operation

#### DFF FORMAT TABLE (FT)

- Pointed to by PAS at hex 00-01.
- The FT describes the format and location of FDT for this format.

<b>'</b>	Disp Hex	Label	Lng Dec	Form	Description	on	
	00-01	FTCHN@	2	Addr	format ta		points to next High-order byte is try.)
)	02-07	FTNAME	6	Char	Name of	display for	mat
	08-09	FTFCS	2	C/S	5444 C/S	of FDT fo	r this format
	0A	FTDTL	1	Bin	Number	of sectors F	DT occupies on disk
	0B-0C	FTTSCS	2	C/S	5444 C/S	of beginni	ng of 3270 text
)	0D	FTTSL	1	Bits	Format a	ttributes:	
					Hex Value	Symbol -	Meaning
					Bits 1-7		Number of sectors 3270 text occupies in object library
					80	FTM#2	Format for Model 2 terminal; otherwise, format for Model 1 terminal
	0E-0F	FTOUTL	2	Bin	Byte leng		text for output
)	10-11	FTINL	2	Bin	Byte leng	-	text to expect for

#### **DFF PROGRAM APPENDED STORAGE (PAS) CONSTANTS** AND WORK AREAS

PAS is pointed to by hex 54-55 in the user's TCB.

PAS serves as a communications area between DFF and the user task.

Disp Hex	Label	Lng Dec	Form	Description
00-01	PASITT	2	Addr	Address of first terminal table (TT) entry. (The first format table (FT) entry follows the first TT entry.)
02-03	PASNFT	2	Addr	Address of next available area for a TT or FT entry
04-05	PASEFT	2	Addr	Address of last byte to use for TT and FT entries (end of TT and FT area)
06-07	PASFDT	2	Addr	Address of beginning of area to contain field descriptor table (FDT) and format index
80	PASTID	1	Char	Task ID character
09	PASFDL	1	Bin	Number of 256-byte blocks available for FDT
0A-0B	PASCT@	2	Addr	Address of TT entry currently processing
0C-11	PASCTN	6	Char	Symbolic terminal name currently processing
12-13	PASCF@	2	Addr	Address of FT entry currently processing or whose FDT is currently in PAS
14-15	PASFR@	2	Addr	Address to return to from DFF000
16-17	PASJR@	2	Addr	Address to return to from DFJ000
18-19	PASXR@	2	Addr	Common save area for return addresses of miscellaneous routines
1A-1B	PASRE@	2	Addr	Address of function determination to return for completion of processing of an operation for which there are two calls from \$CC4II
1C-1D	PASOH@	2	Addr	Beginning address of output hold area (OHA) currently in use by this task
1E-1F	PASOHL	2	Bin	Length in bytes of OHA
20-21	PASOHE	2	Addr	Address of last byte of OHA

## DFF PROGRAM APPENDED STORAGE (PAS) CONSTANTS AND WORK AREAS (Continued)


)	Disp Hex	Label	Lng Dec	Form	Description						
	Copy Text and Work Area										
	22-23	PASCP@	2	Addr	Beginning address of copy text						
)	24	PASCPY	1	Disp	Beginning displacement into PAS of copy text						
	24	PASCES	1	Char	3270 escape character						
	25	PASCCM	1	Char	3270 copy command						
	26	PASCCC	1	Char	3270 copy control character						
)	27	PASCFM	1		From terminal device address character						
	28-29	PASTOD	2	Addr	Address of To TT entry						
				Char	To terminal control unit and device characters						
	2A-2B	PASFRD	2	Addr	Address of From TT entry						
				Char	From terminal control unit and device characters						
	EAU Tex	t and Work A	rea								
	2C-2D	PASEU@	2	Addr	Beginning address of EAU text						
)	2E	PASEQU	1	Disp	Displacement into PAS to beginning of EAU text						
,	(2E)	PASEUE	1	Char	3270 escape character						
	2F	PASEUC	1	Bin	3270 EAU command						

# DFF PROGRAM APPENDED STORAGE (PAS) CONSTANTS AND WORK AREAS (Continued)

Disp Hex	Label	Lng Dec	Form	Descripti	ion			
30	PASFLG	1	Bit	Flag byte	Flag byte:			
				Hex Value	Symbol	Meaning		
				80	PASFRT	To terminal name (COPY); otherwise, From terminal name (COPY)		
				20	PASRST	Reset modified data tags speci- fied in user's WCC		
				10	PASBLK	Blocking of output text needed		
				08	PASFTS	First time switch for blocking; otherwise, second or succeeding block		
				04	PASRUF	Request under format accept input		
31-47	PASIOB	23	Mix	Disk 10E	3			
48-49	PASPL@	2	Addr	Address	of users par	ameter list		
(4A)	PASCPL		Disp			peginning of PAS d user parameter		
4A-59	PASCPE	16	Mix	Save area	a for users p	parameter list		
5A-5B	PASIX1	2	Addr	Save are: \$CC411	a for XR1 u	pon entry from		
5C-5D	PASIAR	2	Addr	Returna	ddress to \$	CC4II		
5E-5F	PASOF@	2	Addr		of FDT ent an output o	ry currently working operation		
60-61	PASHAP	2	Addr	Points to	the curren	t position in OHA		
62-63	PASRAP	2	Addr			of field name or user's output record		

## DFF PROGRAM APPENDED STORAGE (PAS) CONSTANTS AND WORK AREAS (Continued)

Disp Hex	Label	Lng Dec	Form	Description
64-65	PASTTE	2	Addr	Address of empty (available) TT entry (A blank in first character of terminal name indicates an empty entry.)
66-6B	PASCFT	6	Char	Name of desired format for a put operation
			Addr	High-order 2 bytes contain address in output record of error detected by \$CC4DB
6C	PASTC	1	Bin	Termination code if other than 00
6D-6E	PASTTS	1	Bin	Total text length for a put operation
6F-70	PASTTM	2	Bin	Length of text moved or put at this time (used mainly for blocking)
71-72	PASLTH	2	Bin	Total (gross) end position of text currently in OHA
73-74	PASUDL	2	Bin	User defined length of data provided for output
75	PASWCC	1	Char	User's WCC (write control character)
76-77	PASTAR	2	Addr	Save area for return address of caller (within DFCR) of a routine (within DFCR) that might be interrupted to allow a task switch
78-79	PASWRK	2	Mix	Work area for calculations
7A-7B	PASWKZ	2	Mix	Work area high-order byte is always hex 00
7C-7F	PASFRN	4	Char	Request under format name
80-82	PASEND	2	_	Reserved
83	PASL	1	Char	Request under format name



# Installation Verification Program Disk Record

## DISK RECORD CREATED BY CCPIVP

Disp Hex	Label	Lng Dec	Description
00-02		3	Data characters entered from console on an input request by CCPI VP
03		1	Always an asterisk (*)
04-08		8	Data characters entered with the program request for CCPIVP from the console (If fewer than eight characters are entered, they are left-aligned, and the field is padded with blanks.)
ос		1	Always an asterisk (*)
0D-0F		3	Record number—in record representing first input request from console, 001; in record representing next, 002; etc.

.

#### Main Storage During CCP Execution

#### **\$CC4 Load Modules**

\$CCCOM CCP communication area

Transient area 1 (noncommunication)
Transient area 2 (communication)
Command processor work area

Allocating work area
Termination work area
Communication work area
Console management work area
Console buffer

System task control blocks (TCB)

Console main and subterminal unit blocks

First level transient list \$CC4#3 Model 12 remap area \$CC4DF Model 12 remap area

\$CC4DP Task dispatcher and I/O scheduler

\$CC4IO IOS intercept \$CC4IW IOS wait intercept

DPTIAR Routine to determine program level

\$CC41H Common interrupt handler

\$CC4WT Wait \$CC4PS Post

\$CC4IG General entry intercept \$CC4DI Disk queue routine \$CC4II TP I/O interface (user) \$CC4IS TP I/O interface (system) \$CC4Z9 User security information

Maintenance area

\$CC4CM Communications management

\$CC4CP Command processor \$CC4RM Allocate

\$CC4OC Open/close \$CC4TI Terminator

CPHALT

\$CC4PI Transient area handler

\$CC4TX XCTL routine \$CC4TR Transient return \$CC4TT Trace interface

Disaster (U-) halt routine

\$CC4PQ Determine selected terminal status \$CC4MX Move/clear routine

\$CC4IC Console interrupt handler

\$CC4IB BSCA interrupt handler

BSCA IOCS

\$CC4BT BSCA trace interface \$CC4IM MLTA interrupt handler

MLTA IOCS

\$CC4MS GETMAIN/FREEMAIN routine

#### OPTIONAL LOAD MODULES

\$CC\$TR CCP trace routine

CCP trace table

\$CC\$SA Service aid module

\$CC\$BS BSCA trace routine \$CC\$ML MLTA trace routine

#### CONTROL BLOCKS AND DATA AREAS

Program request count tables
Terminal attribute table (TAT)

MLTA adapter DTF

MLTA line 1 DTF/LCB line control block

cated for MLTA line 1 polling list lines 2-8 MLTA line 1 line buffer

ines 2-8 | MLIA line 1 line buffer

These areas | BSCA DTF/LCB line control block

are dupli- BSCA ASCII translation buffer cated for BSCA addressing list

line 2 BSCA statistical data recorder (SDR)

Checklist

These areas

Terminal unit blocks (TUB)
Terminal name table (TNT)
Task control blocks (TCB)
Contents directory entries (CDE)

Short disk DTFs (SDF) and storage index area

Symbolic file tables (XDT)

Master track index area

Sector enqueue blocks (SQB)

File consistent blocks (FSR)

File specification blocks (FSB)

Dynamic teleprocessing buffer area

#### DISPLAY FORMAT FACILITY


\$CC4DF Display format control routine<sup>1</sup>

DFF output hold area


User programs and program appended storage (PAS)

<sup>&</sup>lt;sup>1</sup> Model 12: Only the DFF output hold area and PAS, if \$CC4DF is in the remap area.


#### **Execution Time Control Blocks**





Note: All lengths are in decimal. All displacements are in hexadecimal. Symbolic file associations are not shown here.




## Storage Allocation










## Symbolic File Support


If, during CCP execution, a command terminal operator enters:

#### /FILE XYZ, ABC

Then compile time file name XYZ is associated with OCL file name ABC. The compile time file name is the name specified in a source program. The OCL file name is the name (not label) specified in a //FILE statement when CCP is loaded.

#### Symbolic File Association







Note: All DTFs associated with a given SDF are chained together. However, if NOSHARE is in effect, the chain must be contained in one program.

#### How-to-Find Diagrams

#### HOW TO FIND SCCCOM WITHOUT REMAP



# HOW TO FIND \$CCCOM WITH REMAP (DURING CCP EXECUTION ONLY)




Note: Logical-to-real address translation factors:

80K: Logical address + X'4000' = real address 96K: Logical address + X'8000' = real address


#### If address in \$CC4#3/\$CC4DF:

Logical address + xxxx = real address, where xxxx is a two-byte value found in \$CCCOM at X'CA'


#### HOW TO FIND THE SYSTEM TASK CONTROL BLOCK (TCB)




## HOW TO FIND THE USER TASK CONTROL BLOCK (TCB)




#### HOW TO FIND THE USER PROGRAM AREA BOUNDARIES




# HOW TO FIND A PARTICULAR USER PROGRAM'S BOUNDARIES




# HOW TO FIND USER PROGRAM AREA AVAILABLE SPACE BOUNDARIES




# HOW TO FIND A USER PROGRAM MODULE BY ACTIVE TASK CONTROL BLOCK




# HOW TO FIND A USER PROGRAM MODULE BY CONTENTS DIRECTORY ENTRY




## HOW TO FIND A USER TASK'S LAST TELEPROCESSING.




### HOW TO FIND TERMINAL UNIT BLOCKS BY TERMINAL ID




## HOW TO FIND TERMINAL UNIT BLOCKS BY SYMBOLIC TERMINAL NAME




#### HOW TO FIND THE COMMUNICATIONS BUFFER AREA




#### HOW TO FIND THE LAST COMMUNICATIONS PARAMETER LIST





#### HOW TO FIND THE TELEPROCESSING DTFs (MLTA/BSCA)




## HOW TO FIND THE TELEPROCESSING LINE BUFFERS








#### HOW TO FIND THE TELEPROCESSING LINE QUEUE




Note: High-order byte of hex 00 marks the end of the line queue.

# HOW TO FIND THE INVITE INPUT HOLD BUFFER FOR A TELEPROCESSING LINE




Note: High-order byte of hex 00 indicates no hold buffer for the line.

#### HOW TO FIND THE CONSOLE BUFFER




#### HOW TO FIND THE CONSOLE OUTPUT QUEUE




Note: High-order byte of hex 00 indicates the end of the queue.

#### HOW TO FIND THE CONSOLE INPUT QUEUE




Note: High-order byte of hex 00 indicates the end of the queue.


## HOW TO FIND TERMINAL ATTRIBUTE SETS IN THE TERMINAL ATTRIBUTE TABLE




#### HOW TO FIND THE TUBS (TERMINALS) OWNED BY A TASK




## HOW TO DETERMINE THE TERMINAL OPERATOR'S/FILE SPECIFICATIONS




## HOW TO FIND MAIN STORAGE MANAGEMENT ALLOCATED STORAGE BOUNDARIES AND FREE STORAGE CHAINS




### HOW TO FIND TELEPROCESSING BUFFER LOCATION AND LENGTHS



#### HOW TO FIND THE CCP TRACE TABLES



#### HOW TO FIND THE MLTA TRACE



Hex 40 line 7

Hex 20 line 6 Hex 10 line 5


Hex 08 line 4

Hex 04 line 3

Hex 02 line 2 Hex 01 line 1

- Activated by TRACEMLTA specification during startup.
- During execution the command TRACE (ON, OFF), MLTA controls dumping of the trace table to the printer whenever a permanent error occurs on an MLTA line.

#### HOW TO FIND THE BSCA TRACE



During execution the command TRACE (ON, OFF), BSCA controls dumping of the trace table to the printer whenever a permanent error occurs at a BSCA terminal.

Activated by TRACEMLMP specification during startup.

## Traces

## CCP TRACE

Disp		
Hex	Description	

## Type 01 - Dispatcher Initial Entry

Type OT — I	Dispatcher	Tintial Elicty		
00	Trace type 01			
01	TCBID o	TCBID of TCB		
02	\$DPFLG	from \$CCCOM:		
	Hex Value	Meaning		
	80 40 10 08	Save registers in current TCB Make task nondispatchable Must complete status Allow interrupt processing		
03	Number	of 5471 op ends since last 01 trace		
04	Number	of MLTA op ends since last 01 trace		
05	Number	Number of BSCA op ends since last 01 trace		
06-07	ARR at dispatcher entry			
08-09	XR1 at o	dispatcher entry		
0A-0B	XR2 at c	lispatcher entry		
0C-0D	Wait mas	k (indicates what task is waiting for):		
	Byte 1			
	Hex Value	Meaning		
	80 40 20 10 08 04	Communications I/O request completion Disk I/O completion Accept input completion Shutdown request Transient area 1 available Enqueued data sectors		

Disp Hex Description (0C-0D, Byte 2 continued)

Hex	
Value	Meaning
80	Main storage availability
40	Disk file allocation
20	Unit record allocation
10	Terminal allocation
80	DSM availability
04	Unit record ready
02	DFF hold area space

OE Number of events to take place before redispatching

OF \$DPFLH from \$CCCOM:

Hex	
Value	Meaning
80	A task has entered DSM
40	Suppress task
20	Post has made a task dispatchable
10	User task suspended
80	A task is in must complete status
04	Dispatcher halted, awaiting interrupt
02	A console interrupt exists

If bytes C, D, and E are hex BF, FF, and FF, and the current task ID is T, the trace indicates the completion of the termination task.

+00	Trace Type 01	Active TCBID	\$DPFLG	Number of 5471 Interrupts
+04	Number of MLTA Interrupts	Number of BSCA Interrupts	CCA	RR
+08	cc	CR1	CC	KR2
+0C	TCB Wa	nit Mask	TCB Event Count	\$DPFLH

Disp

Hex Description

#### Type 02 - Dispatcher NCEIOS Intercept

00 Hex 02 disk IOS intercept

01 Current TCB ID

02 Q byte from IOB

03 R byte from IOB

04-05 C/S (5444) C/H (5445) from IOB

06-07 ARR save area

08-09 XR1 save area (IOB address)

0A-0B XR2 save area

OC-OD Contents of IOB chain field (for CCP XCTL, this is two-character

suffix of module name)

0E IOB completion code (N/A for CCP XCTL)

0F

Hex	
Value	Meaning
80	DSM has been entered by a task
40	Suppress trace
20	A task has been made dispatchable
10	A user task is suspended
80	A task is in must complete state
04	Dispatcher halted, awaiting interrupt
02	A console interrupt exists
01	Dispatcher entered via \$CC4IH (interrupt handler) and

Dispatcher entered via \$CC4IH (interrupt handler) and a user task is suspended

+00	Trace Type 02	Issuer's TCBID	IOBQB	IOBRB
+04	IOBCD	IOBSB	Issuer's	ARR
+08	ISSUER'S XR1 -	Addresses (IOB)	Issuer's	XR2
+0C	IOBCHN/Calle	d Transient ID	IOBCMP/ Undefined	\$DPFLH

Disp

Hex Description

Type 03 - Dispatcher NCEIOW Intercept

00 Hex 03 disk wait intercept

01 Current TCB ID

02 Q byte from IOB

03 R byte from IOB

04-05 C/S (5444) C/H (5445) from IOB

06-07 ARR save area

08-09 XR1 save area (IOB address)

0A-0B XR2 save area

OC-OD Contents of IOB chain field (for CCP XCTL, this is two-character

suffix of module name)

OE IOB completion code

ΩF

Hex

Value Meaning

80 DSM has been entered by a task40 Suppress trace

20 A task has been made dispatchable

10 A user task is suspended

08 A task is in must complete state

04 Dispatcher halted, awaiting interrupt

02 A console interrupt exists

01 Dispatcher entered via \$CC4IH (interrupt handler) and

a user task is suspended

+00	Trace Type 03	Issuer's TCBID	ΙΟΒΩΒ	IOBRB
+04	IOBCD	IOBSB	CCA	RR
+08	CCXR1		CC>	R2
+0C	IOBÇHN		IOBCMP	\$DPFLH

Traces

Disp

Hex Description

Type 04 - NCEIOW Entry from Dispatcher

00 Hex 04 dispatcher invoking disk wait

Ω1 TCB ID associated with IOB

02 Q byte from IOB

03 R byte from IOB

04-05 C/S (5444) C/H (5445) from IOB

06-07 ARR save area

08-09 XR1 save area (IOB address)

0A-0B XR2 save area

0C-0D Contents of IOB chain field (for CCP XCTL this is a two-character

suffix of module name)

0E IOB completion code

0F

Hex Value

80 DSM has been entered by a task

Meaning 40 Suppress trace

20 A task has been made dispatchable

10 A user task is suspended

nε A task is in must complete state

04 Dispatcher halted, awaiting interrupt

02 A console interrupt exists

01 Dispatcher entered via \$CC4IH (interrupt handler) and

a user task is suspended

					_
+00	Trace Type 04	IOBTCB TCBID	IOBQB	IOBRB	
+04	IOBCD	IOBSB	Not Mean	l ingful I	
+08	Dispatcher's XR1	Addresses (IOB)	IOBTCB (own	ing TCB @)	•
+0C	IOB	CHN	IOBCMP	\$DPFLH	

Disp	
Hex	Description

Type	05 _	Coneral	Entry	Intercept
I VDe	UD -	General	Entry	Intercept

00	Hex U5 general entry intercept
01	TCB ID of task invoking general entry

02

03 04-05

Hex	
Value	Meaning
80	Save registers in current TCB-
40	Make task nondispatchable
10	Must complete state
08	Allow interrupt processing
Reserve	ed
	ts at ARR +2, 3 (for RIB hex 80,C0 sector and $\#$ sectors -1; ise, insignificant)
ΔRR «	ave area

06-07 ARR save area
08-09 XR1 save area

OA-OB	XR2 save area (for RIB hex 01,00, address of communications parameter list)			
0C	Contents	at ARR +0, 1 the RIB and (for CCP requests) sub-RIB		
0E				
	Hex Value	Meaning		
	80 40 20 10 08 04 02	DSM has been entered by a task Suppress trace A task has been made dispatchable A user task is suspended A task is in must complete state Dispatcher halted, awaiting interrupt A console interrupt exists Dispatcher entered via \$CC4IH (interrupt handler) and a user task is suspended		
OF	Reserved			

+00	Trace Type 05	Issuer's TCBID	\$DPFLG	Reserved
+04	Third and Four after B		Issuer's	ARR
+08	Issuer's XR1		Issuer's XR2 (parame	
+0C	First Two Inline B	ytes after Branch	Reserved	\$DPFLH

D	i	s	р	,

0C-0D

Hex Description

## Type 06 - Transient Request

00 Hex 06 transient request

01 Current TCB ID

02 Q byte of CCP pack

03 R byte from IOB

04-05 Disk address of requested transient

06-07 ARR of calling routine

08-09 XR1 of calling program

0A-0B XR2 of calling program

Two-character suffix of requested transient

0E-0F Parameter passed to requested transient

-00	Trace Type 06	TCBID	IOBQB	IOBRB
04	IOBCB	IOBSB	ТСВА	RR
-08	тсвх	R1	тсвх	R2
-0C	Two-Character Requested		TAXP	RM

	CCF THACE	NACE (Continued)		
_	Disp Hex	Description	on	
	Туре 07 — Е	ntry to Post (\$CC4PS)		
	00	Hex 07 e	ntry to post	
	01	Current T	CB ID	
	02			
		Hex Value	Meaning	
	)	80 40 10 08	Save registers in current TCB Make task nondispatchable Must complete state Allow interrupt processing	
	03	Posted T	CB ID (insignificant if general post)	
	04-05	Address	of TCB to be posted (hex 00XX if general post)	
	06-07	ARR save	e area (address of post list)	
	08-09	XR1 save	area	
	0A-0B	XR2 save	e area	
	oc	Post mas	k (indicates completed event):	
		Hex Value	Meaning	
		80 40	Communications I/O request Disk I/O request	

Accept input

Shutdown request

Transient area 1 available

	04	Enqueued data sectors
OD	Post mas	k continued:

20

10

80

Value Meaning  80 Main storage available 40 Disk file allocated 20 Unit record allocated 10 Terminal allocated 08 DSM available 04 Unit record ready 02 Hold area available for DFF	Hex	
40 Disk file allocated 20 Unit record allocated 10 Terminal allocated 08 DSM available 04 Unit record ready	Value	Meaning
20 Unit record allocated 10 Terminal allocated 08 DSM available 04 Unit record ready	80	Main storage available
10 Terminal allocated 08 DSM available 04 Unit record ready	40	Disk file allocated
08 DSM available 04 Unit record ready	20	Unit record allocated
04 Unit record ready	10	Terminal allocated
	08	DSM available
02 Hold area available for DFF	04	Unit record ready
	02	Hold area available for DFF

Disp

Hex Description

0E Not used

0F

Hex Value Meaning

80 DSM has been entered by a task

40 Suppress trace

20 A task has been made dispatchable

10 A user task is suspended

08 A task is in *must complete* state 04 Dispatcher halted, awaiting interrupt

02 A console interrupt exists

01 Dispatcher entered via \$CC4IH (interrupt handler)

and a user task is suspended

+00	Trace Type 07	Poster's TCBID	\$DPFLG	Postee's TCBID
+04	Addresses (TCB to	post)/00xx if All	cc	ARR
+08	cc	XR1	СС	XR2
+0C	Post	Mas k	Reserved	\$DPFLH

#### Type 08 - Entry to GETMAIN (\$CC4GM)

00 Hex 08 GETMAIN

01 TCB ID of requesting task

02-03 First free segment address after GETMAIN

04-05 Largest free segment size after GETMAIN

06-07 ARR save area

08-09 XR1 save area (address of storage control block)

0A-0B XR2 save area (address of GETMAIN parameter)

OC-0D Address of storage area secured by GETMAIN (hex 0000 if

unsuccessful)

0E-0F Size of storage area secured

+00	Trace Type 08	Issuer's TCBID	SCBCHN	
+04	SCB	MAX	CCARR	
+08	Issuer's XR1—A	Addresses (SCB)	Issuer's XR2-Addresses (parameter list)	
+0C	Address Gotten	0000 if Failed	GMSIZE	

Disp

ററ

02 03

Description Hex

#### Type 09 - Entry to FREEMAIN (\$CC4FM)

00 Hex 09 FREEMAIN

01 TCB ID of requesting task

02-03 First free storage address before FREEMAIN

04-05 Largest free storage size before FREEMAIN

06-07 ARR save area

XR1 save area (address of storage control block) 08-09

0A-0B XR2 save area

0C-0D Address of storage being freed

0E-0F Size of storage being freed

+00	Trace Type 09	Issuer's TCBID	SCBC	<del>I</del> N
+04	SCBI	MAX	CCAF	IR
+08	Issuer's XR1-A	Addresses (SCB)	Issuer's XR2- (paramete	
+0C	GMA	DDR	GMSI	ZE

### Type 0A - \$CC4CM Return from IOCS after CHECK on Op End

01 C'C' TCB ID for communication manager

Hex 0A op end interrupt

DTF op code after interrupt

Completion code after interrupt

04-05 Length of the operation \$MDCRL or \$BDREL

06-07 TUB address for which interrupt occurred

08-09 Communications parameter list address

0A-0B Teleprocessing DTF address

0C-0D Record area address

0E Number of outstanding op end interrupts (those requiring a check)

Disp Hex

Description

0F

Hex	
Value	Meaning
80	Terminal in data mode
40	Terminal in command mode
20	Outstanding program data
10	Invite or get scheduled
80	Complete invite outstanding
04	Online test running
02	Allocation pending
01	If BSCA, EOT not sent or received
C0	Terminal in command interrupt mod
	80 40 20 10 08 04 02

+00	Trace Type 0A	TCBID = C	\$MDOPC/ \$BDOPC	\$MDCMP/ \$BDCMP
+04	MLTA-S BSCB-\$I		Addresse	s (TUB)
+08	CM's XR1- (paramet	l .	CM's XR2-Ad	l dresses (DTF)
+0C	\$BDW	KB	CCOECT	TUBAT2

### Type 0B/1B - \$CC4CM Return from IOCS after Start I/O

Hex 0B MLTA I/O request from resident code

## Trace 0B - MLTA

00

01	C'C' TCB ID for communication manager
02	MLTA operation code
03	Operation start code from IOCS (if nonzero, an error condition exists)
04-05	Size of largest segment in teleprocessing buffer area
06-07	TUB address
08-09	Communications parameter list address
0A-0B	MLTA line DTF address
0C-0D	Internal CCP op code from communications parameter list PL\$PM and PL\$OPC
0E-0F	User specified operation code

	Disp	
<b>\</b>	Hex	Description

0C-0D

Trace 1B - I	BSCA
00	Hex 1B BSCA I/O request from resident code
01	C'C' for communication manager
02	Operation code
03	I/O request completion code (should be zero)
04-05	Size of largest available segment in teleprocessing buffer
06-07	TUB address
08-09	Communication parameter list address
0A-0B	BSCA line DTF address

0E-0F External operation code

PL\$OPM and PL\$OPC

+00	Trace ID-0B/1B	TCBID = C	\$MDOPC/ \$BDOPC	\$MDOSC/ \$BDCMP
+04	SCBM	AX	Addresses (TUB)	
+08	CM's XR1—Addresses (parameter list)		CM's XR2-Add	resses (DTF)
+0C	PL\$OPM	PL\$OPC	PLOPM	PLOPC

Internal CCP operation code from communications parameter list

Disp Hex

Description

### Type 0C - \$CC4II Entry to User I/O Interface

00 Hex 0C user I/O request

Hex

TCB ID of task that issued request

02 Number of outstanding invites from this task

03

04-05

08-09

0E-0F

01

Value	Meaning
80	Terminal in data mode
40	Terminal in command mode
20	Outstanding program data
10	Invite or get scheduled
08	Completed invite outstanding
04	Online test running
02	Allocation pending
01	If BSCA, EOT not sent or pending
CO	Terminal in command interrupt mode
Size of I	argest available segment in teleprocessing buffe
	- g g

06-07 TUB address

Communication parameter list address

0A-0B TNT address

0C-0D Record area address

User op code

+00	Trace Type 0C	Issuer's TCBID	TCBIIC	TUBAT2
+04	SCBMAX		Addresses (TUB)	
+08	Addresses (parameter list)		Addresses (TNT e	ntry)/Undefined
+0C	PLRECA		PLOPM	PLOPC

Disp

06-07

Hex Description

Type 0D - \$CC4IS Entry to System I/O Interface

00 Hex 0D system I/O request

01 TCB ID of requesting task

02 Op code from DTF

03 Attribute byte 2 from DTF

04-05 Size of largest available segment of teleprocessing buffer

TUB address

08-09 Communication parameter list address

0A-0B If MLTA, terminal address from DTF

0C-0D Record area address

0E-0F Op code from parameter list

+00 Trace Type 0D Issuer's TCBID \$MDOPC \$MDAT2 Addresses (TUB) +04 SCBMAX Addresses (parameter list) \$MDTMA/Undefined +08 +0C PLRECA PLOPM PLOPC

CCP TRACE (Continued)		
Disp Hex	Descripti	ion
Type 0E —	\$CC4II Re	turn to User
00	Hex 0E	communication I/O complete
01	TCBID	of task that requested I/O
02	TUBAT	- Terminal attributes byte 1:
	Hex Value	Meaning
	80	Main console TUB
	40	Subordinate console TUB
	20	Terminal online
	10	Command terminal is signed on
	80	Command terminal in /Q status
	04	Terminal is requester of program
	02	Terminal on switched line
	01	Command terminal signoff default is hold
03	TUBAT	2 Terminal attributes byte 2:
	Hex Value	Meaning
	80	Terminal in data mode
	40	Terminal in command mode
	20	Outstanding data for program request
	10	Invite or get scheduled
	80	Completed invite outstanding
	04	Running online test on terminal
	02	Stop polling successful during program request validation
	02	Allocation pending on this TUB
	01	Terminal on BSCA line. EOT not sent or received
04	TUBAT	3 — Terminal attributes byte 3:
	Hex	
	Value	Meaning
	80	Not used
	40	Stop polling failed
	20	/RELEASE command entered by terminal operator
	10	Terminal error-waiting for ERP
	80	Not used
	04	Vary offline pending
	02	Stop poll pending to terminal in command interrupt mode
	01	Discard input data, terminal can be reinvited

Disp Hex	Description				
05	TUBTA2	Second byte of ter	minal attributes set	::	
	Hex Value M	leaning			
	40 D. 20 D. 10 IT 08 TI 04 N. 02 Sp	ata format is record ata format is block ata format is messa FB checking suppor ransparency mode o ID exchange veri panned records sup	mode age mode ted fication aported		
06-07		01 Variable length records supported TUB address			
08-09	Communica	Communication parameter list address			
0A-0B	External ret	urn code			
0C-0D	Internal retu	ırn code			
0E-0F	Operation co	ode			
+00	Trace Type 0E	Issuer's TCBID	TUBAT1	TUBAT2	
+04	TUBAT3	TUBTA2	Addresses (TUB)/	I Addresses (TCB)	
+08	Addresses (pa	i arameter list) L	PLR	tc t	

PLOPM

PL\$RTC

+0C


PLOPC

## **BSCA TRACE**



Disp Hex	Lng Dec	Description	
00	1	Q-byte of SIO:	
		Hex	
		Value Meaning	
		88 BSCA line	2
		80 BSCA line	1
		Bits 5-7 00 — Cont	
		01 - Rece	•
			smit and receive
		03 Rece	
		04 – Auto	
		06 – Loo	p test
01	1	R-byte of SIO:	
		Hex	
		Value Meaning	
		CO Enable BS	CA (off-disable BSCA)
		A0 Enable tes	t mode (off-disable test mode)
		90 Enable ste	p mode (off-disable step mode)
			second timeout (off-cancel
			nd timeout)
			errupt requestability (off-disable requestability)
		•	rrupt request
03	1	Sense byte 1:	
		Hex	
		Value Meaning	
		02 Data set n	eady
		01 Data line	occupied (switched, auto-call)
04-06	3	First 3 characters tra	ansmitted
07-09	3	Last 3 characters tra	nsmitted
0A-0C	3	First 3 characters re	ceived
0D-0F	3	Last 3 characters red	eived

#### **BSCA TRACE (Continued)**



Hex	
Value	Meaning
80	Receive timeout, aborted auto-call
40	Data check during receive operation
20	Adapter check during transmit operation
10	Adapter check during receive operation
80	Invalid ASCII character
04	Abortive disconnect (lost connection)
02	Disconnect 20-se∞nd timeout
	Value 80 40 20 10 08

## MLTA TRACE



Disp	Lng	
Hex	Dec	Trace F0 (Program Level SIO)

## MLTA Trace F0 SIO

00	1	Hex F0 entry ID					
01	1	Op code from DTF (contains hex FF during open/close)					
02-03	2	ARR save area contents from DTF					
04	1	Receive length count (HDB-8)					
05	1	HDB-9:					
		Hex Value Meaning					
		80 PCI flag 40 Break/skip flag 10 Terminal interrupt 08 Inhibit receive flag 04 Inhibit timeout 02 Terminal dependent flag 01 Terminal control type					
06-07	2	Address to receive control at next op end interrupt					
08-09	2	Contents of XR2 save area in DTF					
0A-0B	2	SIO Q and R-bytes in IOB					
0C-0D	2	CAB contents in IOB					
0E-0F	2	TAB contents in IOB					

#### MLTA TRACE (Continued)

NΑ

ов

0E

οF

0C-0D

1

1

2

1

10112	تا لتا	3 3 7 3 7 3 3 7 3 3 7 3
Disp Hex	Lng Dec	Trace F1 (Interrupt Level Entry Trace Table Entry)
MLTA Trac	æ F1	
00	1	Entry ID
01	1	Contents of high density buffer position 0 (DTF)
02	1	Contents of high density buffer position 6 (DTF)
03	1	Contents of high density buffer position 7 (DTF)
04-05	2	CAB contents (MLTCOM) <sup>1</sup>
06-07	2	TAB contents (MLTCOM)
08-09	2	Two characters stored at CAB contents (MLTCOM) <sup>2</sup>

0 1 2 3 4 5 6 7 8 9 4 8 C D F F

Note: If this current trace entry is identical to the last interrupt level entry trace entry (except when at beginning of table), it is not added to the table.

IOCS switches (MLTCOM)<sup>2</sup>

Bit switch of attribute byte 2 (DTF)

Interrupt level 3 source bits (MLTCOM)

Address of DTF associated with this line (XR2)

Count of PCI processing that is pending (MLTCOM)

Traces

<sup>&</sup>lt;sup>1</sup>MLTA IOCS common area

<sup>&</sup>lt;sup>2</sup>If bits 0 or 1 are on (displacement E), the CAB characters are not meaningful.

#### MLTA TRACE (Continued)

					_											
ויו		_	_			- 1		l -, '	١.,	_	١.	В	۱ ۵	۱ ـ	-	-
U	- 1	2	3		4	וטן	וסן	· /	8	ן פ	A	l B	C	טן	=	-
	1			. 1					L			1 _		L	L	L

Disp	Lng	
Hex	Dec	Trace F2 (Interrupt Level Exit Trace Table Entry)

#### MLTA Trace F2

00	1	Entry ID
01 <sup>1</sup>	1	Operation code being processed on this line (DTF)
02	1	Internal IOCS completion code set when interrupt processing is complete (DTF)
03	1	Internal IOCS ERP switches (DTF)
04-05	2	Contents of high density buffer positions 8 and 9 (DTF)
06-07	2	Address to receive control at next operation end interrupt (DTF)
08-09	2	Internal IOCS switches (DTF)
0A-0B	2	SIO Q and control bytes (SIO)
0C-0D	2	CAB contents (IOB)
0E-0F	2	TAB contents (IOB)

Note: If this current trace entry is identical to the last interrupt level exit trace entry in the table (except when at beginning of table), it is not added to the table.

Disp	Lng	
Hex	Dec	Trace F3 (Operation Complete)

## MLTA Trace F3 Op Complete

00	1	Hex F3 trace ID read/write operation complete				
01-02	2	Current record length (DTF)				
03-04	2	Current record address (DTF)				
05-0F	11	Data stored at current record address (nonpolled terminal)				
05-0D	(9)	Data stored at current record address (polled terminal)				
0E-0F	(2)	Terminal address (DTF) (polled terminal)				

<sup>&</sup>lt;sup>1</sup>Contains hex FF during open and close operations

#### TRACE HALT \$CC\$SA

The trace halt service aid halts CCP when significant system events are traced. The service aid user can specify, by entering data on the CPU switches, the trace entry to halt. Optionally, a halt on every trace entry can be selected.

The trace halt service is loaded by startup if:

- 1. CCP TRACE (\$CC\$TR) is loaded, and
- The service aid resides in the same object library as CCP trace. The module name must be \$CC\$SA.

When loaded, \$CC\$\$A does not halt until FFFF is dialed into the CPU data switches. The next entry to trace causes \$CC\$\$A to sense the switches and a CU halt appears. The trace entry to halt can then be selected as follows:

- 1. If hex 0000 is dialed in, \$CC\$SA does not halt until FFFF is sensed.
- Hex XX01-XX1F stores the right data switches and halts when a matching trace entry occurs.
- Hex XX20-XXFF causes the CU halt to reappear.
- Hex XX00 causes the service aid to halt on any entry to trace.

When \$CC\$SA is entered, the current trace ID is compared to the selected trace ID. If they match, or if the selected trace ID is hex 00, an OP halt appears. If halt reset is pressed, the CPU data switches are again sensed. If hex FFFF is dialed into the switches, the CU halt appears, and a new halt ID can be selected.

At any time, 0000 can be dialed into the switches to prevent \$CC\$SA from halting CCP.

\$CC\$SA exists on CCP production pack as \$CC#SA. The module must be renamed before \$CC\$TR can load and activate it.

#### DUMP PROGRAM

The dump program \$CCPDD can be used to print dumps and CCP trace data from the most recent execution of CCP.

#### How to Use \$CCPDD

The following OCL is used to invoke the dump program:

- // LOAD \$CCPDD.uu
- // FILE UNIT-dd,NAME-\$CCPFILE,PACK-XXXXXX
- // RUN

where uu is the unit on which the program is located and dd is the unit on which SCCPFILE is located. XXXXXX is the volume identification of the pack on which SCCPFILE is located.

You can select the type of dump you want by entering any or all of the following types of dump control records from the SYSIN device:

1. To dump all of one storage dump, enter:

// DUMP n

The n specifies the dump number from the 526 or 530 messages issued to the system operator during CCP execution.

2. To dump all storage dumps taken during the last CCP execution, enter:

// DUMP ALL

3. To dump the CCP trace data, enter:

// DUMP TRACE

To dump a portion of one storage dump, enter:

```
// DUMP n, hex aaaaaa, hex bbbbbb (Model 12 only) // DUMP n, hex aaaa, hex bbbb (Models 4, 8, and 10)
```

The n is the dump number, aaaa is the starting address (in hexadecimal) of the area to be dumped, and bbbb is the address of the end of the area to be dumped.

 Follow the last dump control record with a /\* to terminate the dump program.

## USING THE STANDALONE DUMP PROGRAM (MODELS 8.10. AND 12 ONLY)

When the DSM CEFE storage dump fails to function properly because some error has destroyed the low-storage linkage to the dump routine, a card-loadable storage dump can be used to dump main storage to the printer.

Four MFCU-loadable storage dump programs are provided with CCP. The programs are punched during CCP generation. The dump programs differ only in the specific print chain (or train) they support. The dump programs are:

- 1. CCPDAN for AN or LC chain.
- 2. CCPDHN for HN chain.
- CCPDPN for PN chain.
- 4. CCPDTN for TN chain.

The dump program itself occupies 768 (hex 300) bytes of main storage. The 768 bytes can be anywhere in the machine. The bootstrap loader used to load the dump program into main storage occupies the first 256 bytes of storage. The Model 12 dump program occupies 1024 bytes (hex 400) of main storage and must be loaded so that the entire program is below hex 8000.

To use the card-loadable dump program:

- Place the program in the primary MFCU hopper.
- Set the load selector dial to ALTERNATE.
- 3. Press PROGRAM LOAD.
- When the CU halt appears, dial in the address where the dump program is to be loaded, then reset the halt.
- 5. When the 5E halt appears, use the left two dials to set the high-order two digits of the beginning dump location; use the right two dials to set the high-order two digits of the ending dump location. After setting the dials, press HALT RESET/START. (If the 5E halt remains, the beginning location is set higher than the ending location.) For Model 12 only, after the program is loaded, a 5A halt will appear. Use the four dials to set the high-order 2 bytes of the 3-byte physical address of the beginning location of the dump. Press HALT RESET/START. When the EA halt appears, set the four dials to the high-order 2 bytes of the 3-byte physical address of the ending location and press HALT RESET/START. (If the SA halt reappears, the beginning address was higher than the ending address.)
- After printing the dump, the dump program returns to the starting address halt. You can dump another area of main storage without reloading the dump program.

#### REP STATEMENT PROCESSOR

This facility is used to patch execution time resident code. To activate this facility at startup time, enter the keyword FEREP.

If you wish to always activate the rep card processor at startup time, the following disk patch to \$CC3CX is necessary:

```
// LOAD $SGFIX, xx
// RUN
HDR & O$CC3CX, xx
PTF & $CC3000
DATA & 0013, 87, 80
END
```

To deactivate the facility, replace DATA card above with:

DATA & 0013, 80, 87

During startup, the activated \$CC3Cs prompts:

ANY REPS FOR THIS RUN?

A response of YES or Y covers rep cards to be read (from SYSIN) and then processed.

#### Rep card format:

- Col 1-3 REP
  - 4 Blank
  - 5-6 Address to be patched
    - 7 Blank
  - 8-? The patch bytes (Any bytes can be separated by a comma. An asterisk causes the 2 preceding bytes to be relocated relative to the start of CCP program level. Comments are allowed if separated from patch data by a blank. A card with an asterisk in column 1 is logged. The last card of the rep deck must be /\*.)

#### HOW TO WRITE A SERVICE AID PROGRAM

To write your own service aid program, consider that:

- The program must be named \$CC\$SA and must reside in the object library of the CCP pack.
- 2. The entry point of the program must be the first byte.
- 3. The ARR must be saved upon entry and used to return to \$CCSTR.
- General entry, IOS, and IOW cannot be invoked from the service aid program.

The input to the service aid is:

- The address of \$CCCOM is passed in XR1.
- 6. The address of the trace control block is passed in XR2.

#### **CCP Halts**

See IBM System/3 Communications Control Program Messages Manual, GC21-5170.

#### PROGRAM TERMINATION CODES

526 xxxxxx TASK-n CMP-nn [REQR-'xx' DUMP#-n]

Where: xxxxxx = Program name

TASK-n = CCP identification of user task
CMP-nn = User program termination code

CMP-nn = User program termination code

REQR-'xx' = CCP terminal reference identifier of the requesting terminal, if still attached to the user program when it terminated. If the user task was an MRT program,

the oldest attached requester is identified.

DUMP#-n = Identification number of the disk dump of the user
program on \$CCPFILE (if space was available for a

dump in the dump area).

When user program errors involving the DFF put override operation cause the termination, message 526 is preceded by message 528.

#### 528 ERROR IN DATA FOR DEF AT LOCATION none

## Completion Code

02	Reason	Invalid operation for the 5471 printer/keyboard
UI	Recovery	Review operation code or invalid operation code modifier Review operation code/operation modifier combinations.

-		mitana operation for the Giff printer, no pour a
	Recovery	Review operations issued to CONSOL. The valid operations
		are put-then-get, put, put-no-wait, get attributes, and accept
		input (data with program request only).

03	Reason	Symbolic terminal name not defined to CCP
	Recovery	Verify the terminal names used in the program against the

terminal names defined at assignment time.

04	Reason	Terminal not allocated to this program
	Recovery	Determine which operation was issued to an unallocated

terminal (other than acquire terminal and get terminal attributes). Correct the program and/or the assignment set.

05 Reason Allocated terminal referenced by other than an allocated

Recovery Verify

Verify that terminal names used in the program are the names specified in the // PROGRAM assignment statement

or in an acquire terminal operation.

06	Reason Recovery	Blank symbolic terminal name used in an MRT program Correct the program to specify a terminal name. Blank terminal names are allowed only in SRT programs.
07	Reason	Blank terminal name used in an SRT program after the requesting terminal has been released
	Recovery	Correct the program to specify a terminal name on the operation or do not release the requesting terminal.
80	Reason Recovery	Blank symbolic terminal name is invalid for this operation Review operations. A blank terminal name is not allowed for an acquire terminal operation.
09	Reason Recovery	Invalid use of a subterminal name Review operations. A subterminal name (a symbolic terminal name for the component(s) of a multicomponent terminal) may not be used with acquire terminal and release terminal operations.
0A	Reason Recovery	Symbolic terminal name not assigned to a terminal Verify that terminal names specified in the PROGRAM assignment statement are assigned to terminals by TERMNAME assignment statements; revise the program and/or assignment set as necessary.
ОВ	Reason Recovery	Terminal attribute set is invalid for the terminal specified The terminal attribute set associated with a terminal by an acquire terminal operation is invalid for the terminal. Review the attribute identifiers and terminal types.
0C	Reason	Terminal does not have the I/O capability specified in the operation. Either an output operation is being issued to an input-only terminal or an input operation is being issued to an output-only terminal.
	Recovery	Review program logic and terminal assignments.
0D	Reason Recovery	Invalid output length Review output lengths. The output length for put record operations must be greater than zero.
0E	Reason Recovery	Invalid input length Review input lengths. The input length for input operations must be greater than zero.
0F	Reason	Input length greater than teleprocessing line buffer size (4) for an invite input operation (Four characters are required for control information used by the main storage allocation requires.)
	Recovery	routines.) Review lengths specified for invite input operations; ensure that all necessary terminal attribute identifiers for this terminal are specified at assignment time.

10	Reason	Invalid operation issued to a terminal with data from a program request outstanding
	Recovery	Review program logic. The only operation that is valid to a terminal with data accompanying the program request is an accept input.
11	Reason	Invalid operation issued to a terminal to which an invite input operation is outstanding
	Recovery	Review program logic. Only an accept input or stop invite input operation can be issued to the terminal.
12	Reason	Accept input operation issued to a nonnever-ending program that had no outstanding invite input operations
	Recovery	Review program logic. An accept input is valid for a nonnever-ending program only if one or more invite inputs are outstanding.
13	Reason	Accept input operation issued by a never-ending program that has no outstanding invite input operations and whose active terminal count is equal to the maximum terminal count
	Recovery	Review the logic of the program and the value specified for MRTMAX on the PROGRAM assignment statement for the program.
14	Reason	Stop invite input operation issued to a terminal that has no outstanding invite input operations
*	Recovery	Review program logic. Stop invite input can only be issued to a terminal that has an outstanding invite input.
15	Reason	Input record area not large enough for a get block operation (BSCA terminals).
	Recovery	Review record area sizes in the program and check the value of the BLKL keyword on the TERMATTR assignment statement.
16	Reason Recovery	DFF copy command issued to a terminal not using the DFF Check the attribute sets used by the terminals in the
	·	program. The TERMATTR assignment statement must contain the DFF3270-YES keyword in order to use the copy command with the terminal.
17	Reason	Copy operation issued to a terminal whose name is not defined in the CCP system
	Recovery	Check the terminal names used in the program against the TERMNAME assignment statements for this assignment set. The error refers to the copy to terminal.
18	Reason Recovery	Copy operation issued to a 3275 display station Change the program. The copy operation can be issued only to Models 1 and 2 of the following 3270 components (attached to the same 3271 control unit): 3277, 3284, and 3286.

19	Reason	DFF erase all unprotected operation issued to a terminal that does not support the display format facility Check the attribute sets used by the terminals in the program. The TERMATTR assignment statement must contain the DFF3270-YES keyword in order to use DFF operations with the terminal.	
1A	Reason	Put override operation issued to a terminal that does not support the 3270 display format facility	
	Recovery	Check the attribute sets used by the terminals in the program. The TERMATTR assignment statement must contain the DFF3270-YES keyword in order to use DFF operations with the terminal.	
18	Reason	A put operation other than a message mode output opera- tion issued to a terminal that supports the display format facility	
	Recovery	Only message mode operations can be issued to terminals that support the DFF. Check terminal attribute sets and program operations to locate the error.	
1C	Reason Recovery	Record area not large enough for BSCA ITB Review the record area size specified in the parameter list, and check the record length specified in the TERMATTR assignment statement. When processing input or output data in record mode with ITB, you must specify a record length equal to that specified in the TERMATTR statement.	
1 D	Reason	Accept input operation issued, but it is not possible to receive data from any terminal with an outstanding invite input	
	Recovery	Review program logic. The only outstanding invite input operations are to BSCA terminals, but the BSCA line is currently owned by a terminal in use by your program that is awaiting EOT.	
1E	Reason	Output operation to the console specified a length greater than the maximum allowed. The maximum lengths are:  Model 4 66  Models 8, 10, and 12 80	
	Recovery	Check console operations in the program to ensure that the length specified for output operation does not exceed the maximum allowed.	
1F	Reason	Output length greater than the teleprocessing line buffer size	
	Recovery	Review the output lengths and the terminal attribute sets associated with the terminal.	
20	Reason	Total length of fields to be moved by RPG II SUBR90 greater than the size of the record area provided	_
	Recovery	Check lengths specified in the program as RLABLs for	

SUBR90 against the record area length specified in the

RPG II file description specifications.

	21	Reason	Program attempted to acquire a terminal by a symbolic subterminal name Review acquire terminal operations cannot be used in an acquire terminal operation.
	22	Reason Recovery	Program attempted to acquire the console Review acquire terminal operations; acquire terminal cannot be issued to the console.
	23	Reason	Program issued an invalid acquire terminal operation:  — Attempted to acquire a nonrequesting terminal that was already allocated to the program by assignment specifications or a previous acquire terminal operation  — Attempted to acquire a requesting terminal without specifying the set terminal attributes modifier in the operation code
		Recovery	Review program logic for acquiring terminals. Determine from the PROGRAM assignment statement which terminals are required to be available to the program (therefore, already allocated to the program when it is initiated). Acquire terminal can be issued to a requesting terminal only to reset the terminal attributes.
	24	Reason Recovery	Acquire terminal operation issued to a requesting terminal that is in the process of transmission Review program logic. Acquire terminal cannot be issued
			to a BSCA terminal that is operating in block or record mode and has not yet sent or received EOT.
	25	Reason Recovery	Acquire terminal operation issued with an invalid attribute set identifier or with attributes invalid for the terminal. Review TERMATTR and PROGRAM assignment statements
		riccovery	to determine valid attribute set identifiers; correct the program or change the assignment set.
	26	Reason	Attempted to issue a release terminal operation to a subterminal of a multicomponent terminal
		Recovery	Review release terminal operations and TERMNAME assignment statements. Release terminal cannot be issued with a subterminal name.
	27	Reason	Release terminal operation issued to a BSCA terminal that is in the process of transmission
		Recovery	Review program logic. Release terminal cannot be issued to a BSCA terminal that is operating in block or record mode and has not yet sent or received EOT.
	28	Reason	Input or output length specified for an RPG II operation using SUBR92 greater than the record length specified in the file description specifications or less than 14.
		Recovery	Review input and output lengths; compare to length specified in file description specifications.
_			

29	Reason	Invali	Invalid put-then-get operation in RPG II program (using			
		SUBF	R92):	_		
		1.	Put-then-get issued to other than a combined file	1		
		2.	Put-then-get operation code is in the array for an input	•		

not performed previously

Recovery Review use of put-then-get operation:

- 1. Must be issued to a combined file
- The output part of the operation must precede the input part

Determine reason for cancelation and take appropriate

Determine reason for cancelation and take appropriate action.

operation, but the output part of the operation had

		action, it necessary.
2B	Reason	System operator canceled the CCP, causing all programs to
		he canceled

System operator canceled your program

2C Reason User program went to end of job normally, but had outstanding invite input operations

Recovery If a program is to go to end of job prematurely (with

Recovery If a program is to go to end of job prematurely (with outstanding invite input operations), it should issue stop invite input to terminals with outstanding invite inputs.

2D Reason User program went to end of job normally, but had an incomplete BSCA I/O operation (EOT was not sent or received on a record or block mode operation)

Recovery Review program logic. A user program should not go to end of job until EOT is received on BSCA I/O operations

in progress.

Program has two or more definitions for the same file and has tried to add records to that file using more than one of

those definitions

Recovery Review the program and correct the logic. Two definitions of the same file are valid in Model 10 CCP systems that are generated with file sharing, but you must not add records to the file using more than one of the definitions.

2F Reason Invalid or illegal command, order, or buffer address in output data for the 3270 or an I/O interface overrun on the 3270 control unit

Recovery Review output data to the 3270 for invalid command, order, or buffer address. If the program uses a DFF copy operation, perhaps an attempt is made to copy a protected display format (the from format contains a protected alphameric attribute byte in row 1, column 1).

30 Reason SUBR92 used with an exit operation or SUBR91 used with

a SPECIAL file

Recovery Check for improper use of communications service subroutines and recompile the program.

2A

2E

Reason

Reason

Recovery

Recovery

31	Reason	A never-ending program went to end of job prior to a SHUTDOWN request. Storage occupied by the program is not usable for other programs during this CCP run.
	Recovery	<ul> <li>Change the never-ending program logic so that the program goes to end of job only when SHUTDOWN is recognized, or</li> <li>Change the PROGRAM assignment statement so that the program is no longer a never-ending program.</li> </ul>
32	Reason	Program attempted to read a record from a shared file and sufficient control blocks (SQB) were not available for it Allocate more SQBs in the SQB-parameter of the SYSTEM statement for this assignment set.
33	Recovery	Indicator 91 was left on after two operations to the same file or indicator 92 was left on for more than two task chain operations.  Check all return codes in the RPG II program and reset indicator 91 or 92 after issuing a CCP operation.
34	Reason Recovery	An array is not associated with a file that used SUBR92. Include an extension specification associating an array with every file that uses SUBR92.
35	Reason	A user program that is not defined as using DFF attempted to perform an operation on a terminal whose attributes set indicates it does not use DFF.  Review the TERMATTR assignment statement and/or the program's use of the terminals.
7F	Reason	Halt issued by the user program or by a DSM routine supporting the user program. The halt information is printed on the system operator's console (990 series message), preceding message 526. Determine the reason for the halt and correct the error condition. Do not use the following statements in programs written to run under CCP:
		RPG II: Halt indicators COBOL: STOP statement FORTRAN IV: PAUSE statement Basic Assembler: Branch to general entry (hex 0004) with a RIB of 85 (call halt/syslog)
		RPG II programs must protect against an unidentified record halt.
80	Reason	Program requested an undefined function from CCP. In an RPG II, COBOL, or FORTRAN IV program, incorrect data area manipulation may have destroyed part of the program. In a Basic Assembler program, the sub-RIB used in a branch to general entry is invalid.
	Recovery	Review the program and correct the logic.

#### 82 Reason Model 4:

An unrecoverable error occurred during CCP initialization of a user program's file:

- Filename not recognized.
- Filename not in PROGRAM assignment statement.
- Maximum skip line number is greater than printer page size.
- Disk file access method specified is not a valid access.
- Method of access is not permitted for this disk file organization.
- Disk file method of access does not match access method specified in PROGRAM assignment statement.
- Ordered load access specified, but it is not the first access of the file, or attempted to access a disk file to which an ordered load must be done first.
- An unordered load access is specified in this assignment set for this file; therefore, only unordered load is allowed during this CCP run.
- ISA or ISUA access was specified in the program, but cannot be allowed, because there were previous adds to the file.
- File characteristics as defined in the program do not match those declared in the DISKFILE assignment statement (ORG, RECL, KEYL, and KEYPOS parameters).
- More than one file definition is being used to update, load, or add to the same physical file in a program.

## Recovery

Ensure that the file is defined at assignment time, that the file processing methods and file characteristics you defined in your program are compatible with the file definition requirements for assignment, and that you considered disk file sharing requirements.

## 82 Reason Models 8, 10, and 12:

An unrecoverable error occurred during CCP initialization of a user program's file:

- Basic Assembler program attempted to open a unit record device without allocating it.
- Attempted to use a disk file, but the name of the file was not declared in the FILES parameter of the PROGRAM assignment statement.
- Method of processing a disk file does not match the access value specified for that file in the FILES parameter of the PROGRAM assignment statement.
- File characteristics as defined in the program do not match those declared in the DISKFILE assignment statement (ORG, RECL, KEYL, and KEYPOS parameters).
- Basic Assembler only: DTF is specified incorrectly or unit record device buffers are aligned incorrectly.

8R

EF

Reason

Reason

Recovery	Perform one of the following:
	<ul> <li>Basic Assembler: Allocate unit record devices (branch to general entry with RIB 8B) before attempting to open the files (branch to general entry with RIB 82).</li> <li>Ensure that the disk file is defined at assignment time.</li> <li>Ensure that the file processing methods and file characteristics you defined in your program are compatible</li> </ul>

- with the file definition requirements for assignment.

   For disk files, see above.
  - For unit record devices, ensure that you aligned your unit record device buffers correctly.
- 83 Reason 1. RPG II or FORTRAN IV: CCP encountered an error
  - condition during program termination

    2. COBOL or Basic Assembler: CCP encountered an error condition during disk file close
- Recovery User program may have modified main storage outside of its bounds. If no error can be found, contact IBM for programming support.
- 84 Reason Permanent I/O error during CCP initialization or termination of a user program's files

  Recovery The problem could be hardware or, if a Basic Assembler program is being executed, it could be a program error. If an

error cannot be found within the program, call IBM for programming support.

Note: In a Basic Assembler program, a disk DTF cylinder/

sector value that is incorrect can result in a permanent disk error that would look like a hardware error.

- Program attempted to use a card reader or printer, but the assignment parameter for the device was not specified in the PROGRAM assignment statement. Also, the program might have attempted to use the console as a non-communication device.
- Recovery Be sure to define unit record devices used by the program in the PROGRAM assignment statement. Also, be sure that operations issued to the console by the program running under the CCP are issued as communications operations.
- EE Reason Program attempted to use a put override operation to modify data in an input field

  Recovery Determine program name and approximate location of error
  - from message 528. Change field class to output/input or review logic of this operation.
    - override operation

      Recovery Determine program name and approximate location of error from message 528. Change indicator to blank to indicate no modified data, or M to indicate modified data.

Program used an invalid modify data indicator in a put

FO Reason Program used an invalid character for cursor positioning in a

put override operation

Recovery Determine approximate location of error from message 528.

Correct the cursor positioning character to C to position the

cursor or to blank if cursor is not to be positioned.

F1 Reason Program gave an invalid character in a put override operation to override the field type, or the field type character was not

consistent with alpha/numeric field rules.

Recovery Determine approximate location of error from message 528.
The field type must be blank, 1, 2, or 5 for output fields;
blank or 1-7 for SPD and input fields; blank or 1-8 for
output/input fields. If the field is defined as alpha, valid

override characters are 1, 2, or 5 (and 7, for input alpha fields); if the field is numeric, valid characters are 3, 4, or

6 for input or output/input fields.

F2 Reason The value given as the output length for a DFF put message, copy, or put override operation was incorrect

Recovery Determine which output record is in error and recalculate the length of data that should be provided or the value that

should be given.

Put Message: The output length value must include the six positions for the display format name and the full length of each field supplied at execution time (+14, in RPG II SPECIAL).

Copy: The output length value must be 6 or 7 (if the copy control character is specified). (In RPG II SPECIAL, the value must be 20 or 21.)

Put Override: The output length value must include the WCC, nine positions for each field that is overridden, plus the full length of each field that has modified data (+14, in RPG II SPECIAL).

F3 Reason The model number specified for the display format does not match the model number of the terminal

Recovery Request a different format or regenerate the display format, designating the proper model number.

A field name was expected in the record area for a put

override operation with DFF and one of the following occurred:

• The field name was not provided in the correct sequence.

A field name is duplicated in the record area.

An invalid field name was specified.

An incorrect value was given for output length.

The field name was not given in the proper location in the record area.

 The field may have been defined as data source F instead of G.

F4

Reason

type fields.

Recovery	Determine which output record contains the error and
	determine the position in the record area where the field

name in error is located (message 528 provides this value).

Verify the following:

- The order and spelling of the field names match those in the format generation listing.
- The proper format was overridden.
- The value given for the output length includes the WCC, nine positions for each overridden field, plus the full length of each field that has modified data (+14, in RPG II SPECIAL).
- The editing of an output field did not blank out the M designating modified data.

F5 Reason A modify data indicator of E was used, but the field erased to nulls is an output or SPD field type. A modify data indicator of E is valid only for input or output/input

Recovery Determine the output record in error, and determine the position in the record area where the field name in error is located (message 528 provides this value). Verify that an attempt was made to override an output or SPD field type.

Correct the PUT override list or format.

F6 Reason The space available in the program appended storage area for DFF is not large enough to contain the field descriptor table for the desired format.

Recovery Check the field descriptor table size for every format this program uses and increase the DFFSFDT value on the

PROGRAM assignment statement.

F8 Reason The amount of text to be sent to a 3270 terminal is more than 256 bytes and the output hold area is not large enough.

Recovery The output hold area must be at least 512 bytes in length for blocking of output text when DFF is used. Specify a value of 512 bytes or larger on the BLKL keyword of the

TERMATTR assignment statement.

F9 Reason Disk I/O error occurred during operation of the display format control routine.

Recovery System operator should obtain a dump of storage from

\$CCPFILE. Call your IBM representative.

FA Reason For a DFF copy operation, the *from* and *to* terminals are either not both online, not attached to the same control

unit, or not on the same BSCA line.

Recovery Verify the terminal names used in the copy operation.

Obtain verification of the status of the desired *from* and

to terminals from the system operator.

FB Reason The BSCA line buffer is smaller than the output hold area

for DFF.

Recovery The BSCA line buffer must be at least as large as the output hold area defined for the line. Ensure that the

value for BLKL in the TERMATTR statement for this

terminal is large enough for your data.

FC Reason The des

The desired display format was not found on the specified

disk pack for DFF.

Recovery Verify that the display format name is valid and verify which disk pack it is on. All display formats must be on

the same disk pack (program or system pack). If the format name and location are correct, contact IBM for

CCP programming support.

FD Reason A non-SPD field (input or output/input) was received from a terminal and the data was received because of a

selector pen attention field.

Recovery Data cannot be provided to the program for input or output/input field in this case. Evaluate the types of

fields defined at the terminal. In the case of overlay formats, the modify data indicators were not reset when

the overlay format was issued to the terminal or a non-SPD field was modified to an SPD field by improper data.

FE Reason

Recovery

Not enough space allocated in the program-appended storage area for the program to use DFF Increase the number of terminals this program can communicate with concurrently in the DFFMTERM keyword or the number of display formats this program

uses in the DFFNDF keyword of the appropriate

PROGRAM assignment statement.

FF Reason

 Program is attempting to communicate with a terminal using DFF, and a display format was not previously sent to a terminal by means of a put message or copy operation.

The format is not on the terminal because either a negative return code was received from the last output operation, or a CLEAR key return code was received

Recovery

from the last input operation issued to the terminal.

1. Restructure the program to issue a display format to the terminal before attempting to receive data from the terminal via DFF. This message does not apply to an accept input that is preceded by an implied invite input (data allowed with the program request from the terminal).

Transmit a format to the terminal.

## **OPERATION CODES**

## Operation Symbols

GET Get

PUT Put

SPI

ACQ

REL

PTG Put-then-get

PNW Put-no-wait

INV Invite input

ACC Accept input

Stop invite input

Acquire terminal Release terminal

SHQ Shutdown inquiry

Get terminal attributes GTA

Force end of file (RPG II only) EOF

Copy (3270 DFF only) CPY

Erase all unprotected (3270 DFF only) EAU

## **Operation Modifier Symbols**

BLK Block-send end of block (EOB)

MSG Message-send end of transmission (EOT)

RVI Send reverse interrupt (RVI)

KPL Keep line

STA Set terminal attributes

NNL Not start new line

NEL Not end new line

OVR Override (3270 DFF only)

	V	alue	RPG II
Operation	Dec	Hex	Code
GET	1	0001	101619 V
GET,RVI	17	0011	<b>W</b> AA
PUT	2	0002	<b>PPPB</b>
PUT,NNL	514	0202	<b>PRPB</b>
PUT,NEL	258	0102	₩A₩B
PUT,NNL,NEL	770	0302	₩C#B
PUT,BLK	34	0022	b#bBB
PUT,BLK,PRF	98	0062	₽R EB
PUT,BLK,NNL	546	0222	₩ВВВ
PUT,BLK,NEL	290	0122	<b>MABB</b>
PUT,BLK,NNL,NEL	802	0322	<b>Ы</b> СВВ
PUT,MSG	50	0032	₩b6CB
PUT,MSG,PRF	114	0072	bbbGB
PUT,MSG,NNL	562	0232	<b>₩</b> BCB
PUT,MSG,NEL	306	0132	₩ACB
PUT,MSG,NNL,NEL	818	0332	<b>ВССВ</b>
PTG	3	0003	RRRC
PTG,NNL	515	0203	₩B₩C
PTG,NEL	259	0103	<b>WANC</b>
PTG,NNL,NEL	771	0303	<b>RCRC</b>
PTG,MSG,GET	51	0033	RACC
PUT,MSG,OVR	2098	0832	ынсв
PUT,MSG,PRF,OVR	2162	0872	<b>W</b> HGB
PNW,MSG,OVR	3002	0836	<b>WHCF</b>
EOF	_	_	₩₩GA
SHQ	0	0000	<b>PPOO</b>

b = blank

# **OPERATION CODES (Continued)**

	v	'alue	RPG II
Operation	Dec	Hex	Code
CPY	66	0042	₩DB
EAU	82	0052	<b>W</b> EB
PNW	6	0006	<b>₽₽₽</b> ₽
PNW,NNL	518	0206	ЫВЫF
PNW,NEL	262	0106	babf
PNW,NNL,NEL	774	0306	<b>⊮</b> C⊮F
PNW,BLK	38	0026	ЫЫBF
PNW,BLK,NNL	550	0226	<b>6</b> BBF
PNW,BLK,NEL	294	0126	₿ABF
PNW,BLK,NNL,NEL	806	0326	<b>BCBF</b>
PNW,MSG	54	0036	ЫЫСЕ
PNW,MSG,PRF	118	0076	₩b⊌GF
PNW,MSG,NNL	566	0236	₩BCF
PNW,MSG,NEL	310	0136	<b>MACF</b>
PNW,MSG,NNL,NEL	822	0336	⊌CCF
PNW,MSG,OVR	3022	0836	<b>ЫНС</b> Б
PNW,MSG,OVR,PRF	2166	0876	⊌HGF
INV	5	0005	ююю́Е
ACC	4	0004	#o#o#oD
SPI	1025	0401	₩D#A
GTA	8	8000	<b>БРР</b>
ACQ	9	0009	PARPAI
ACQ,STA	25	0019	ЫҚАІ
REL	10	000A	<b>ままな</b> て
REL,KPL	26	001 A	ЫВАК
PUT,MSG,INV	_	_	161616S
PNW,MSG,INV			<b>RRRM</b>
PUT,MSG,INV,OVR	_	-	RHRR
PNW,MSG,INV,OVR	_	_	RHRW

## **RETURN CODES**

ССР	RETURN	CODES		Program Action
Dec	Hex	RPGII	Description	Code <sup>1</sup>
0	0000	00	Successful operation.	A1
1	0001	01	DATA TRUNCATED: Data was truncated; for input operations, the data was greater than the input length specified in the parameter list; for output operations, the length of the data was greater than the length of the teleprocessing line buffer.	A2
2	0002	02	EOT: Input operation was successful; EOT was received.	А3
3	0003	03	DATA TRUNCATION AND EOT: Data truncation occurred on this operation and EOT was received.	A2
4	0004	04	SHUTDOWN REQUESTED: The system operator has requested CCP shutdown. The requested operation was not performed.	A4
5	0005	05	DATA PENDING: The operation was issued to a terminal on a BSCA line that is currently controlled by another terminal in use by your program (line awaiting EOT), or an invite input was issued to a terminal awaiting EOT.	A6
6	0006	06	TERMINAL INTERRUPT/RVI: A terminal interrupt (MLTA) or RVI (BSCA) was received from the remote station. The operation was successful.	A5
7	0007	07	3270 CLEAR: The terminal operator at 3270 pressed the CLEAR key. (See <i>3270 Component Description</i> , GA27-2749.)	A5
8	8000	08	TERMINAL NO LONGER AVAIL- ABLE: The terminal operator went into command interrupt mode and was released (/RELEASE command). The terminal is no longer available to this program.	А3

See last page in this section for description of these program action codes.

CCP Return Codes				Program Action	
Dec	Hex	RPG II	Description	Code <sup>1</sup>	
9	0009	09	TERMINAL OFFLINE: The requested terminal was varied offline and is not available to this program.	А3	
10	000A	10	STOP INVITE INPUT SUCCESS- FUL: The request to stop invite input was successful; the invite input was canceled.	A1	
11	000B	11	ACQUIRE TERMINAL FAILED: The attempt to acquire a terminal for this program has failed.	A1	
-1	FFFF	OJ	DATA CHECK: Data was received incorrectly, checking error condition detected.	A2	
-2	FFFE	ок	INVALID CHARACTER: (1) During translation of data, an invalid character was found. (2) An invalid ASCII character has been detected by BSCA.	A2	
-3	FFFD	OL	LOST DATA: Data received was lost because it exceeded the size of the input buffer.	A2	
-4	FFFC	ОМ	PERMANENT BSCA ERROR: Operation failed because a perma- nent error condition was detected.	A2	
-5	FFFB	ON	ABNORMAL RESPONSE: An invalid response was received from the remote station.	A2	
-6	FFFA	00	TRANSMIT/RECEIVE ABORT: Data transfer failed and the tele- processing line has been closed. CCP has varied offline all terminals on this line.	А3	
<b>-7</b>	FFF9	ОР	NO RESPONSE TO POLLING/ ADDRESSING: The selected terminal does not respond to polling or addressing.	A2	
-8	FFF8	OΩ	TEXT TIME OUT: The terminal does not respond to attempted data transfer.	A2	

See last page in this section for description of these program action codes.

cc	P Return	Codes		Program Action
Dec	Hex	RPG II	Description	Code 1
-9	FFF7	OR	WAIT TIME EXCEEDED: Data was not sent or received before EOT within a specified time frame.	A2
-10	FFF6	1	NO CONNECTION: Unable to establish a connection with the remote station.	A2
-11	FFF5	1 }	INVALIDIDs: The ID exchange with the remote station failed.	A2
-12	FFF4	1K	ABORT, DISCONNECT: The switched line connection to the remote station has been lost.	A2
-13	FFF3	1L	ADAPTER CHECK: A hardware check occurred on the teleprocessing line adapter.	A2
-14	FFF2	1 M	NEGATIVE RESPONSE TO ADDRESSING: The remote terminal has an error condition that prevents it from successfully receiv- ing data.	A2
		9J	OPERATION NOT PERFORMED (RPG II SPECIAL): The operation was not performed because indicator 91 was set on by a previous operation and was not set off.	A2
-20	FFEC	2	3270 device is unavailable or not ready	A2
-21	FFEB	2J	Reserved <sup>2</sup>	
-22	FFEA	2K	3270 equipment check; device end	A2
-23	FFE9	2L	3270 detected a BSCA error	A2
-24	FFE8	2M	3270 control check; data check	A2
-25	FFE7	2N	3270 data check on copy command	A2
-26	FFE6	20	3270 operation check—copy command	A2

 $<sup>^1\</sup>mathrm{See}$  last page in this section for description of these program action codes.  $^2\mathrm{This}$  return code is not returned to the user if CCP detects this condition and the operations message, followed by a 2F termination code, is displayed.

CC Dec	P Return Hex	Codes RPG II	Description	Program Action Code <sup>1</sup>
-27	FFE5	2P	3270 device busy with copy command	A2
-28	FFE4	2Q	3270 control check, operation check, data check during copy command	A2
~29	FFE3	2R	3270 invalid data from 3270 using DFF. <sup>2</sup>	A2
-40	FFD8	4 }	3735 attempted send before receive	Α7
~41	FFD7	4.j	3735 invalid character	A2
-42	FFD6	4K	3735 buffer overflow	A2
-43	FFD5	4L	3735 disk full	A5
-44	FFD4	4M	3735 directory full	A5
-45	FFD3	4N	3735 undefined header	A2
-46	FFD2	40	3735 disk error	A2
-50	FFCE	5 }	3741 transparency error occurred	A2
-51	FFCD	5J	3741 no activity within 20 seconds	A2
-52	FFCC	5K	3741 data check	A2
-53	FFCB	5L	3741 received line bid error	A2
-54	FFCA	5M	3741 wrong length error	A2
-55	C9	5N	3741 reset was pressed on 3741	A5
-56	C8	50	3741 security check	A5
-57	C7	5P	3741 disk overflow	A5
-58	C6	5Q	3741 bad extent error	A2
-59	C5	5R	3741 both stations transmit	Α7
-60	C4	G }	3741 length error	A2
-61	С3	6J	3741 no record found on disk	A2

<sup>&</sup>lt;sup>1</sup>See last page in this section for description of these program action codes.

<sup>2</sup>This condition code is returned to the user if TEST REQ is passed to a 3270 that has an invite input outstanding.

CCP Return Codes				Program Action
Dec	Hex	RPG II	Description	Code <sup>1</sup>
-62	C2	6K	3741 seek error	A2
-63	C1	6L	3741 read error	A2
-64	CO	6M	3741 write error	A2
-65	BF	6N	3741 not ready	A2
-66	FFBE	60	3741 diskette label is write protected	A2

Program				
Action				
Code	Description	1		1

- A1 Continue normal processing.
- A2 Attempt to determine the cause of the error and retry the operation if appropriate; otherwise, go to the next logical operation.
- A3 Do not reissue the operation to this terminal.
- A4 Go to end of job as soon as logically possible.
- A5 Process according to the requirements of the application.
- A6 Process data until EOT on the terminal for which data is pending.
- A7 Issue a get operation or go to end of job.

 $<sup>^{\</sup>rm 1}\,{\rm See}$  last page in this section for description of these program action codes.

## **BSCA CONTROL CHARACTERS AND CODES**

# EBCDIC

_	EBCDIC					
	Hex	Char	Hex	Char	Hex	Char
	00	NUL	32	SYN	83	С
	01	SOH	34	PN	84	d
	02	STX	35	RS	85	е
	03	ETX	36	UC	86	f
	04	PF	37	EOT	87	9
	05	нт	3C	DC4	88	h
	06	LC	3D	NAK	89	i
	07	DEL	3E	ACK	91	į
	09	RLF	3F	SUB	92	k
	0A	SMM	40	SP	93	1
	ОВ	UT	4A	¢	94	m
	0C	FF	<b>4</b> B		95	n
	0D	CR	4C	<	96	0
	0E	SO	4D	(	97	Р
	0F	SI	4E	+	98	q
	10	DLE	4F	I	99	r
	11	DC1	50	&	A1	~
	12	DC2	5A	!	A2	s
	13	DC3	5B	\$	A3	t
	14	RES	5C	•	A4	u
	15	NL	5D	)	A5	v
	16	BS	5E	;	A6	w
	17	IL	5F	_	A7	x
	18	CAN	60	-	A8	У
	19	EM	61	/	A9	z
	1A	СС	6A		CO	{
	1C	IFS	<b>6</b> B	,	C1	À
	1D	EGS	6C	%	C2	В
	1E	IRS	<b>6</b> D		C3	С
	1F	IUS	6E	>	C4	D
	20	DS	6F	?	C5	E
	21	SOS	79	\	C6	F
	22	FS	7A	:	C7	G
	24	BYP	7B	#	C8	Н
	25	LF	7C	@	C9	I
	26	EOB (ETB)	7D		D0	}
	27	PRE (ESC)	7E	=	D1	Ĵ
	2A	SM	7F	"	D2	K
	2D	ENQ	81	а	D3	L
	2F	BEL	82	ь	D4	М

## BSCA CONTROL CHARACTERS AND CODES (Continued)

Hex	Char	Hex	Char	Hex	Char
D5	N	E6	w	F6	6
D6	0	E7	X	F7	7
D7	P	E8	Y	F8	8
D8	Q	E9:	z	F9	9
D9	Ř	F0	0		•
		. •			
E0	\	F1	1		
E2	S	F2	2		
E3	Т	F3	3		
E4	U	F4	4		
E5	V	F5	5		
ASCII					
00	NUL	1E	RS	3C	<
01	SOH	1F	US	3D	
02	STX	20	SP	3E	= >
03	ETX	21	!	3F	?
04	EOT	22	· ''	40	@
04	201			10	
05	ENQ:	23	#	41	A
06	ACK	24	\$	42	В
07	BEL	25	%	43	С
80	BS	26	&	44	D-
09	нт	27	•	45	E
0A	LF	28	•	46	F
0B	VT	29	)	47	G
0C	FF	2A	•	48	H
OD	CR	28	+	49	ŧ
0E	so	2C	•	<b>4</b> A	J
0F	SI	2D	_	4B	Κ
10	DLE	2E		4C	L
11	DC1	2F	1	4D	M
12	DC2	30	0	4E	N
13	DC3	31	1	4F	0
14	DC4	32	2	50	P
15	NAK	33	3	51	Q
16	SYN	34	4	52	R
1.7	ETB	35	5	53	S
18	CAN	36	6	54	Т
19	EM	37	7	55	U
1A	SUB	38	8	56	v
1B	ESC	39	9	57	W
1C	FS:	3A	:	58	х
1D	GS	3B	;	59	Υ

## BSCA CONTROL CHARACTERS AND CODES (Continued)

	Hex	Char	Hex	Char	Hex	Char
	5A	Z	69	i	78	x
	5B	[	6A	j	79	У
	5C	\	<b>6</b> B	k	7A	z
	5D	]	<b>6</b> C	1	7B	{
	5E	-	<b>6</b> D	m	7C	1
						Į
	5F		<b>6</b> E	n	<b>7</b> D	}
	60	,	6F	0	7E	, <del>~</del>
	61	a	70	р	7F	DEL
	62	b	71	9		
	63	С	72	r		
	64	d	73	s		
	<b>6</b> 5	e	74	t		
_	66	f	75	u		
	67	g	76	v		
	68	h	77	w		

## CONTROL CHARACTERS

Char	EBCDIC	ASCII	Char	EBCDIC	ASCII
ACK0	1070	1030	ITB	1 F	1 F
ACK1	1061	1031	NAK	3D	15
DISC	1037	1004	RVI	107C	103L
DLE	10	10	soh	01	01
ENQ	2D	05	STX	02	02
EOT	37	04	SYN	32	16
ETB	26	17	TTD	022D	0205
ETX	03	03	WACK	106B	103B

## HOW TO DETERMINE THE WRITE CONTROL CHARACTER (WCC)

Select bits 2-7.

1		
Bit	Name	Explanation
2,3	Printer	Define the printout format as follows:
		OD The NL order in the data stream determines print line length.
		01 Specifies 40-character print line.
		10 Specifies 64-character print line.
		11 Specifies 80-character print line.
4	Start Printer	Start Printer bit, when set to 1, initiates a printout operation at completion of the write operation.
5	Sound Alarm	The sound alarm bit, when set to 1, sounds the audible alarm at the selected device at the end of the operation if that device has an audible alarm.
6	Keyboard Restore	The keyboard restore bit, when set to 1, restores operation of the keyboard by resetting the input inhibited indicator. It also resets the AID byte at the termination of the I/O command.
7	Reset MDT	When reset MDT bits are set to 1, all MDT bits in the selected devices' existing buffer data are reset before any

data is written or orders are executed.

# HOW TO DETERMINE THE WRITE CONTROL CHARACTER (WCC) (Continued)

Match chosen bits with bits 2-7 in chart.

3.

Use EBCDIC graphic for that bit configuration. (This graphic determines contents of bits 0 and 1.)

Bit	s 2-7	EBCDIC Graphic	ASCII
00	0000 0001 0010	(space) A B	20 41 42
	0011 0100	C D	43 44
1	0101 0110	E F	45 46
	0111 1000	G Н	47 48
	1001	1	49
00	1010 1011	¢ <	5B 2E
00	1100	( +	3C 28
00	1110	1	2B 21
01	0000	& J	26 4A
1 .	0010 0011	K L	4B 4C
	0100 0101	M N	4D 4E
01	0110 0111	O P	4F 50
1 .	1000	Q	51
01 01	1001 1010	R !	52 5D
01	1011 1100	\$ •	24 2A
01		)	29
	1110 1111 0000	;	3B 5E 2D
10	0000 0001 0010	/ S	2F 53

Bits 2-7	EBCDIC Graphic	ASCII
10 0011	Т	54
10 0100	U	55
10 0101	V	56
10 0110	w	57
10 0111	X	58
10 1000	Υ	59
10 1001	<b>Z</b> 1	5A
10 1010	} 1	5C
10 1011	•	2C
10 1100	%	25
10 1101	>	5F
10 1110		3E
10 1111	?	3F
11 0000	0	30
11 0001	1	31
11 0010	2	32
11 0011	3	33
11 0100	4	34
11 0101	5	35
11 0110	6	36
11 0111	7	37
11 1000	8	38
11 1001	9	39
11 1010	÷	3A
11 1011	#	23
11 1100	@	40
11 1101	•	27
11 1110	=	3D
11 1111		22

<sup>&</sup>lt;sup>1</sup>The character is converted internally to hex 6A for a WCC character by DFGR when DFGR generates a format, and by DFCR when using the WCC in a put override operation.

#### STARTUP SPECIFICATIONS

#### \*SU011 ANY SPECIFICATIONS?

(Enter YES to make changes via prompter mode; otherwise, use keywords.)

UNIT Unit for \$CCPFILE

LOG Unit for \$CCPLOG (Model 4 only)

SET Assignment set ID

MAXEUP Maximum number of concurrent user programs

MINUPA Minimum user program area (nn.nnk)
MINTPBUF Minimum TP buffer area (nnnnn) bytes

PASSWORD Sign on password (ccccc)

TRACEBLK<sup>1</sup> Size of in-storage CCP trace (0, 1, 2, 3, 4, 6, 8, 12, 24)

256-byte blocks

Also activates trace to disk function.

TRACEMLTA MLTA line number to trace (1-8) or all (A) (Can be repeated

for different lines)

TRACEMLMP<sup>1</sup> Trace BSCA (no operand)

SUPPRESS End of specifications (Return control at SU300.)
OFFLINE End of specifications (Return control at SU340.)

CANCEL Causes end of job

CHANGE YES allows corrections, NO causes end of specifications

(same as null reply)

\*SU300 ANY FACILITY TO BE SUPPRESSED?

NO or null reply causes control to return at SU940.

\*SU320 DISKFILE NAME TO BE SUPPRESSED?

Enter physical file name or end.

\*SU330 SYMFILE NAME TO BE SUPPRESSED?

Enter symbolic file name or end.

\*SU30S PROGRAM NAME TO BE SUPPRESSED

Enter program name or end.

\*SU345 BSCA LINE NUMBER TO BE SUPPRESSED

Enter line number or end.

\*SU360 MLTALINE NUMBER TO BE SUPPRESSED

Enter line number or end

\*SU375 TERMINAL ID TO BE SUPPRESSED

Enter terminal ID or end.

<sup>&</sup>lt;sup>1</sup>These options available by keyword only.

## STARTUP SPECIFICATIONS (Continued)

\*IS PROGRAM REQUEST COUNT TO BE SUPPRESSED?

Enter YES, NO, or end.

\*SU940 SPECIFY ANY OFFLINE TERMINAL ID

Enter terminal ID or end.

\*SU918 SPECIFY ANY EXTRA USER PROGRAM AREA

Enter the amount of extra storage to allocate to the user program area (nn.nnK).

## CONSOLE OPERATOR COMMANDS

Send a message to a command terminal that is not in data mode.

Display outstanding console reply requests.

Display queued programs and the terminal that requested them.

Display status of specified terminal 1, or all assigned terminals.

- Physical id/symbolic name
- Associated user task (P if none)
- Status (online/offline)
- Mode (data, command, etc.)
- Has terminal issued program request?
- Number of file specification blocks (FSB)
- Error recovery/online test in effect?

$$\left\{\begin{array}{c} \text{DISPLAY} \left\{\begin{array}{c} \text{M} \end{array}\right\} \\ \text{D} \end{array}\right\} \left\{\begin{array}{c} \text{TERMADDR} \\ \text{A} \end{array}\right\} \left[\begin{array}{c} \text{symbolic name} \end{array}\right] \left[\begin{array}{c} \text{D} \end{array}\right]$$

Display physical id for specified terminal (1), or all assigned terminals.

## CONSOLE OPERATOR COMMANDS (Continued)

#### Insert as status in display users:

#### Hex Mask

8000	Waiting for communication I/O completion
4000	Waiting for disk I/O completion
2000	Waiting for accept input completion
1000	Waiting for shutdown request
0800	Waiting for transient area 1 free
0400	Waiting for enqueued data sectors
0800	Waiting for main storage allocation
0040	Waiting for disk file allocation
0020	Waiting for unit record allocation
0010	Waiting for terminal allocation
8000	Waiting for DSM availability
0004	Waiting for unit record device ready
0002	Waiting for DFF output hold area space

## Display status of user task(s):

- Task id
- Program name
- Storage usage
- Number of terminals used
- Number of disk files used
- Number of unit record devices used
- Status (suspend, active, wait)
- Whether or not in allocation

# For (1)(specified) or (2) (last) user task display also:

- Terminal symbolic names
- Terminal identifications
- Terminal queued/active indicator
- Terminal I/O scheduled
- Disk file labels
- Unit record devices used

Allocate 1) or deallocate 2) specified device to CCP

$$\left\{\begin{array}{l} \text{SUSPEND} \\ \text{S} \end{array}\right\} \quad \text{$\begin{tabular}{l} \textbf{b} \\ \textbf{commands} \end{array}} \left\{\begin{array}{l} \text{USERS } \boxed{1} \\ \text{task id, program name } \boxed{2} \\ \text{INIT } \boxed{3} \\ \text{COMMANDS } \boxed{\bullet} \end{array}\right\}$$

## CONSOLE OPERATOR COMMANDS (Continued)

- (1) Suspend execution and initiation of user programs.
- (2) Suspend execution of specified task.
  - 3 Prevent program initiation.
- Prohibit terminal operator commands from terminals not in command interrupt mode.

Reset effect of SUSPEND command

Place specified terminal on or offline

Assign a symbolic name to specified terminal. If  $\bigcirc$ 1, assign a telephone number from switched terminal table (STT) to specified terminal.

Activates specified trace facility.

(For CCP, begin trace to disk.)

- ①, ② Start online test of specified MLTA terminal, if ④ loop on the specified test number.
  - (3) Stop a test currently being looped on.

Request online test from BSCA CPU. Valid text numbers are 0, 1, 6, 14. (Text) data applies to tests 0 and 1.

## CONSOLE OPERATOR COMMANDS (Continued)

$$\left\{\begin{array}{c} \mathsf{CANCEL} \\ \mathsf{C} \end{array}\right\} \quad \text{$\mathsf{b}$} \quad \left\{\begin{array}{c} \mathsf{task} \ \mathsf{id}, \ \mathsf{program} \ \mathsf{name} \end{array} \right. \left. \begin{array}{c} \mathsf{1} \\ \mathsf{CCP} \end{array} \right. \right\}$$

Immediately cancel specified 1 task or all 2 user tasks. For 2 , CCP terminates.

#### SHUTDOWN

Causes CCP to terminate after all currently executing or queued programs have completed processing.

#### Additional Console Operator Facilities for Model 4

Command key 8 Page forward in log file

Command key 7 Page backward in log file

Command key 6 Bypass error on 3277 console

## Field Lights for Model 4

Lights 1-3 Alternates from 3 through 1 on a pass through the

dispatcher

Light 4 Not used

Light 5 On indicates that task is awaiting operator reply

Light 6 On indicates that 3277 console is in ERP

Light 7 On indicates that oldest console message is not on screen

Light 8 On indicates that newest console message is not on screen

## TERMINAL OPERATOR COMMANDS

/MSG & text

Note: When reference name is specified without specifying actual name, the reference is canceled. When neither operand is specified, all references are canceled.

#### TERMINAL OPERATOR COMMANDS (Continued)

/Q Queue program request when resources not available.

/NOO

/RUN Return to program control from command interrupt mode

/RELEASE Release terminal from program control from command interrupt mode

The system console operator can also enter:

/Q, /NOQ, or /FILE.

The symbolic name of the console is CONSOL

#### MI TERFII

MLTERFIL is located on F1 and consists of twenty-four 256-byte records.

Record 0 MLTA OBB (outboard recorder) contains permanent error indications.

- Byte 0-1 Displacement to the most recent entry (6, 11, ..., 251)
  - 2-3 Reserved
  - Total error count 4-5
  - 6-255 Fifty 5-byte permanent error entries
- Byte 0 Line number (1-8)
  - Terminal address (hex 00 if not polled)
  - 2 High density buffer position 0 (HDB0):

Hex	
Value	Meaning
80	PCI overrun
40	Uppercase
20	Text-in mode
10	Text-out mode
Bits 4-7	Bit time count fi

3 High density buffer position 6 (HDB6):

Hex	
Value	Meaning
80	Timeout
40	Data check
20	Transmit abort
10	Receive abort
08	Overrun
04	Terminal interrupt
02	No operation performed on instruction
01	Lost data

eld

## MLTERFIL (Continued)

4 High density buffer position 7 (HDB7):

Hex Value	Meaning	
80	Modem not ready	
10	Line not ready	
Bits 5-7	SIO n-code	

#### Records 2-8 MLTA SDR (statistical data recorder):

Byte 0-1 Invalid terminal address count

2-3 Reserved

4-255 Forty-two 6-byte statistical entries (one for each terminal address)

(Order of entries by terminal address is /, A-Z, 0-9, @, -, \$, ., &).


Bytes 0-1 Number of errors of all types

2-5 Number of successful read/write operations (exclusive of poll with negative response and WTDS)

Records 9-17, reserved.

Records 18-20 MLMP terminal statistics line 1:

Byte 0 of each sector is the displacement of the next available byte (hex 00 indicates no logging has been done in this sector).



Entries are variable length

- L Length of terminal address (1 byte)
- A Terminal address (1-7 bytes)
- U Number of unsuccessful operations (2 bytes)
- S Number of successful operations (4 bytes)

The last entry in a sector delimited by hex F0.

The last entry for the line delimited by hex FE.

Records 21-23 MLMP terminal statistics line 2

# BSCA SDR/OBR

## E1 C/S 001/

F1 C/S 0014			
	Displacement (hex) of four-byte cumulative counters		
1	Displacement (hex) of two-byte temporary counters		
77	AB	Text blocks sent	
7B	AD	Text blocks received	
7F	AF	NAKs received	
83	B1	Data checks	
87	В3	Foreward aborts received	
8B	B5	Aborts received	
8F	B7	Adapter checks on transmit	
93	В9	Adapter checks on receive	
97	ВВ	Invalid responses	
9B	BD	ENQs received to acknowledgments sent	
9F	BF	Lost data errors	
А3	C1	Disconnect timeouts	
A7	C3	Receive timeouts	











## Index

\$CC\$\$A 2-47 \$CCCOM (CCP communication area) 1-69 \$CCCOM, how to find 2-11 \$CCPDD, how to use \$CCPFILE, disk layout of 1-34 \$CCPLOG file (Model 4 only) \$CCSCN used with scan control block 1-60 \$CC4 load modules 2-1 \$CC4CM return to IOCS after check on op end trace type 0A 2-35 return to IOCS after start I/O trace type 0B/1B 2-36 \$CC4II entry to user I/O interface trace type 0C 2-38 return to user trace type 0E 2-40 \$CC4IS entry to system I/O interface trace type 0D 2-39 \$WORK2 (see work file) /file specifications, how to determine 2-22 active task control block, how to find user program module by 2.14 activity, work file 1-18 adapter, MLTA DTF 1-127 additional cells, console address characters, terminal identification 1-168 address pointers, queue/list origin 1-72 address table 1-3 address table in a CCP transient, relocation 1-176 addresses of CCP, MLTA, and BSCA trace routines 1-72 component work areas 1-69 disk I/O intercept points in CCP dispatcher 1-71 DSM data management routines, disk 1-78 system task control blocks (TCB) 1-69 addresses, dynamic (task control block) 1-76 allocation control block buffer storage 1-73 user program area 1-73 allocation work area 1-90 allocation/usage bytes, unit record 1-77 allocation, storage 2-5

```
area
```

```
1-90
  allocation work
  boundaries, how to find user program 2-13
  BSCA I/O
               1-126
  BSCA work
                1-119
  CCP communication ($CCCOM) 1-69
  CCP execution data
                     1-69
  command processor work
  common register save
                        1-71
  communication management work
                                    1-92
  console IOB work (Models 8, 10, and 12)
                                         1-94
  console management work
     Model 4
               1-95
     Models 8 10 and 12 1-93
  control blocks and data
                          2-2
  DFF data
             1-177
  DFGR common 1-177
  dispatcher work 1-74
  display format facility work 1-80
  expansion 1-79
  general work
                 1-76
  main storage table save
                          1-30
  MLTA IOCS common
                       1-146
  organization of BSCA IOB and buffers in I/O 1-126
                  1-78
  password save
  PFGR common
                   1-177
  RPG II
           1-158
  startup
     data
            1-57
            1-58
     save
  task control block user 1-87
  termination work
                    1-91
  user program dump
                      1-78
  user record 1-157
                    1-157
     RPG II output
     RPG input
                1-157
ASCII
  codes
          2-72
  control characters
                     2-72
assignment build local data areas
association, symbolic file 2-9
attributes set fields, current terminal 1-172
attributes set, terminal
                      1-164
attributes table, terminal
                        1-164
```

1-178

2-14

attributes, format physical (first entry)

available space boundaries, how to find user program area

```
binary synchronous communications adapter (see BSCA)
block
   addresses of system task control 1-69
   RSCA
      input/output 1-115
      line control
                   1-105
   buffer storage allocation control
   console buffer control
                          1-73
   control and data areas
                           2-2
   dynamic addresses of task control 1-76
   execution time control
                          2-3
   file specification 1-98
   free segment control 1-155
   main storage control 1-155
   MLTA line control
                      1-128
   scan control used with $CCSCN
                                    1-60
   sector queue 1-159
   segment control
                    1-159
   system task control, how to find
                                    2-12
   task control
               1-82
                 1-56, 1-167
   terminal unit
   user task control, how to find 2-12
boundaries, how to find
   particular user program
   user program area
                       2-13
   user program area space available
                                      2-14
boundaries, main storage management allocated storage 2-23
RSCA
   addresses of trace routines
   control characters and codes
                               2-71
   I/O area 1-126
         1-115
   IOB and buffers in I/O area, organization 1-126
   LCB
         1-105
  line control block (LCB)
                           1-105
   only segment, second
                          1-114
  receive buffer
                  1-118
   SDR/OBR
               2-83
   statistical data recording/outboard recording
  switched lines only (optional)
                                 1-47
  terminals on control station or multipoint lines only 1-56
          2-42
   trace, how to find
                     2-25
  transmit buffer 1-118
  work area 1-119
buffer area, communications
buffer control block, console
                              1-73
buffer invite input hold 2-20
buffer layout, console
                       1-98
buffer storage allocation control block
```

buffer
BSCA
I/O area, organization of 1-126
receive 1-118
transmit 1-118
console 2-20
console input 1-94
length 2-23
location 2-23
receive 1-118
teleprocessing 2-23
teleprocessing line 2-17
transmit 1-118
bytes
console status 1-101
end-of-list 1-145 parameter 1-145
parameter 1-145
unit record allocation 1-77
unit record usage 1-77
ů
CCP
addresses of trace routines 1-72
communication area (\$CCCOM) 1-69
execution data areas 1-69
execution, main storage during 2-1
trace 2-26
trace tables, how to find 2-24
transient
beginning of a 1-175
relocation address table 1-176
CCPIVP, disk record created by 1-187
CDE (contents directory entry) 1-149
cells, console additional 1-101
chain fields, queue 1-171
character
control 2-73
write control 2-74
classes, DFF field 1-186
codes
ASCII 2-72
BSCA 2-71
EBCDIC 2-71
operation 2-63
program termination 2-51
return 2-66
COMARA (see communications area)
command processor work area 1-89

```
commands
   console operator 2-77
   terminal operator
                    2-80
COMMON (see common area)
common area 1-4
   $CGNBX 1-15
   $CGNCM
             1-5
   $CGNIN 1-5
   $CGNPE 1-10
   $CGNPS 1-11
            1-7
   $CGNSB
   $CGNSF 1-7
   $CGNSS 1-9
   $CGNSX 1-15
   DFGR 1-177
   MLTA IOCS 1-146
   PFGR 1-177
common register save areas 1-71
communication management work area 1-92
communications area
   address table 1-3
   CCP ($CCCOM) 1-69
   DTFs
        1-3
   IOBs
          1-3
   printer 1-17
   transfer vector 1-3
communications buffer area, how to find 2-16
communications control program (see CCP)
communications parameter list 1-151
communications parameter list, last 2-16
component work areas, addresses 1-69
compressed table
   file control
             1-30
   line control 1-30
   program characteristics 1-31
  terminal name 1-32
   terminal used 1-33
configuration record 1-35
console additional cells 1-101
console buffer 2-20
  control block 1-73
               2-20
  how to find
  layout
         1-98
console input buffer 1-94
console input queue, how to find 2-21
console IOB
  Models 8, 10, and 12 1-99
  work area (Models 8, 10, and 12) 1-94
console management work area
  Model 4 1-95
  Models 8, 10, and 12 1-93
console manager, data fields passed to 1-94
```

```
console operator
               2-77
  commands
  facilities (Model 4) 2-80
console output queue, how to find 2-21
console requests from $CC4CM transients 1-94
console status byte 1-101
constants and work areas, DFF program appended storage 1-182
constants, system 1-71
contents directory entry (CDE) 1-149
  how to find user program module by
control block
  addresses of system task 1-69
  BSCA line
              1-105
  buffer storage allocation
                           1-73
  console buffer 1-73
  dynamic addresses, task
                           1-76
  execution time 2-3
  free segment 1-155
  main storage
                1-155
  MLTA line 1-128
  scan used with $CCSCN 1-60
  segment 1-159
  system task, how to find 2-12
  task 1-82
  user program area, allocation 1-73
  user task, how to find 2-12
control blocks and data areas 2-2
control characters 2-73
  ASCII
          2-72
  BSCA
          2-71
           2-71
  EBCDIC
        2-74
  write
control record, work file
                      1-20
control statement keyword parameter list 1-27
control station lines only 1-47
```

copy text and work area 1-183 cross-reference data, work file 1-25 current terminal attribute set fields 1-172

```
data areas 1-1
   assignment build local
   CCP execution
                  1-69
   DFF
          1-177
            1-57
   startup
data areas and control block
                             2-2
data fields passed to console manager
data management routines, disk addresses of DSM 1-78
data mode escape fields
                         1-172
data recording table, statistical
define the file (see DTF)
dependent, device
                    1-142
device dependent section
DFF
   data areas
               1-177
   field classes
                1-186
   field descriptor table (FDT) 1-178
   format table (FT)
                     1-181
   program appended storage (PAS) constants and work areas 1-182
   terminal table (TT)
                      1-180
DFGR common areas
                      1-177
diagnostic aid
                2-1
directory
          1-41
directory entry, contents 1-149
disk addresses of DSM data management routines 1-78
disk drive
   5444
         1-162
   5445
          1-163
   5447
          1-162
disk DTF
   how to find
                2-18
          1-160
disk I/O intercept points in CCP dispatcher, addresses of
          1-103
disk layout of $CCPFILE
                        1-34
disk record created by CCPIVP
                               1-187
disk record, installation verification program 1-187
dispatcher
   initial entry trace type 01
                             2-26
   NCEIOS intercept trace type 02
                                   2-28
   NCEIOW intercept trace type 03
                                  2-29
   work area
              1-74
displacements for each ID to receive (optional) 1-47
display format facility 2-2
   load parameter list
                     1-81
   work area
              1-80
DSM data management routines, disk addresses of 1-78
DSM intercept 2-8
DTF
   communications area 1-3
   disk
         2-18
          1-110
   end of
   MLTA adapter
                   1-127
   references, symbolic-actual
                               2-19
   short disk
              1-160
   teleprocessing MLTA BSCA
dump area, user program
                          1-78
dump program
                2-47
dump program, stand alone (Models 8, 10, and 12 only)
dynamic addresses of task control block
                                       1-76
                                                            Index
                                                                    X-7
```

```
EAU text and work area
                       1-183
FBCDIC codes 2-71
EBCDIC control characters 2-71
end of DTF 1-110
end-of-list bytes 1-145
entries
   physical file name 1-44
   noll
        1-145
   symbol table
                1-24
   symbolic file name
                     1-44
  contents directory 1-149
   field 1-179
   first (format physical attributes) 1-178
   translated symbol table 1-25
entry to FREEMAIN ($CC4FM) trace type 09
                                           2-35
entry to GETMAIN ($CC4GM) trace type 08
                                           2-34
entry to post ($CC4PS) entry type 07 2-33
error record, work file
                     1-24
escape fields, data mode
execution data areas, CCP 1-69
execution time control blocks
execution, CCP, main storage during
expansion area
                1-79
facilities, console operator (Model 4) 2-80
facility, display format 1-80
FCT (file control table)
                      1-30, 1-43
FDT (field descriptor table), DFF 1-178
field
  classes, DFF 1-186
  current terminal attribute set 1-172
  data mode escape 1-172
  descriptor table, DFF 1-178
  entry 1-179
  lights (Model 4) 2-80
  queue chain 1-171
  terminal type 1-173
fields passed to console manager, data 1-94
file
  $CCPLOG for Model 4 1-56
                       2-9
  association, symbolic
  control table (FCT) 1-43
     compressed 1-30
     while building FCT entries 1-30
  indexed only 1-44
  indexed with master index only 1-44
  name entries
     physical
              1-44
               1-44
     symbolic
  specification block (FSB)
                          1-98
  support, symbolic 2-9
  table, symbolic 1-164
first entry (format physical attributes) 1-178
flags, system level 1-70
```

```
format
   facility, display 2-2
   physical attributes, (first entry) 1-178
   table, DFF
              1-181
format, work file
                  1-18
free segment control block
                          1-155
free storage chains, how to find
FREEMAIN parameter list 1-154
FSB (file specification block) 1-98
FT (format table), DFF 1-181
general entry intercept trace type 05
                   1-76
general work area
GETMAIN/FREEMAIN parameter list 1-154
halts, CCP 2-50
halts, CCP generation (Models 8, 10, and 12 only) 2-50
how to determine terminal operator's/file specifications
how to find
   $CCCOM
      with remap (during CCP execution only)
      without remap
                      2-11
   BSCA trace
                2-25
   CCP trace tables
                     2-24
  communications buffer area 2-16
   console
      buffer
              2-20
     input queue
                   2-21
     output queue
                    2-21
   diagrams
            2-11
  disk DTF
              2-18
   free storage chains
                       2-23
  invite input hold buffer for a teleprocessing line 2-20
  last communications parameter list
                                      2-16
  main storage management allocated storage boundary
   MLTA trace
                2-25
   particular user program boundaries 2-13
  system task control block (TCB)
   teleprocessing
     buffer length
                    2-23
     buffer location
                    2-23
     DTF (MLTA/BSCA)
                         2-16
     line buffers
                  2-17
                  2-20
     line queue
  terminal attribute set in terminal attribute table 2-21
   terminal unit blocks
                       2-22
     by symbolic terminal name
                                 2-15
     by terminal ID
                    2-15
     owned by a task
                        2-22
```

```
how to find (continued)
   user program area
      available space boundaries 2-14
      boundaries
                 2-13
   user program module
      by active task control block
                                   2-14
      by contents directory entry
                                  2-14
   user task
      control block (TCB)
                           2-12
      last teleprocessing I/O request 2-15
how to use $CCPDD
                      2-47
how to write service aid program 2-50
I/O area
           1-126
   BSCA
   organization of BSCA IOB and buffers in
ID to receive, displacements for each
                                     1-47
identification, terminal and address characters
                                              1-168
index, master with indexed files 1-44
indexed files only
                  1-44
indexed files with master index only 1-44
information table, system
                          1-52
input buffer, console
                    1-94
input queue, console
input/output (see I/O)
input/output block (see IOB)
input/output control system (see IOCS)
input, user record area for RPG
                               1-157
installation verification program disk record
intercept, DSM
               2-8
intermediate text data
                       1-19
                     2-6
interrupt processing
invite input hold buffer, how to find 2-20
IOB
   BSCA
          1-115
   BSCA I/O area, organization of
                                   1-126
  communications area
                        1-3
  console (Models 8, 10, and 12)
                                 1-99
  disk
         1-103
  keyboard (Model 4)
                      1-101
  MLTA IOCS 1-146
  work area, console (Models 8, 10, and 12) 1-94
IOCS
  common area, MLTA
  IOB, MLTA
               1-146
  MLTA 1-146
```

keyboard IOB (Model 4) 1-101 keyword parameter list, control statement 1-27

last communications parameter list, how to find last teleprocessing I/O request, user task layout \$CCPFILE 1-34 console buffer 1-98 I CB **BSCA** 1-105 MLTA 1-128 LCT (line control table) 1-30, 1-45 length, teleprocessing buffer lights, field (Model 4) line buffers, teleprocessing 2-17 line control block BSCA 1-105 MITA 1-128 line control table 1-45 line control table, compressed 1-30 line queue, teleprocessing 2-20 lines, BSCA switched only (optional) 1-47 lines, control station only 1-47 communications parameter 1-151 control statement keyword parameter 1-27 display format facility load parameter FREEMAIN parameter 1-154 GETMAIN/FREEMAIN parameter 1-154 last communications parameter 2-16 MLTA polling 1-145 phase roller 1-57 standard parameter 1-156 transient relocation XREF transient 1-65 load modules modules \$CC4 2-1 modules optional 2-2 load parameter list, display format facility 1-81 location, teleprocessing buffer 2-23

main storage
control block (SCB) 1-155
during CCP execution 2-1
management allocated storage boundary, how to find table save area 1-30
management work area, console (Model 4) 1-95
manager, data fields passed to console 1-94
master index with indexed files 1-44
miscellaneous pointers 1-79

```
MLTA
```

```
adapter DTF 1-127
   addresses of trace routines
                            1-72
  IOCS common area 1-146
   IOCS IOB 1-146
   LCB
         1-128
   line control block (LCB) 1-128
   polling list 1-145
   terminals on control station or 1050 switched lines only 1-56
         2-44
  trace
     F0 SIO 2-44
     F1 2-45
     F2
          2-46
     F3 op complete 2-46
     how to find
                 2-25
MLTERFIL
            2-81
Model 4 $CCPLOG file 1-56
modifier symbols, operation 2-64
module
  $CC4 load
              2-1
  optional load 2-2
multiple line terminal adapter (see MLTA)
```

name record, work file 1-21 name table, terminal 1-166 NCEIOW entry from dispatcher trace type 04 2-30

2-83

OBR, SDR, BSCA

```
operation codes
                2-63
operation modifier symbols 2-64
operation symbols
operator commands
             2-77
   console
             2-80
   terminal
operator facilities (Model 4)
                            2-80
optional load modules 2-2
organization of BSCA IOB and buffers in I/O area 1-126
origin address pointers, queue/list
                                  1-72
outboard recording, statistical data recording
output queue, console 2-21
output, user record area for RPG II 1-157
```

parameter bytes 1-145 parameter list communications 1-151 display format facility load 1-81 FREEMAIN 1-154 GETMAIN/FREEMAIN last communications 2-16 standard 1-156 particular user program boundaries, how to find 2-13 PAS (program appended storage), DFF 1-182 password save area 1-78 PCT (program characteristics table) 1-31, 1-48 PFGR common area 1-177 phase roller list 1-57 physical attributes, format (first entry) 1-178 physical file name entries only 1-44 pointers miscellaneous 1-79 queue/list origin address 1-72 poll entries 1-145 polling list, MLTA 1-145 printer communications area processing, interrupt 2-6 processor work area, command processor, rep statement 2-49 program appended storage (PAS) constants and work areas 1-182 program area available space boundaries, how to find user 2-14 boundaries, how to find user 2-13 program boundaries, how to find particular user 2-13 program characteristics table (PCT) 1-48 compressed 1-31 program dump 2-47 program service aid 2-50 program termination codes 2-51 program, installation verification, disk record program, stand alone dump (Models 8, 10, and 12 only) 2-48 queue chain fields 1-171

chain fields 1-171 console input 2-21 console output 2-21

teleprocessing line 2-20 queue/list origin address pointers 1-72

```
receive buffer 1-118
   BSCA
          1-118
record
   area, user 1-157
      RPG II output
                      1-157
      RPG input 1-157
   configuration
                  1-35
   symbol attribute
                     1-25
   symbol definition
                      1-25
   symbol reference
                     1-26
   translated name
                    1-25
   translated term
                    1-26
recording table, statistical data
                              1-150
references, symbolic-actual DTF
                                2-19
register save areas, common 1-71
relocation address table in a CCP transient 1-176
relocation list, transient
                       1-61
remap, how to find
   $CCCOM with
                   2-11
   $CCCOM without
                     2-11
rep statement processor
                         2-49
requests from $CC4CM transients, console
                                         1-94
return codes
              2-66
roller list, phase
                1-57
routines, addresses of CCP, BSCA, and MLTA trace 1-72
RPG II area
             1-158
   SUBR91
              1-158
   area SUBR92
                 1-158
RPG II output, user record area
                              1-157
RPG input, user record area 1-157
save area
  common register 1-71
   main storage table
                     1-30
  password
              1-78
  startup
            1-58
scan control block used with $CCSCN
                                      1-60
SCB (segment control block)
                            1-159
SCB (storage control block)
                            1-155
SDF (short disk DTF)
                      1-160
SDR (statistical data recording) table
                                    1-150
SDR/OBR, BSCA
                   2-83
second BSCA only segment
sector queue block (SQB)
                          1-159
segment control block (SCB)
                             1-159
segment control block, free
                          1-155
segment, second BSCA only 1-114
service aid program, how to write
                                  2-50
set, terminal attributes 1-164
```

short disk DTF (SDF) 1-160 SIT (system information table) 1-52 specification block, file 1-98 specifications startup 2-76 terminal operator's/file 2-22 SQB (sector queue block) 1-159 stand alone dump program (Models 8, 10, and 12 only) 2-48 standard parameter list 1-156 startup data areas 1-57 save area 1-58 specifications 2-76 statement processor, rep 2-49 statistical data recording (SDR) table 1-150 statistical data recording/outboard recording 2-83 status byte, console 1-101 storage allocation 2-5 storage allocation control block, buffer 1-73 storage control block 1-155 storage during CCP execution, main 2-1 storage, program appended (DFF) 1-182 STT (switched terminal table) 1-56, 1-163 SUBR91, RPG II area 1-158 SUBR92, RPG II area 1-158 support, symbolic file 2-9 switched BSCA line only (optional) switched terminal table (STT) 1-56. 1-163 symbol attribute record, work file 1-25 symbol definition record, work file 1-25 symbol reference record, work file 1-26 symbol table 1-17 entries, work file 1-24 entry, translated 1-25 symbolic file association 2-9 name entries only 1-44 support 2-9 table (XDT) 1-164 symbolic-actual DTF references 2-19 symbols, operation 2-63 symbols, operation modifier 2-64 system constants 1-71 system information table (SIT) 1-52 system level flags system task control blocks addresses of 1-69 how to find 2-12

```
table
   CCP trace 2-24
   DFF
      field descriptor 1-178
      format
               1-181
      terminal
                1-180
   entries, symbol
                    1-24
   file control
                1-43
      compressed
                   1-30
      while building FCT entries 1-30
               1-45
   line control
      compressed
                    1-30
   program characteristics
                          1-48
      compressed
                   1-31
   relocation address in a CCP transient
                                       1-176
   statistical data recording 1-150
   switched terminal 1-56, 1-163
   symbolic file
                1-164
   system information
                        1-52
   terminal attributes 1-31, 1-164
   terminal attributes use
   terminal name
                   1-56, 1-166
      compressed
                   1-32
   terminal used
                  1-54
      compressed
                   1-33
TAS (terminal attributes set) 1-164
TAS in TAB 2-21
task control block (TCB)
                        1-82
   address of system
                      1-69
   dynamic addresses
                       1-76
                         2-12
   system, how to find
              1-87
   user area
   user, how to find
                    2-12
TAT (terminal attributes table)
                              1-31, 1-164
TAU (terminal attributes use table) 1-32
TCB (task control block)
                         1-82
   addresses of system
                         1-69
   system, how to find
                         2-12
             1-87
   user area
   user, how to find 2-12
teleprocessing
   buffer length, how to find
                            2-23
   buffer location, how to find
                              2-23
   DTF, how to find (MLTA/BSCA)
                                    2-16
   I/O request, user task last
                              2-15
  line buffers, how to find
                            2-17
  line queue, how to find
                           2-20
term record, work file
                     1-22
terminal attributes set (TAS)
                            1-164
   fields, current
                  1-172
   terminal attribute table, how to find
terminal attributes table (TAT)
                              1-31, 1-164
terminal attributes table, terminal attributes set in
                                                 2-22
terminal attributes use (TAU) table 1-32
```

```
terminal identification and address characters 1-168
terminal name table (TNT) 1-56, 1-166
  compressed 1-32
terminal operator commands
                           2-80
terminal operator's/file specifications, how to determine 2-22
terminal table
  DEE 1-180
  switched 1-56, 1-163
terminal type fields.
                  1-173
terminal unit block (TUB) 1-56, 1-167
  how to find by symbolic terminal name 2-15
  how to find by terminal ID 2-15
terminals
  BSCA on control station or multipoint lines only 1-56
  MLTA on control station or 1050 switched lines only 1-56
terminals used table (TUT)
                         1-54
  compressed
               1-33
termination codes, program 2-51
termination work area 1-91
text copy and work area
                        1-183
text data, intermediate 1-19
text EAU and work area 1-183
TNT (terminal name table) 1-56, 1-166
  compressed 1-32
trace
  BSCA 2-25, 2-42
  halt $CC$$A 2-47
         2-25, 2-46
  MLTA
  routines, addresses of CCP, BSCA, and MLTA 1-72
  tables, CCP 2-24
  type
     OA. $CC4CM return from IOCS after check on op end
     0B/1B, $CC4CM return from IOCS after start I/O
                                                     2-36
     OC, $CC4II entry to user I/O interface 2-38
     0D, $CC4IS entry to system I/O interface
     OE. $CC4II return to user 2-40
     01, dispatcher initial entry
                              2-26
     02, dispatcher NCEIOS intercept 2-28
     03, dispatcher NCEIOW intercept 2-29
     04, NCEIOW entry from dispatcher 2-30
      05, general entry intercept
                                2-31
     06, transient request
                           2-32
     07, entry to post ($CC4PS)
                                 2-33
     08, entry to GETMAIN ($CC4GM)
                                       2-34
      09, entry to FREEMAIN ($CC4FM) 2-35
```


transfer vector 1-3

transient 1-175 \$CC4CM 1-94 CCP beginning of a 1-175 relocation address table 1-176 list XREE 1-65 relocation list 1-61 request trace type 06 2-32 translated name record 1-25 translated symbol table entry 1-25 translated term record 1-26 transmit buffer 1-118 BSC A 1-118 TT (terminal table), DFF 1-180 TUB (terminal unit block) 1-56, 1-167 TUB owned by a task, how to find 2-22 by symbolic terminal name 2-15 by terminal ID 2-15 TUT (terminals used table) 1-54 compressed 1-33 unit block, terminal 1-56, 1-167 unit record allocation/usage bytes 1-77 usage bytes, unit record allocation 1-77 user area, task control block 1-87 user program area allocation control block 1-73 available space boundaries, how to find boundaries how to find 2-13

boundaries, how to find particular 2-13 dump area information 1-78 module by contents directory entry, how to find 2-14 how to find by active task control block 2-14 1-157 user record area RPG II output 1-157 RPG input 1-157 user task control block, how to find 2-12 last teleprocessing I/O request, how to find 2-15 WCC (write control character) 2-74 work area addresses of component 1-69 allocation 1-90 BSCA 1-119 command processor 1-89 communication management console IOB (Models 8, 10, and 12) 1-94 console management Model 4 1-95 Models 8, 10, and 12 1-93 copy text 1-183 DFF program appended storage constants 1-182 dispatcher 1-74 display format facility 1-80 EAU text 1-183 1-76 general termination 1-91 work file activity 1-18 control record 1-20 cross-reference data 1-25 error record 1-24 format 1-18 intermediate text data 1-19 name record 1-21 symbol attribute record 1-25 symbol definition record 1-25 symbol reference record 1-26 symbol table entries term record 1-22 translated name record 1-25 translated symbol table entry 1-25 translated term record 1-26 write control character (WCC) 2-74

XDT (symbolic file table) 1-164 XREF transient list 1-65

5444 disk drive 5445 disk drive 1-163 5447 disk drive 1-162



- Descriptions of data areas
- Descriptions of how to use the diagnostic aids
- Additional references

Note: All displacements herein are relative to zero and are in hexadecimal notation. All lengths are in decimal notation. Field names reference the entire field and do not imply either leftmost or rightmost addressability.

### RELATED PUBLICATIONS

- IBM System/3 Model 4 Operator's Guide, GC21-5149
- IBM System/3 Communications Control Program Programmer's Reference Manual, GC21-7579
- IBM System/3 Models 8, 10, and 12 System Communication Control Program System Reference, GC21-7588
- IBM System/3 Communications Control Program (5702-SC1) Terminal Operator's Guide, GC21-7580
- IBM System/3 Models 8, 10, and 12 System Communications Control Program System Operator's Guide, GC21-7581
- IBM System/3 Multiline/Multipoint Binary Synchronous Communications Reference Manual, GC21-7573
- System/3 Multiple Line Terminal Adapter RPQ Program Reference and gent Description Manual, GC21-7560
- em/3 Disk Systems Binary Synchronous Communications Programprt Input/Output Control System Logic, SY21-0526
- A/3 Multiple Line Terminal Adapter RPQ Supporting RPQs S40028-S40033 Program Numbers 5799-WAU (Models 10 and 12) 5799-WEK (Model 15) Rogram Logic Manual, SY21-0527
  - IBM System/3 Models 4, 8, 10, and 12 Communications Control Program Logic Magual, 5 (21-0531 IBM System/3 Model 4 Communications Control Program Programmer's
- Reference Manual, C21-5150
- IBM System/3 Communication Control Program Messages Manual, GC21-5170
- IBM System/3 Disk Sort Reference Manual, SC21-7522
- IBM System/3 Communications Control Program System Design Guide, GC21-5165

iv



# **Technical Newsletter**

This TNL No.

SN21-7972

Date

30 June 1978 SY21-0048-1

Base Publ. No. File No.

S3-36

Previous TNLs

None

IBM System/3 Models 4, 8, 10, and 12 Communications Control Program Data Areas and Diagnostic Aids



This technical newsletter applies to the current versions and modifications of the applicable System/3 programs listed in the edition notice and provides replacement pages for the subject publication. These replacement pages remain in effect for subsequent versions and modifications unless specifically altered. Pages to be inserted and/or removed are:

3

Cover, Edition Notice

1-79, 1-80

1-83, 1-84

1-87, 1-88

Changes to text and illustrations are indicated by a vertical line at the left of the change.




## Summary of Amendments


#### Miscellaneous technical changes

*Note*: Please file this cover letter at the back of the manual to provide a record of changes.



IBM Corporation, Publications, Department 245, Rochester, MN 55901





# IBM

International Business Machines Corporation

General Systems Division 4111 Northside Parkway N.W. P.O. Box 2150 Atlanta, Georgie 30301 (U.S.A. only)

General Business Group/International 44 South Broadway White Plains, New York 10601 U.S.A. (International)