

THIS IS A COPYRIGHTED PROGRAM, COPYRIGHT 1970 BY VARIAN DATA MACHINES

V.D.M. PART NO. 92L0107-006A

RELEASED 10-29-70

620 TEST EXECUTIVE-PRELIM. TESTS

```

****      ****      ***** *          *** * *
* * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * *
****      ****      *** * * * * * * * *
* * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * *

```

```

000010
000020
000030
000040
000050
000060
000070

```

THIS TEST PROGRAM IS A PART OF THE SIX TWENTY  
 TEST EXECUTIVE PROGRAM SYSTEM (STEPS)

```

000080
000090
000100
000110
000120

```

THIS LISTING CONTAINS A PRELIMINARY INSTRUCTION TEST AND A  
 PRELIMINARY MEMORY TEST FOR THE 620 COMPUTER.

```

000130
000140
000150
000160

```

INSTRUCTION TEST

ONLY A BASIC SET OF INSTRUCTIONS ARE TESTED TO GAIN CONFIDENCE  
 THAT STANDARD TEST PROGRAMS CAN BE LOADED.  
 MOST OF THE SUBTESTS BUILD FROM PRECEDING SUBTESTS AND ASSUME  
 THAT THE INSTRUCTIONS USED PREVIOUSLY ARE WORKING.

```

000170
000180
000190
000200
000210
000220

```

MEMORY TEST

LOCATIONS 0 THRU EME1 (APPROX 07420) ARE EXERCISED  
 WITH AN ALTERNATE BIT PATTERN, AND ITS COMPLEMENT.  
 THE PREVIOUS CONTENTS ARE SAVED, AND RESTORED.

```

000230
000240
000250
000260
000270

```

SWITCHES

USE SS2 TO LOOP ON ERROR AFTER HALT  
 USE SS3 TO LOOP ON BOTH PRELIMINARY TESTS

```

000280
000290
000300
000310

```

LOADER

```

000320
000330

```

THE BINARY LOADER WILL ADAPT TO THE BOOTSTRAP  
AND LOAD/EXEC THE NEXT PROGRAM.

000340  
000350  
000360  
000370  
000380  
000390  
000400  
000410  
000420  
000430  
000440  
000450  
000460  
000470  
000480  
000490  
000500  
000510  
000520  
000530  
000540  
000550  
000560  
000570  
000580  
000590  
000600  
000610  
000620  
000630  
000640  
000650  
000660  
000670  
000680

INSTRUCTION TEST

```

006500      ORG      06500
*
006500      ENBT    TZA
006501      001010  JAZ      ENA1
006502      008210  R      ENA0
006503      001200  JSS2    ENBT
006504      000500  R
006505      000001  HLT     01
006506      001000  JMP     ENB0
006507      006523  R
006510      008211  ENA1   DAR
006511      024007  STA
006512      001004  JAN
006513      000213  R
006514      001000  JMP
006515      000003  R
006516      014502  ENA2   LDA
006517      025111  IAR
006518      001010  JAZ      ENB0
006519      000503  R
006520      001200  JSS2    ENA2
006521      000516  R
006524      000002  HLT     02
*
006525      024003  ENB0   LDA      ONES
    
```

ERROR--TZA/DAR/JAZ/JAN

ERROR--LDA/IAR/STA

PAGE	0003					
006526	001020		JBZ	ENR1		000690
006527	006533 R					
006530	005002		TZR			000700
006531	001020		JBZ	ENR2		000710
006532	006536 R					
006533	001200	ENR1	JSS2	ENR0		000720
006534	006525 R					
006535	000003		HLT	3	ERROR--LDB/JBZ/TZR	000730
006536	005122	ENR2	IBR			000740
006537	001020		JBZ	ENR3		000750
006540	006544 R					
006541	005322		DBR			000760
006542	001020		JBZ	ENR0		000770
006543	006547 R					
006544	001200	ENR3	JSS2	ENR0		000780
006545	006525 R					
006546	000004		HLT	4	ERROR--IBR/DBR	000790
		*				000800
		*				000810
		*				000820
006547	034631	ENR0	LDX	ONES		000830
006550	001040		JXZ	ENC1		000840
006551	006555 R					
006552	005004		TZX			000850
006553	001040		JXZ	ENC2	CONTINUE	000860
006554	006560 R					
006555	001200	ENC1	JSS2	ENC0		000870
006556	006547 R					
006557	000005		HLT	5	ERROR--LDX/JXZ/TZX	000880
006560	005144	ENC2	IXR			000890
006561	001040		JXZ	ENC3		000900
006562	006566 R					
006563	005344		DXR			000910
006564	001040		JXZ	END0	CONTINUE	000920
006565	006571 R					
006566	001200	ENC3	JSS2	ENC0		000930
006567	006547 R					
006570	000006		HLT	6	ERROR--IXR/DXR	000940
		*				000950
		*				000960
		*				000970
006571	014607	END0	LDA	ONES		000980

006572	054002		STA	**3		000990
006573	005001		TZA			001000
006574	006010		LDAI	1	(ALL ONES)	001010
006575	000001					
006576	001010		JAZ	END1		001020
006577	006602	R				
006600	001004		JAN	END2	CONTINUE	001030
006601	006605	R				
006602	001200	END1	JSS2	END0		001040
006603	006571	R				
006604	000007		HLT	7	ERROR--LDAI/JAN	001050
		*				001060
006605	134573	END2	ERA	ONES		001070
006606	001004		JAN	END3		001080
006607	006612	R				
006610	001010		JAZ	ENE0	CONTINUE	001090
006611	006615	R				
006612	001200	END3	JSS2	END0		001100
006613	006571	R				
006614	000010		HLT	010	ERROR--LDAI/ERA/JAN	001110
		*				001120
		*				001130
		*				001140
006615	014563	ENF0	LDA	ONES		001150
006616	054002		STA	**3		001160
006617	005001		TZA			001170
006620	006130		ERAI	1	(ALL ONES)	001180
006621	000001					
006622	001002		JAP	ENE1		001190
006623	006627	R				
006624	134554		ERA	ONES		001200
006625	001002		JAP	ENF0	CONTINUE	001210
006626	006632	R				
006627	001200	ENE1	JSS2	ENF0		001220
006630	006615	R				
006631	000011		HLT	011	ERROR--ERAI/JAP	001230
		*				001240
		*				001250
		*				001260
006632	014545	ENF0	LDA	ONES		001270
006633	054002		STA	**3		001280
006634	005002		TZB			001290

PAGE	0005					
006635	006020		LDBI	1	(ALL ONES)	001300
006636	000001					
006637	005021		TBA			001310
006640	001002		JAP	ENF1		001320
006641	006645	R				
006642	134536		ERA	ONFS		001330
006643	001010		JAZ	ENGO	CONTINUE	001340
006644	006650	R				
006645	001200	ENF1	JSS2	ENFO		001350
006646	006632	R				
006647	000012		HLT	012	ERROR--LDBI/TBA	001360
		*				001370
		*				001380
		*				001390
006650	014530	ENGO	LDA	ONES		001400
006651	054002		STA	*+3		001410
006652	005001		TZA			001420
006653	006030		LDXI	1	(ALL ONES)	001430
006654	000001					
006655	005041		TXA			001440
006656	001002		JAP	ENG1		001450
006657	006663	R				
006660	134520		ERA	ONES		001460
006661	001010		JAZ	ENHO	CONTINUE	001470
006662	006666	R				
006663	001200	ENG1	JSS2	ENGO		001480
006664	006650	P				
006665	000013		HLT	013	ERROR--LDXI/TXA	001490
		*				001500
		*				001510
		*				001520
006666	024511	ENHO	LDB	D125	CONSTANT=125252	001530
006667	005024		TRX			001540
006670	001640		JXZ	ENH1		001550
006671	006676	R				
006672	005041		TXA			001560
006673	134504		ERA	D125		001570
006674	001010		JAZ	ENIO	CONTINUE	001580
006675	006701	R				
006676	001200	ENH1	JSS2	ENHO		001590
006677	006666	R				
006700	000014		HLT	014	ERROR--LDB/TRX	001600

		*				001610
		*				001620
		*				001630
006701	014475	FNIO	LDA	D052	CONSTANT=052525	001640
006702	134474		ERA	D052		001650
006703	001010		JAZ	FNII	CONTINUE	001660
006704	006710	R				
006705	001200		JSS2	ENIO		001670
006706	006701	R				
006707	000015		HLT	015	ERROR--LDA/ERA	001680
		*				001690
006710	014467	ENII	LDA	D125	CONSTANT=125252	001700
006711	054470		STA	TS01	TEMP STORE	001710
006712	005001		TZA			001720
006713	014466		LDA	TS01		001730
006714	001010		JAZ	ENI2		001740
006715	006721	R				
006716	134461		ERA	D125		001750
006717	001010		JAZ	ENJO	CONTINUE	001760
006720	006724	R				
006721	001200	ENI2	JSS2	ENI1		001770
006722	006710	R				
006723	000016		HLT	016	ERROR--LDA/STA	001780
		*				001790
		*				001800
		*				001810
006724	024452	ENJO	LDB	D052	CONSTANT=052525	001820
006725	064453		STB	TS01	TEMP STORE	001830
006726	024453		LDB	TS01		001840
006727	005021		TBA			001850
006730	134445		ERA	D052		001860
006731	001010		JAZ	FNFO	CONTINUE	001870
006732	006735	R				
006733	001200		JSS2	ENJO		001880
006734	006724	R				
006735	000017		HLT	017	ERROR--LDB/STB	001890
		*				001900
		*				001910
		*				001920
006736	034440	ENKO	LDX	D052	CONSTANT=052525	001930
006737	074442		STX	TS01	TEMP STORE	001940
006740	034441		LDX	TS01		001950

PAGE 0007

006741	005041		TXA			001960
006742	134434		ERA	D052		001970
006743	001010		JAZ	ENLO	CONTINUE	001980
006744	006750	R				
006745	001200		JSS2	ENK0		001990
006746	006736	R				
006747	000020		HLT	020	ERROR--LDX/STX	002000
		*				002010
		*				002020
		*				002030
006750	005111	ENLO	IAR			002040
006751	005001		TZA			002050
006752	005002		TZR			002060
006753	003010		XAZ	ENLO		002070
006754	006750	R				
006755	006130		ERAI	1		002080
006756	000001					
006757	001010		JAZ	ENL1	CONTINUE	002090
006760	006764	R				
006761	001200		JSS2	ENLO		002100
006762	006750	R				
006763	000021		HLT	021	ERROR--XAZ	002110
		*				002120
006764	014414	ENL1	LDA	ONES		002130
006765	003020		XBZ	FNLO		002140
006766	006750	R				
006767	001010		JAZ	ENMO	CONTINUE	002150
006770	006774	R				
006771	001200		JSS2	ENLO		002160
006772	006750	R				
006773	000022		HLT	022	ERROR--XBZ	002170
		*				002180
		*				002190
		*				002200
006774	007400	ENMO	ROF			002210
006775	001001		JOF	ENM1		002220
006776	007002	R				
006777	007401		SOF			002230
007000	001001		JOF	ENM2		002240
007001	007005	R				
007002	001200	ENM1	JSS2	ENMO		002250
007003	006774	R				

007004	000023		HLT	023	ERROR--RDF/SDF/JCF	002260
007005	007400	*	ENM2	RIF		002270
007006	001001		JUF	ENM3		002280
007007	007012	R				002290
007010	001000		JMP	ENNO	CONTINUE	002300
007011	007015	R				
007012	001200	ENM3	JSS2	ENM2		002310
007013	007005	R				
007014	000024		HLT	024	ERROR--RDF/JCF/JMP	002320
		*				002330
		*				002340
		*				002350
007015	014363	ENNO	LDA	ONES		002360
007016	002000		JMPH	ENN1		002370
007017	007027	R				
007020	001010		JAZ	END0=5	CONTINUE	002380
007021	007034	R				
007022	001200		JSS2	ENNO		002390
007023	007015	R				
007024	000025		HLT	025	ERROR--JMPH/JMP*	002400
007025	001000		JMP	END0=5		002410
007026	007034	R				
007027	000007	* ENN1	DATA	7	ENTR = NONZERO	002420
007030	005001		TZA			002430
007031	001000		JMP*	ENN1		002440
007032	107027	R				002450
007033	000026		HLT	026	ERROR--JMP*	002460
007034	014722	*	LDA	07757	SIXTEEN BIT ?	002470
007035	006130		ERA1	04011	*	002480
007036	004011					002490
007037	001010		JAZ	END5	YES	002500
007040	007111	R				
007041	006010	ENNO	LOAI	052525		002510
007042	052525					
007043	004263		LWLA	19	A=125252	002520
007044	134333		ERA	0125		002530
007045	001010		JAZ	END1	CONTINUE	002540
007046	007052	R				
007047	001200		JSS2	ENNO		002550



007050	007041	R					
007051	000027		HLT	027	ERROR--LRLA		002560
							002570
007052	005002		* END1	TZR			002580
007053	006010			LDAI	052525		002590
007054	052525						
007055	004561			LLSR	17	A=0 B=125252	002600
007056	001010			JAZ	END2		002610
007057	007063	R					
007060	001200			JSS2	END1		002620
007061	007052	R					
007062	000030			HLT	030	ERROR--LLSR	002630
							002640
007063	005021		* END2	TBA			002650
007064	134313			ERA	0125		002660
007065	001010			JAZ	END3	CONTINUE	002670
007066	007072	R					
007067	001200			JSS2	END1		002680
007070	007052	R					
007071	000031			HLT	031	ERROR--LLSR	002690
							002700
			* END3				002710
007072	004461			LLRL	17	A=052525 B=0	002720
007073	134303			ERA	0052		002730
007074	001010			JAZ	END4		002740
007075	007101	R					
007076	001200			JSS2	END1		002750
007077	007052	R					
007100	000032			HLT	032	ERROR--LLRL	002760
007101	005021		END4	TBA			002770
007102	001010			JAZ	ENP0		002780
007103	007155	R					
007104	001200			JSS2	END1		002790
007105	007052	R					
007106	000033			HLT	033	ERROR--LLRL	002800
007107	001000			JMP	ENP0		002810
007110	007155	R					
			* END5				002820
							002830
							002840
007111	014265			LDA	0052		002850
007112	004261			LRLA	17	A=125252	002860

007113	134264		ERA	D125		002870
007114	001010		JAZ	END6		002880
007115	007121	R				
007116	001200		JSS2	END5		002890
007117	007111	R				
007120	000027		HLT	027	ERROR=>LRLA	002900
		*				002910
007121	005002	END6	TZB			002920
007122	014254		LDA	D052		002930
007123	004557		LLSR	15	A=0 B=125252	002940
007124	001010		JAZ	END7		002950
007125	007131	R				
007126	001200		JSS2	END6		002960
007127	007121	R				
007130	000030		HLT	030	ERROR=>LLSR	002970
		*				002980
007131	005021	END7	TBA			002990
007132	134245		ERA	D125		003000
007133	001010		JAZ	END8	CONTINUE	003010
007134	007140	R				
007135	001200		JSS2	END6		003020
007136	007121	R				
007137	000031		HLT	031	ERROR=>LLSR	003030
		*				003040
		*				003050
007140	004457	END8	LLRL	15	A=052525 B=0	003060
007141	134235		ERA	D052		003070
007142	001010		JAZ	END9		003080
007143	007147	R				
007144	001200		JSS2	END6		003090
007145	007121	R				
007146	000032		HLT	032	ERROR=>LLRL	003100
		*				003110
007147	005021	END9	TBA			003120
007150	001010		JAZ	END0		003130
007151	007155	R				
007152	001200		JSS2	END6		003140
007153	007121	R				
007154	000033		HLT	033	ERROR=>LLRL	003150
		*				003160
		*				003170
		*				003180

007155	014220	ENP0	LDA	D001		003190
007156	124222		ADD	DNES		003200
007157	001010		JAZ	ENP1	OK	003210
007160	007164	R				
007161	001200		JSS2	ENP0		003220
007162	007155	R				
007163	000034		HLT	034	ERROR--ADD	003230
007164	006120	ENP1	ADDI	0177777		003240
007165	177777					
007166	006110		ORAI	0177777		003250
007167	177777					
007170	006130		ERAI	0177777		003260
007171	177777					
007172	001010		JAZ	ENQ0	CONTINUE	003270
007173	007177	R				
007174	001200		JSS2	ENP0		003280
007175	007155	R				
007176	000035		HLT	035	ERROR--ADDI/ORAI	003290
		*				003300
		*				003310
007177	014177	ENQ0	LDA	D052	CONSTANT=052525	003320
007200	144176		SUB	D052		003330
007201	001010		JAZ	ENR0	CONTINUE	003340
007202	007206	R				
007203	001200		JSS2	ENQ0		003350
007204	007177	R				
007205	000036		HLT	036	ERROR--SUB	003360
		*				003370
		*				003380
		*				003390
007206	005001	ENR0	TZA			003400
007207	054172		STA	T301		003410
007210	014171		LDA	T301		003420
007211	005000		NOP			003430
007212	001010		JAZ	EN50		003440
007213	007217	R				
007214	001200		JSS2	ENR0		003450
007215	007206	R				
007216	000037		HLT	037	ERROR--NOP	003460
		*				003470
		*				003480
		*				003490

007217	014161	ENSO	LDA	ONES		003500
007220	024160		LOB	ONES		003510
007221	005103		INCR	03		003520
007222	005311		DAR			003530
007223	005322		DBR			003540
007224	001010		JAZ	ENS2		003550
007225	007233	R				
007226	001200	ENS1	JSS2	ENS0		003560
007227	007217	R				
007230	000040		HLT	040	ERROR--INCR 03	003570
007231	001000		JMP	ENTO		003580
007232	007237	R				
007233	001020	ENS2	JBZ	ENTO		003590
007234	007237	R				
007235	001000		JMP	ENS1		003600
007236	007226	R				
		*				003610
		*				003620
		*				003630
007237	005002	ENTO	TZB			003640
007240	005302		DECR	02		003650
007241	005021		TBA			003660
007242	134136		ERA	ONES		003670
007243	001010		JAZ	ENUD		003680
007244	007250	R				
007245	001200		JSS2	ENTO		003690
007246	007237	R				
007247	000041		HLT	041	ERROR--DECR 02	003700
		*				003710
		*				003720
		*				003730
007250	005103	ENUN	INCR	03		003740
007251	005122		IDR			003750
007252	005032		MERG	032		003760
007253	005021		TBA			003770
007254	005130		ERAI	03		003780
007255	000003					
007256	001010		JAZ	ENVO		003790
007257	007263	R				
007260	001200		JSS2	ENUD		003800
007261	007250	R				
007262	000042		HLT	042	ERROR--MERG 032	003810

		*				003820
		*				003830
		*				003840
007263	006010	ENVO	LDAI	0100		003850
007264	000100					
007265	004346		LSRA	6		003860
007266	005311		DAR			003870
007267	001010		JAZ	ENX0		003880
007270	007274 R					
007271	001200		JSS2	ENVO		003890
007272	007263 R					
007273	000043		HLT	043	ERROR--LSRA 6	003900
		*				003910
		*				003920
		*				003930
007274	006030	ENVO	LDXI	D125		003940
007275	007400 R					
007276	005001		TZA			003950
007277	015000		LDA	0,1		003960
007300	134077		ERA	D125		003970
007301	001010		JAZ	ENX0		003980
007302	007306 R					
007303	001200		JSS2	ENVO		003990
007304	007274 R					
007305	000044		HLT	044	ERROR--LDA 0,1	004000
		*				004010
		*				004020
		*				004030
007306	005001	ENX0	TZA			004040
007307	054072		STA	TS01		004050
007310	006030		LDXI	TS01		004060
007311	007402 R					
007312	014065		LDA	D125		004070
007313	055000		STA	0,1		004080
007314	134065		ERA	TS01		004090
007315	001010		JAZ	ENY0		004100
007316	007322 R					
007317	001200		JSS2	ENX0		004110
007320	007306 R					
007321	000045		HLT	045	ERROR--STA 0,1	004120
		*				004130
		*				004140

007322	014056	★	ENY0	LDA	DNES		004150
007323	006150			ANAI	0125252		004160
007324	125252						004170
007325	134052			ERA	0125		004180
007326	001010			JAZ	EN70		004190
007327	007333	R					
007330	001200			JSS2	ENY0		004200
007331	007322	R					
007332	000046			HLT	046	ERROR--ANAI	004210
		★					004220
		★					004230
		★					004240
007333	014044		ENZ0	LDA	0125		004250
007334	006050			STAI	01		004260
007335	000001						
007336	006030			LDXI	**1		004270
007337	007335	R					
007340	018000			LDA	0,1		004280
007341	134036			ERA	0125		004290
007342	001010			JAZ	EN10		004300
007343	007347	R					
007344	001200			JSS2	EN70		004310
007345	007333	R					
007346	000047			HLT	047	ERROR--STAI	004320
		★					004330
		★					004340
		★					004350
007347	005003		EN10	HERG	03		004360
007350	003022			XIF	022,EN11		004370
007351	007357	R					
007352	001004			JAN	EN20		004380
007353	007360	R					
007354	001200			JSS2	EN10		004390
007355	007347	R					
007356	000050			HLT	050	ERROR--XIF 022	004400
007357	005311		EN11	DAR			004410
		★					004420
		★					004430
		★					004440
007360	005001		EN20	TZA			004450
007361	007401			SDF			004460

007362	001011		JIF	011,EN22		004470
007363	007371	R				
007364	001200	EN21	JSS2	EN20		004480
007365	007360	R				
007366	000051		HLT	051	ERROR--JIF 011	004490
007367	001000		JMP	EMEM		004500
007370	007403	R				
007371	007400	EN22	RDF			004510
007372	001011		JIF	011,EN21		004520
007373	007364	R				
007374	001000		JMP	EMEM	START OF PRELIMINARY MEMORY TEST	004530
007375	007403	R				

\*  
\*  
\*  
\*  
\*

004540  
004550  
004560  
004570  
004580

DATA TABLE

007376	000001	D001	DATA	1		004590
007377	052525	D052	DATA	052525		004600
007400	125252	D125	DATA	0125252		004610
007401	000001	ONES	DATA	1	WILL BE MADE ALL ONES	004620
007402	000007	T801	DATA	7	TEMP. STORAGE, 7 FOR NON-ZERO BOOTSTRAP FORMAT	004630

\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*  
\*

004640  
004650  
004660  
004670  
004680  
004690

620 PRELIMINARY MEMORY TEST

TEST LOCATIONS 0 THRU EMEM WITH 052525 AND 125252 PATTERNS  
CONTENTS OF CELLS ARE SAVED AND RESTORED.

004700  
004710  
004720  
004730

007403	014052	EMEM	LDA	EMDA	052525 DATA WORD	004760
007404	054053		STA	EMDC	CURRENT TEST WORD	004770
007405	054053		STA	EMTS	TEMP STORE FOR DRG CONTENTS OF A LOCATION	004780
007406	005001		TZA			004790
007407	014051		LDA	EMTS		004800
007410	134047		ERA	EMDC	CURRENT TEST WORD	004810
007411	001010		JAZ	*+4		004820

004830

007412	007415	R						
007413	000007		HLT	7		ERROR HALT--TEMP STORE LOCATION BAD		004840
007414	005000		NOP					004850
007415	005002		TZR					004860
007416	005004	EME1	TZX					004870
007417	015000	EME2	LDA	0,1				004880
007420	054040		STA	EMTS		SAVE LOCATION CONTENTS		004890
007421	014036	EME3	LDA	EMDC		CURRENT TEST WORD		004900
007422	055000		STA	0,1		STORE IT		004910
007423	005001		TZA					004920
007424	015000		LDA	0,1				004930
007425	134032		ERA	EMDC		COMPARE WORD STORED WITH WORD READ		004940
007426	001010		JAZ	*+5				004950
007427	007433	R						
007430	001200		JSS2	EME3		LOOP ON ERROR		004960
007431	007421	R						
007432	000077		HLT	077		COMPARE ERROR HALT		004970
007433	014025		LDA	EMTS				004980
007434	055000		STA	0,1		RESTORE ORIGINAL CONTENTS		004990
007435	005041		TXA					005000
007436	005144		IXR					005010
007437	006140		SUBI	EME1		LAST LOCATION TO TEST		005020
007440	007416	R						
007441	001004		JAN	EME2		GO TO NEXT LOCATION		005030
007442	007417	R						
007443	001020		JBZ	EME4				005040
007444	007451	R						
007445	001400		JSS3	ENBT		REPEAT TESTS		005050
007446	006500	R						
007447	001000		JMP	BEGIN		GO MODIFY LOADER		005060
007450	007517	R						
007451	005122	EME4	IBR					005070
007452	014004		LDA	EMDB		125252 DATA PATTERN		005080
007453	054004		STA	EMDC				005090
007454	001000		JMP	EME1		LOOP THRU MEMORY		005100
007455	007416	R						
007456	052525	EMDA	DATA	052525		TEST WORD		005110
007457	125252	EMDB	DATA	0125252		TEST WORD		005120
007460	000001	EMDC	DATA	000001		CURRENT TEST WORD	(01 DATA FOR BOOTSTRAP)	005140
007461	000001	EMTS	DATA	000001		TEMP STORAGE	(01 DATA FOR BOOTSTRAP)	005150
		*						005160



007462 000001  
 007463 000001  
 007464 000001  
 007465 000001  
 007466 000001  
 007467 000001  
 007470 000001  
 007471 000001  
 007472 000001  
 007473 000001  
 007474 000001  
 007475 000001  
 007476 000001  
 007477 000001  
 007500 000001  
 007501 000001  
 007502 000001  
 007503 000001  
 007504 000001  
 007505 000001  
 007506 000001  
 007507 000001  
 007510 000001  
 007511 000001  
 007512 000001  
 007513 000001  
 007514 000001  
 007515 000001  
 007516 000001  
 007517 000001  
 007520 000001  
 007521 000001  
 007522 000001  
 007523 000001  
 007524 000001  
 007525 000001  
 007526 000001  
 007527 000001  
 007530 000001  
 007531 000001  
 007532 000001  
 007533 000001

DATA 1,1,1,1,1,1,1,1

BUFFER BETWEEN PROGRAMS

005170

DATA 1,1,1,1,1,1,1,1,1,1,1

005180

DATA 1,1,1,1,1,1,1,1,1,1,1

005190

DATA 1,1,1,1,1,1,1,1,1,1,1

005200

DATA 1,1,1,1,1,1,1,1,1,1,1

005210

007534 000001  
 007535 000001  
 007536 000001  
 007537 000001  
 007540 000001  
 007541 000001  
 007542 000001  
 007543 000001  
 007544 000001  
 007545 000001  
 007546 000001  
 007547 000001  
 007550 000001  
 007551 000001

DATA 1,1,1,1,1,1,1,1

005220

007466  
 007466 014302  
 007467 004546  
 007470 005001  
 007471 004542  
 007472 005111  
 007473 004547  
 007474 005111  
 007475 004457  
 007476 054000  
 007477 100400  
 007500 004546  
 007501 005101  
 007502 004543  
 007503 005111  
 007504 004541  
 007505 005111  
 007506 004545  
 007507 005111  
 007510 004457  
 007511 054001  
 007512 014003  
 007513 103100  
 007514 001000  
 007515 006500  
 007516 000223

ROFF

ORG 07466  
 LDA 07771  
 LLSR 6  
 TZA  
 LLSR 2  
 IAR  
 LLSR 7  
 IAR  
 LLRL 15  
 STA \*\*1  
 SEL 0400  
 LLSR 6  
 INCR 01  
 LLSR 3  
 IAR  
 LLSR 1  
 IAR  
 LLSR 5  
 IAR  
 LLRL 15  
 STA \*\*2  
 LDA BEGIN-1  
 DAR 00  
 JMP ENST

TURN READER OFF

TURN OFF HSPT

TURN OFF TTY

005230  
 005240  
 005250  
 005260  
 005270  
 005280  
 005290  
 005300  
 005310  
 005320  
 005330  
 005340  
 005350  
 005360  
 005370  
 005380  
 005390  
 005400  
 005410  
 005420  
 005430  
 005440  
 005450  
 005460

DATA 0223

\*\*\*\*\*

UPDATE LOADER TO TYPE OF INPUT  
 CONT

\* BEGIN

005470  
 005480  
 005490

007517 006020

LDRI

007520	007555	R					
007521	014247		LDA	07771			005500
007522	006150		ANAI	0100			005510
007523	000100						
007524	001010		JAZ	**4			005520
007525	007530	R					
007526	006020		LDBI	CONT+9			005530
007527	007566	R					
007530	006030		LOXI	END+3			005540
007531	007612	R					
007532	074003		STX	**4			005550
007533	034002		LDX	**3			005560
007534	015000		LDA	0,1			005570
007535	006050		STAI	1			005580
007536	000001						
007537	005341		DECR	041			005590
007540	001010		JAZ	BEG1			005600
007541	007547	R					
007542	016000		LDA	0,2			005610
007543	055000		STA	0,1			005620
007544	005122		IBR				005630
007545	001000		JMP	*-10			005640
007546	007533	R					
007547	006010		BEG1	LDAI	LOAD		005650
007550	007630	R					
007551	054027		STA	LHLT+2			005660
007552	005101		INCR	01			005670
007553	001000		JMP	LHLT+1			005680
007554	007600	R					
	007555	R	CONT	EQU	*		005690
			*				005700
007577			ORG	07577			005710
007577	000007		LHLT	HLT	7	OPERATOR SETS MODE	005720
007600	002000		CALL	ROFF=1		RDR OFF /// WILL = (LOAD)	005730
007601	007465	R					
007602	001000		JMP	**3		HALT FOR OPERATOR	005740
007603	007577	R					
			*				005750
			*	BINARY LOAD ROUTINE			005760
			*				005770
007604	007400		RDF	RDF			005780
007605	005002		TZB	TZB			005790

007606	074002	STX	DATA	074002	* ,STX ,LOAD	005800
007607	014141	END	LDA	CKSM		005810
007610	001011		JIF	011,LRCO	(GOOD LOAD RCD)	005820
007611	007635	R				
007612	007613	R	DATA	**1,**1,**1	READER OFF	005830
007613	007614	R				
007614	007615	R				
007615	007632	R	DATA	LOAD+2		005840
007616	005302		DECR	2		005850
007617	003010		XAZ	TZB		005860
007620	007605	R				
007621	014131		LDA	MODE		005870
007622	001010		JAZ	**4		005880
007623	007626	R				
007624	003022		XIF	022,STX	SET RETURN IF GOOD EXEC RCD	005890
007625	007606	R				
007626	034123		LDX	FRST	SET LAST ADDR READ	005900
007627	001000		JMP	*	RETURN,OR EXECUTE PROGRAM	005910
007630	007627	R				
		*			INIT SET TO PRELIM TEST	005920
007630		LOAD	BES	0	*ENTRY POINT	005930
007631	054121		STA	MODE	SAVE LOAD MODE	005940
007632	007633	R	DATA	**1,**1,IN	READER ON	005950
007633	007634	R				
007634	007730	R				
007635	007401	LRCO	SDF		*LOAD A RCD	005960
007636	002000		CALL	INPT	FIND RCD MARK	005970
007637	007732	R				
007640	004547		LLSR	7	LOOK FOR LEADER	005980
007641	001010		JAZ	**3	*	005990
007642	007636	R				
007643	002000		CALL	INPT	*	006000
007644	007732	R				
007645	001010		JAZ	**4		006010
007646	007651	R				
007647	001000		JMP	**4	*	006020
007650	007643	R				
007651	054077		STA	CKSM	RESET CHECKSUM	006030
007652	002000		CALL	LNRD	GET RCD LENGTH	006040
007653	007701	R				
007654	064077		STB	RCDL	IF 0	006050
007655	003020		XBZ	ROF	SET EXEC FLAG	006060

007656	007604	R					
007657	002000		CALL	LWRD	GET ADDR		006070
007660	007701	R					
007661	005024		TBX				006080
007662	064067		STB	FRST	SAVE ADDR		006090
007663	002000		LDATA CALL	LWRD	GET DATA OR CHECKSUM		006100
007664	007701	R					
007665	014066		LDA	RCDL			006110
007666	001010		JAZ	END	(END OF RCD)		006120
007667	007607	R					
007670	005311		DAR				006130
007671	054062		STA	RCDL	COUNT WORDS READ		006140
007672	014060		LDA	MODE			006150
007673	001004		JAN	**3			006160
007674	007676	R					
007675	065000		STB	0,1			006170
007676	005144		IXR		SET NEXT ADDR		006180
007677	001000		JMP	LDATA			006190
007700	007663	R					

\* READ AND CHECKSUM BINARY WORD

							006200
							006210
007701	000007		LWRD	DATA	7	ENTR POINT, DATA FOR LOADING PURPOSES ONLY	006220
007702	005103			INCR	3		006230
007703	005111			IAR			006240
007704	054072		LWR1	STA	TEMP	SET LOOP COUNTER	006250
007705	002000			CALL	INPT	GET SIX BITS	006260
007706	007732	R					006270
007707	144036		SUB	K40		REMOVE CODE	006280
007710	134035		ERA	K40			006290
007711	004005		ASLB	5			006300
007712	004041		LRLB	1			006310
007713	005032		MERG	032		ASSEMBLE DATA WORD	006320
007714	004346		LSRA	6			006330
007715	005311		DAR				006340
007716	001002		JAP	END+3		ERROR	006350
007717	007612	R					
007720	124056		ADD	TEMP			006360
007721	001002		JAP	LWR1			006370
007722	007704	R					
007723	005021		TBA				006380
007724	134024		ERA	CKSM		CALCULATE CHECKSUM	006390

Address	Instruction	Register	Op	Operand	Label	Address
007725	STA			CKSM		006400
007726	JMP*			LWRD		006410
007727		R				
	* INPUT PAPER TAPE					006420
	* INPT DATA INPT+1 CIA					006430
	* RETURN					006440
007730	JMP			*		006450
007731		R				006460
007732		R				
007732	INPT		BES	0	*ENTRY	006470
007733			DATA	1,IN	SEN IBFR RDY	006480
007734		R				
007735	JMP			*=2		006490
007736		R				
007737	OUT		QAR	01		006500
007740	JMP			*		006510
007741		R				
007741	DTPY		BES	0		006520
007742			SEN	0101,OUT		006530
007743		R				
007744	JMP			*=2		006540
007745		R				
	* K40 DATA 040					006550
007746						006560
007747	XON		DATA	0221	READER ON	006570
007750	XOFF		DATA	0223	READER OFF	006580
007751	CKSM		DATA	0	LOAD CHECKSUM	006590
007752	FRST		BSS	1	INITIAL DUMP ADDR	006600
007753	MODE		BSS	1		006610
007754	RCDL		BSS	1	RCD LENGTH	006620
	* RELOCATED INSTRUCTIONS					006630
007555	ORG		CONT			006640
007612	LDC		END+3			006650
007612	LDA	I001	XOFF		READER OFF *** TTY DA=01	006660
007613	CALL		DTPT			006670
007614		R				
007615	LDA		CKSM			006680
007561	ORG		CONT+4			006690
007632	LDC		LOAD+2			006700
007632	LDA		XON		READER ON	006710
007633	CALL		DTPT			006720
007634		R				

007635	102501		CIA	01	INPUT TO (A)	006730
007636	101201		DATA	0101201	SEN IBFR RDY	006740
007566			ORG	CONT+9		006750
007612			LOC	END+3		006760
007612	100437	I037	SEL	0437	READER OFF	006770
007613	005000		NOP		*	006780
007614	005000		NOP		*	006790
007615	005000		NOP		*	006800
007672			ORG	CONT+13		006810
007632			LOC	LOAD+2		006820
007632	100537		SEL	0537	READER ON	006830
007633	005000		NOP		*	006840
007634	005000		NOP		*	006850
007635	102537		CIA	037	INPUT TO (A)	006860
007636	101537		DATA	0101537	SEN IBFR RDY	006870
	007777	TEMP	SET	07777		006880
	007577	R	END	LHLT		006890

\*\*\* HSPT DA=37

LITERALS

POINTERS

SYMBOLS

0	007777	TEMP
0	007612	R I037
0	007612	R I001
1	007784	R RCCL
1	007783	R MODE
1	007782	R FRST
1	007781	R CK3M
1	007759	R XOFF
1	007747	R XON
1	007746	R K40
1	007741	R OTPT
1	007737	R OUT
1	007732	R INPT
1	007730	R IN
1	007704	R LNR1
1	007701	R LNR0
1	007663	R LDAT

1	007635	R	LRCO
1	007630	R	LOAD
1	007607	R	END
1	007606	R	STX
1	007605	R	TZB
1	007604	R	ROF
1	007577	R	LHLT
1	007555	R	CONT
1	007547	R	BEG1
1	007517	R	BEG1
1	007486	R	ROFF
1	007461	R	ENTS
1	007460	R	EMDC
1	007457	R	ENDB
1	007456	R	EMDA
1	007451	R	EME4
1	007421	R	EME3
1	007417	R	EMER
1	007416	R	EME1
1	007403	R	EMEM
1	007402	R	T801
1	007401	R	ONES
1	007400	R	D125
1	007377	R	D052
1	007376	R	D001
1	007371	R	EN22
1	007364	R	EN21
1	007350	R	EN20
1	007357	R	EN11
1	007347	R	EN10
1	007333	R	EN20
1	007322	R	ENY0
1	007306	R	ENX0
1	007274	R	ENW0
1	007263	R	ENV0
1	007250	R	ENU0
1	007237	R	ENT0
1	007233	R	ENS2
1	007220	R	ENS1
1	007217	R	ENS0
1	007206	R	ENF0
1	007177	R	ENG0



1	007164	R	ENP1
1	007155	R	ENP0
1	007147	R	ENQ9
1	007140	R	ENQ8
1	007131	R	ENQ7
1	007121	R	ENQ6
1	007111	R	ENQ5
1	007101	R	ENQ4
1	007072	R	ENQ3
1	007063	R	ENQ2
1	007052	R	ENQ1
1	007041	R	ENQ0
1	007027	R	ENN1
1	007015	R	ENN0
1	007012	R	ENM3
1	007005	R	ENM2
1	007002	R	ENM1
1	006774	R	ENM0
1	006764	R	ENL1
1	006750	R	ENL0
1	006736	R	ENK0
1	006724	R	ENJ0
1	006721	R	ENI2
1	006710	R	ENI1
1	006701	R	ENI0
1	006676	R	ENH1
1	006666	R	ENH0
1	006663	R	ENG1
1	006650	R	ENG0
1	006645	R	ENF1
1	006632	R	ENF0
1	006627	R	ENE1
1	006615	R	ENE0
1	006612	R	END3
1	006605	R	END2
1	006602	R	END1
1	006571	R	END0
1	006566	R	ENC3
1	006560	R	ENC2
1	006555	R	ENC1
1	006547	R	ENC0
1	006544	R	ENB3

1 006536 R ENB2  
1 006533 R ENB1  
1 006525 R ENB0  
1 006516 R ENA2  
1 006510 R ENA1  
1 006503 R ENA0  
1 006500 R ENST