Session: R23



IBM Systems Group

IBM Power and Cooling

Scott Tease WW Product Marketing- IT Infrastructure

> IBM @server xSeries August 2004

> > © IBM Corporation 2004

© 2004 IBM Corporation

	_
	_
_	

Planning for high density servers

What is different?

- ✓ Ever increasing chip speeds
- ✓Greater density
- ✓More PCI slots
- ✓ Larger drives More drives
- ✓More memory
- The results of this...
 - More power needed to run systems
 - ✓More BTU output from system
 - ✓ More cabling and complexity in the rack
- Things to consider
 - Racking considerations
 - ✓Power requirements
 - ✓Heat/thermal output
 - ✓ Air volume requirements
- Back up





IBM Systems Group

Understanding power, power supplies, and power distribution

© 2004 IBM Corporation

_		
-	_	

Overview of power supplies

Our power supplies are rated by the output they can deliver not the input

Example: the 1800W BladeCenter module is able to deliver up to 1800W of DC power

- A power supply can take in more AC power than it can deliver DC- the difference between the input requirement and the output is commonly called the efficiency rating
- Server content and server utilization determine the power draw not the size of the supply

AC power wattage is extremely useful

The numbers that we quote are worst case – worst case is constant

- Typical customer utilization is from 25-75% which reduces power usage greatly
- If server is not fully optioned up power usage will be less than max
- ✓ We quote worst case because that is not variable

In a redundant solution both power supplies share the load

- Each power supply delivers half the load if both are powered on and working properly
- Having supplies share the load leads to longer life, reduced failures
- One supply can carry the entire power requirement if called on

	- N.	_
		the second second
	_	_

IBM Server- power guide

	Power Supply	Input Power	Input Power	Line	PDU Planning	PDU Planning	Rack Power	Rack Power
System	Rating (DC)	(AC) Max	(AC) Typical	cords	(Amps @220V)	(Amps @110V)	Max (W)	Typical
x305	220	200	140	1	0.9	1.8	8400	5880
e325	411	587	400	1	2.7	5.3	24654	16800
x335	350	340	245	1	1.5	3.1	14280	10290
x345	514	500	350	1 or 2	2.3	4.5	10500	7350
x235	660	800	560	1 or 2	3.6	7.3	6400	4480
x360	370	740	520	2 or 3	3.4	6.7	10360	7280
x440	950	900	850	2	4.1	8.2	9000	8500
x445	1200	900	850	2	4.1	8.2	9000	8500
x450	1200	900	850	2	4.1	8.2	9000	8500
x365	950	1100	770	1 or 2	5.0	10.0	15400	10780
x255	370	1000	530	2	4.5	9.1	6000	3180
Bladecenter	1800	4000	3400	2 or 4	9.1	N/A	24000	20400

Notes:

Max is based on today's max configuration running at 100% utilization- guide for planning Typical is based on today's max configuration at average utilization- more realistic however you must really understand what the customer is doing with the server

Amperage guidance- max draw per line cord for planning. Normal operation for dual power is half this load, only failure mode demands this amperage.

CFM - Cubic Feet per minute.

Airflow- low at 22C or less, max at 32C+. Increase linear between the two.

		_		_
-	_	_		
		-	-	=
				_

Understanding power terms

- Wattage- a measurement of real power
- Amps-measurement of the rate of current flow
- Voltage- definition of the capacity
- Formulas:

Amps = Watts/Voltage

So if server draws 500W how many Amps will it draw at 100V and at 208V?

4.5A at 110V and 2.4A at 208V





What can we derive from AC information

An example with BladeCenter 1800W

90% efficient so 1800/.9 = 2000AC watts

2000W per domain is theoretical max (4000/chassis)

4000W (entire chassis) x 3.41 = <u>13,640BTU</u>

4000W/.99 = <u>4040VA</u>

2000/220V = <u>9.1A</u>

13,640/12000 = <u>1.13 tons</u>

BTU or heat output

BTU is a measurement of heat output from a device

AC wattage x 3.41 = BTU (3.41 is a constant)

X345 AC draw is 500W max BTU is therefore 1700

VA rating

Older way of looking at power usage

VA rating x power factor correction = wattage

IBM supplies are near unity (98%+)

X440 AC draw is 900W so VA rating is around 915 (near unity)

Amperage

Measurement of the current flow needed by a power supply

AC wattage divided by voltage = amps

X335 AC draw is 340W so amperage at 220V is 1.5A

Tonnage of AC

Measurement of the AC capacity needed for cooling BTU divided by 12000 = AC tons to cool

_	

Distributed Power Interconnect (DPI) PDUs

New set of high density PDUs

- Replaced the NetBAY family
- Easier to install- customer install versus electrician install
- Easier to scale up
- Smaller form factor frees up rack space
- Extremely outlet dense designs
- Industry leading power density
- Among the most advanced products available for high density power



More products to come...

Running new power feeds to a rack means substantial cost

20amp feed - \$450 - \$750US 30/32amp feed - \$800 - \$1200US 60/63amp feed - \$1500 - \$2000

IBM PDUs can help reduce some of this cost if used properly



The DPI Family of PDUs DPI 100-127V DPI Universal Rack PDU Rack PDU The Rack PDUs can be used on their own <u>Wall</u> 9 Rack PDU or Nema **Rack PDU** 1 phase Country-specific line 3-wire line cord cord and plug

The Universal Rack PDUs used with the DPI Front-end PDU to consolidate line cords

DPI Front-end PDU



© 2004 IBM Corporation



High Density PDUs

New PDUs is a combined Front End/Rack PDU

Improved power support for the high end- x360, x440, x450, BladeCenter

Complete racks of BladeCenter - only four PDUs, four power feeds

3-phase delivers more power than previously possible

Full rack width

10



73P5844	DPI 32amp 3-phase High Density C19 PDU with IEC 309 32A 3P+N+Gnd (250V) line cord
73P5847	DPI 60amp 3-phase High Density C19 PDU with IEC 309 60A 3P+Gnd (208V) line cord
73P5856	DPI 63amp 1-phase High Density C19 PDU with Fixed IEC 309 63A 3P+N+Gnd (250V) line cord
73P5855	DPI 60amp 1-phase High Density C19 PDU with IEC 309 60A 2P+Gnd (208V) line cord





PDU sizing assistance- fact finding

Items that are needed to pick PDUs

- Determine what does the customer want in a PDU structure?
 - ✓The cheapest?
 - ✓ Redundancy
 - Lowest number of line cords fed to the rack

Need to know the type of power source customer wants to use

- ✓ Is this World Trade (International) or North American power
- ✓ What is the amperage they are capable of running- 20, 30, or 60
- ✓ Single phase or three phase
- Number and type of servers and options
 - Need wattage of supply
 - Number of line cords

We have designed the DPI PDU family to cover a broad range of customer needs

- ✓ PDUs work alone or together
- Number of outlets are easily scalable for growth
- ✓ PDUs can be mounted in a variety of locations
- ✓ DPI PDUs are designed for powering and protecting IBM servers



What type of PDU fits your location?

Simplify the type of PDUs you need to work with

The PDUs designed for the World Trade (International) countries and those designed for North American systems differ greatly.

	North American	World Trade
Countries	North America, Japan, Taiwan, Saudi, Philippines	Rest of the globe
Rack PDUs	20A Rack PDU 32P1736	20A Rack PDU varies by country (32P1736-1749)
	Nema PDU 32P1761	
Front End PDUs	30A Front End PDU for low voltage (100-127V) is 32P1751	32A Front End PDU is 32P1752
	30A Front End PDU for high voltage (200-208V) is 32P1766	63A Front End PDU is 32P1754
	60A Front End PDU (200-208 only) is 32P1767	
High Density PDU	60A Single Phase High Density PDU (200-208V) is 73P5855	63A Single Phase High Density PDU (220-240V) is 73P5856
	60A Three Phase High Density PDU (200-208V) is 73P5847	32A Three Phase High Density PDU (220-240V) is 73P5844

The rules governing how we use these PDUs also differ greatly.



PDU sizing assistance- The basics

Need to know the type(s) of power supply customer has

- Itemize the type and number of each server in the rack
- Each server power supplies is unique and draws a specific amount of power
- Each server power topology is different- some have 1, 2, 3, or 4 supplies and corresponding line cords
- Begin adding servers to the Rack PDUs until you reach a limit either amperage or outlets
- Rack PDU has a limit of 15amps in total or 10A per outlet
- ✓ Seven C13 outlets
- If more than two Rack PDUs and lines are needed look into consolidating with the Front End PDUs
- Front End PDUs have a limit of either 24, 32, 48 or 63amps depending on type and location installed or 16A per outlet
- ✓ Three C19 outlets
- When adding FE PDUs into the topology be careful not to exceed power limits- two maxed out Rack PDUs will fully utilize a FE PDU

The new High Density PDUs are a combined Rack and FE PDU. Amperage limitations depend on type of power input- single phase or three phase

14



Line cords & connectors

C13 connector- 10A rated (female) Rack PDU outlet Mating connector to server	O	
C14 connector- 10A rated (male) The inlet on most servers & options Rack jumper cords		
C19 connector- 16A rated (female) FE PDU Outlet FE to Rack PDU cable, BC line cord	• []•	
C20 connector- 16A rated (male) BladeCenter and Rack PDU inlets Part of BladeCenter line cord		R.

Lower number is female. Power flows from female to male.

© 2004 IBM Corporation



PDU connector info

- The higher power PDUs use industry standard IEC connectors
- These connectors are used world wide and are approved for application in the US and CAN
- Here is information on the two main connectors used in the high power PDUs

The 60A 3phase High Density PDU

Receptacle or connector is a type, 3 Phase 60A, 250V,3P4W or 3 Pole and Ground, connected to a 3 Phase 208 Volt, 60 A service.

Link: http://mennekes.com/pdf/ME_460P9W.pdf PART NO.: ME 460C9W DESCRIPTION: 60AMP 3 Phase 4W 250VAC Connector CONSTRUCTION:Watertight IEC IP 67 APPROVALS: UL Listed Standards 1682 CSA Certification to Spec. C22.2 No.182.1 IEC 309 - 1; IEC309 - 2 IEC COLOR CODE: Blue GROUND PIN: 9 Hour Position Mates with Male in 3 Hour Position.

The 60A 1Phase Front End or High Density PDU

Receptacle could be Mennekes type, 1 Phase 60A, 250V,2P3W or 2 Pole and Ground, connected to a 1 Phase 208 Volt, 60 A service.

Link: :http://mennekes.com/pdf/ME_360P6W.pdf PART NO.: ME 360C6W DESCRIPTION: 60AMP 1 Phase 3W 250VAC Connector, Watertight IEC IP 67 APPROVALS: UL Listed Standards 1682; 1686 CSA Certification to Spec. C22.2 No.182.1 IEC 309 - 1; IEC309 - 2 IEC COLOR CODE: Blue GROUND PIN: 6 Hour Position Mates with Male in 6 Hour Position.

Alternately, please check the Hubbell weblink below.

The output at each IEC320--C19 outlet will be 208 Vp-p.

http://www.hubbellcatalog.com/wiring/section-e-datasheet.asp?PN=HBL360R6W&FAM=PS&P=5957,6509,6121,6125

1				
_		_		-
		-	-	
			_	
	_	_		_
		_		





A North Americas Example

Customer wants to install 18 - x345s into a rack and needs power information

- This version of the x345 has a 350W supply- so operating at 208V the server will draw a max of 2.25A per supply
- ✓ X345 has two line cords and two power supplies- 36 line cords total

This means we can add up to 6 servers to each Rack PDU since it has a limit of 15A Since we have more than two Rack PDUs and lines consolidating with the Front End PDUs makes sense if the customer can supply us with a 30A outlet at the rack

- Three Racks PDUs each drawing over 13A of power well exceeds the amount of power that a 30A (24A) PDU can deliver so we should move this customer to 60A (48A) PDU.
- A quick check 13A times three Rack PDUs is less than the 48A available from the 60A Front End PDU so we are fine.



		and the second
-	-	
	_	
	_	

	Max system air	Min system air	Rack CFM	Rack CFM
System	flow - CFM	flow - CFM	Max	Min
x 3 0 5	3 5	2 5	1470	1050
e 3 2 5	4 0	2 5	1680	1050
x 3 3 5	4 0	2 5	1680	1050
x 3 4 5	98	5 2	2058	1 0 9 2
x 2 3 5	9 0	5 0	720	400
x 3 6 0	1 1 0	6 0	1540	840
x 4 4 0	175	100	1750	1000
x 4 4 5	175	100	1750	1000
x 4 5 0	175	100	1750	1000
x 3 6 5	320	74	4480	1036
Bladecenter	465	265	2790	1590

Airflow requirements by server

Air flow is cumulative- add them all up and you get the rack level data

All IBM servers work in the same manner - as inlet temperatures increase so does air flow (CFM)

•Minimum fan speeds are found at temperatures less than 25C

•Maximum fan speeds are found at and above 32C

•The increase is linear to the temperature increase

•The server MM controls fan speed, responding to inlet temp changes.



IBM Systems Group

How the rack and data center work

© 2004 IBM Corporation

IBM

Racking considerations

The rack is the basic building block of the data center

Rack needs to be engineered to be part of the thermal solution

- ✓ A poorly designed rack can lead to poor cooling efficiency
- ✓ Shallow racks do not allow room in rear for cable placement
- Racks with poor airflow will starve servers of needed cooling
- Need for fans interrupts natural airflow in data center and in rack

IBM racks allow for highly efficient cooling

- Designed not to allow hot air recirculation within the rack
 - •Side design does not let air from back of rack escape to the front
 - •Rack front to back partition works properly even when in a suite
 - •Top and bottom of rack are set up so that there is not unblock able spaces to let air leak to front
- ✓ Solid top in front of rack
 - •Less chance of hot air re-circulation over top of rack
 - •Racks with perf top cause more problems that they are worth

note: even a well designed rack that is not set up properly will cause air recirculation within the rack







 _	_

How the Rack Works

What are the requirements for cooling our servers?

✓IBM servers are designed to work at temperatures above HP and Dell

✓ Inlet air temperatures maintained at or below 35oC temperature for elevation below 3k feet, or 32oC for elevation between 3k and 7k feet

✓Humidity 8-80%

✓ Front to back cooling- the most efficient method available

✓ Plenty of space in front and rear as well as over head to handle thermal physics

 Enough CFM (cubic feet per minutevolume) of air to supply the server- this varies by server



	_	
	_	
_		
		= 7 =

How the data center works

Typical data center

It is a complex environment

- Items of interest
- Perforated tiles
- Raised floor
- Aisle ways- hot and cold
- ✓ Ceiling height
- Density in the cabinet
- Cooling assets
- ✓ Cable opening
- ✓ Types of racks
- ✓ Number of racks
- ✓ KW load of equipment





The data center and how it works

The key requirement maintain rack inlet temperatures within manufacturers specifications



Subfloor

• 2 separate complex thermo-fluid problems- (1) Underfloor air distribution (2) Above floor air/temperature distribution



Examples of different data centers





Raised Floor Supply/Ceiling Supply







_	

Examples of poor data center design



Progressive Oven Design

✓ All racks facing the same direction:

✓ Hot air from rack 1 is taken in as cooling air through rack 2 and so on.

✓ Last rows can get much hotter than first racks



The Seems Like a Good Plan Design

✓ Racks with solid doors that feed cool air directly into the rack

Low total CFM can cause problems

- Each rack is a potential failure point
- \checkmark Usually depends on fans which fail
- ✓ Depending on ceiling height fans can push air fast enough that it will bounce back down to inlet

	the second second

There is a lot of information out there to help

Available on ibm.com

- ✓ Decision Makers Guides
- IBM NetBAY Rack product overview
- ✓ IBM KVM and ACT products
- IBM UPS Guides- low voltage and high voltage products
- ✓ IBM PDUs options
- ✓ Flat Panel products

Spec sheets

- ✓IBM Remote Console Manager
- ✓IBM Local Console Manager
- ✓IBM UPS3000X family
- ✓ IBM UPD Tower family
- ✓ IBM DP Interconnect PDU- translated into several languages
- (Japanese, Chinese, Korean, French, German, Spanish, Italian)

Internal documents

✓ Problem solving guide to ACT - frequently asked question guide version 2.0



BladeCenter Installation and Planning Information

For use with customers



Installing BladeCenter

Rack information

- ✓ 7U high mechanical
- Chassis mounts on rail kit which fits in a standard 19" rack (conforms to EIA 310D standards)
- Chassis can be fixed to rack with thumb screws
- Everything is accessible from front or back of rack
- BladeCenter chassis is 28" deep
 - •Rear module handles add greater depth (approx 2 inches)
 - •Front handles also add about 2 inches
 - •Acoustic module adds a little more than 7 inches to depth

Weight

- A fully configured BladeCenter can weigh close to 110kg (240 lbs)
- Unit contains handles to lift it, best to install chassis then install blades and modules- empty chassis 18.2kg (40 lbs)
- Full racks of BladeCenters can approach 820kg (1800 lbs)



		_
_	=	

Power basics

Power basics



BladeCenter is only supported at high line power- 200-240V

Red Power Supplies

- Optional for 86771XX/2XX Chassis
 - (single p/n, two supplies)
- Operate as Redundant Pair
- Provides redundant power for Blades 7-14
- Load balancing power supplies
- Maximum draw from each supply 1XX
- 1200- 7.5A
- -1400-9.0A 1XX
- -1800-12.0A **2XX**

Blue Power Supplies

- Standard in 86771XX/2XX Chassis
- Operate as Redundant Pair
- Provides redundant power for Chassis Modules and Blades 1-6
- Load balancing power supplies
- Maximum draw from each
- 1200- 7.5A 1XX
- 1400- 9.0A 1XX
- 2XX - 1800- 12.0A



- 16A C20 style In some installations we exceed the 10A rating of the
 - more common C14 inlet

		_
	- N.	
_	_	_
	_	

BladeCenter power supplies

IBM power supplies are rated by the output they can deliver not the input

Example: the 1800W BladeCenter module is able to deliver 1800W of DC power

- A power supply will take in more AC power than it can deliver DC- the difference between the input requirement and the output is commonly called the efficiency rating
- The BladeCenter 1800W supply requires about 2100W input
- The power supplies in our high performance servers are extremely efficient
- The numbers that we quote are worst case scenario- they are what the supply could deliver if the server was fully equipped and at full utilization
- ✓ Typical customer utilization is from 25-75%
- ✓ We quote worst case because that is not variable
- In a redundant solution both power supplies share the load
- Each power supply delivers half the load if both are powered on and working properly
- ✓ Having supplies share the load leads to longer life, reduced failures
- One supply can carry the entire power requirement if called on



What is the real power usage?

- Power usage increases with work load and option content
- Most customers find themselves in the 25-70% utilization range



Power versus utilization

Information measured from domain 2 fully configured: Dual 3.2Mhz, 8GB memory, 2 IDE. Plot points are approximate

-		
	`	==

Power comparisons

32

•	X345	• X335	 BladeCenter
	450W per server	350W per server	3600W per chassis
	2 processors	2 processors	28 processors
	<u>225W per processor</u>	175W per processor	128W per processor

Ī	Power Configurator			
Quantity	Description	Idle Power	Max Power	Current
1	Blade Center	1206 W	2849 W	12.3 A
	Domain 1	554 W	1311 W	5.7 A
1	IBM BladeCenter Chassis			
	Power Supplies for Blades 1-6: 2x 12	200 W & Blades	7-14: 2x 1400 W	/
	1 Management Module(s)			
	(1) 4-Port Gigabit Ethernet Switch M	odule		
6	HS20			
	(2) 2.8 GHz Xeon (533 MHz)			
	(2) 1024 MB Dimm(s)			
	(2) 40 GB 5400-rpm ATA-100 HDD			
	Domain 2	651 W	1538 W	6.7 A
8	HS20			
	(2) 2.8 GHz Xeon (533 MHz)			
	(2) 1024 MB Dimm(s)			
	(2) 40 GB 5400-rpm ATA-100 HDD			



Power consumption

- Is BladeCenter a power hog?
- The initial perception of blade servers in general was that they were very power intensive. This was primarily due to the rack density possible with these ultra dense offerings
- The truth however is that many blade servers provide a way to add processing power more 'power' efficient than traditional servers and competitive blade offerings.

What is limiting density in today's data center?

- ✓ Real estate in the rack
- Power input
- ✓ Thermal output
- ✓ Airflow requirements

These limitations in the data center led IBM to rethink how we design servers

- More energy efficient power supplies
- A drive to new technologies that can reduce power- new memory technology
- Efficient low power high speed fans
- Finding ways to share components across multiple systems



The Gartner Report- what does it really mean?

Gartner recently published an Electrical Requirement Study¹ comparing similar dual processor server configurations including IBM BladeCenter, a generic 1U, and HPs BL20p G2. The power savings by using BladeCenter were readily apparent but what does this power savings really mean to the bottom line?

	1U server	HP BL20p G2	IBM BladeCenter	
Max configuration/rack	84 Xeon DP 3.2Ghz	96 Xeon DP 3.2Ghz	168 Xeon DP 3.2Ghz	
Number of processors	72	72	72	
U space required	36	30	21	
Power requirement	15,912W	13,891W	8,872W	
Heat output	54,260 BTU	47,365 BTU	30,255 BTU	

For customers that adopt BladeCenter the savings will come in three different forms

Raw electricity cost savings – less money to your utility company

Reduced cooling costs – less cost to run your AC units at max

✓ Reduced infrastructure build out costs in the data center – the ability to get more processing power in your current thermal or power envelop

¹Electrical Requirements for Blade Servers. Written by Jane Wright (G00120690) released April 24, 2004. Available from Gartner Research.

²Comparison was done on similar dual 3.2Ghz servers, with 4GB memory, Fibre connectivity, and dual ethernet switching.



The Cost (more accurately the savings) of Ownership

Electricity cost savings – the easiest to see and understand.

- ✓ If we assume an average corporate customer is paying \$.05US per kilowatt over an entire day BladeCenter has the capability to save users about \$6.00/day over HP and \$7.00/day over 1U.
- Not sounding like much? Over a year this could mean savings in this one rack of over \$2000.

Reduced cooling costs – power not used means heat that is not generated

- For every 12,000BTUs produced it requires 1 ton of AC cooling capacity- so in our example BladeCenter saved about 17,000BTU or 1.4 tons of cooling compared to HP and 24,000BTU or 2 tons compared to the 1U
- This also adds to the electrical saving you may see from not having to run your AC units at max capacity
- Reduced infrastructure costs in the data center if your one of the many customers bumping the ceiling of what your data center can handle from a thermal load this one is big
- This level of cooling savings spread out over many racks in the data center will not take long to add up to entire HVAC units worth of cooling

³Power input costs: Average cost for power varies considerably around the world. In the US the numbers vary from \$.02-\$.08/KWh for business customers. Conservative average is \$.05/KWh.

36



Fitting the most into the power/thermal envelope



Shared resources and energy efficiency means IBM BladeCenter allows users to pack more processors into a given power/thermal limitation

Air flow requirements

 BladeCenter blowers are completely redundant and hot swappable

Note: These two blowers take the place of 112 individual fans found in a comparable 14 server 1U installation

- The MM controls blowers, they respond to external temperature changes
- Inlet temperature is critical- temperatures at the back of the rack are less critical
- At 25°C the airflow required by BladeCenter will be 265CFM (cubic feet per minute)
- As temperatures rise to 32°C the fans increase in speed to a maximum of 465CFM. Blowers also go to max in the event of a management module failure
- The increase is linear to the temperature increase
- For a 3 BladeCenter installation under normal data center conditions we need 795CFM of air flow





		_		_
-	_	_		_
		-	_	=
				_

Airflow comparisons

- BladeCenter
 265 CFM per chassis at <25C
 28 processors
 <10 CFM per processor
- X345
 52 CFM per server at <25C
 2 processors
 26 CFM per processor
- X335

38

- 40 CFM per server at <25C
- 2 processors
- 20 CFM per processor



Summary

BladeCenter is a very efficient user of power, air, and thermal as compared to alternative products

- Compared to the x335, HP, or Dell 1U offerings BladeCenter uses at least 20% less power in normal operation
- Compared to HP blades IBM can save more than 20% at like density and utilization

If BladeCenter contains industry standard components how can it run with less power?

✓ Shared Infrastructure

- Common fans
- Common CD and Floppy
- Shared Management and midplane
- Energy Efficient power supplies
 - 90%+ AC to DC conversion means less AC is lost to heat

Smart server design will reduce power consumption. As long as customers want to deploy the most computing power/watt blades will be a focus

Infrastructure Savings

Per 42 Servers (IDE, dual SAN, dual enet, KVM, redun pwr)	1U Servers	Blades	Reduction / Addition
Rack Space	42U	21U	-50%
Ethernet Cabling	84	6 / 24	-71%
Fibre Channel Cabling	84	12	-86%
KVM Cabling	42	0/3	-93%
Systems Mgmt Cabling	42	6	-86%
Power Cords	84	12	-86%
PDU's	8	4	-50%
KVM Switches	6	0/1	-83%





A North Americas Example

Customer wants to install 42 blades (3 BladeCenters) into a rack

- BladeCenter has four 1800WDC supplies. Maximum draw from these supplies is 2000W AC.
- BladeCenter has four line cords and four power supplies- 12 line cords total
- BladeCenter has a 16A rated input

The best choice for larger installations of BladeCenter is the High density PDU. To power three BladeCenters 3 phase power is best.

- The Max draw from a BladeCenter power supply is 12A
- The 3phase PDU can deliver 28A per phase (derated or 34A not derated).
- ✓ We can put a pair of power supplies on each phase for a total of 3 BladeCenters.

